₩KD 948 021 **08**

12/06

© Dr. Ing. h.c. F. Porsche AG

Porsche, the Porsche crest, Cayenne, Tiptronic and Tequipment are registered trademarks and the distinctive shapes of Porsche automobiles are trademarks of Dr. Ing. h.c. F. Porsche AG.

All rights reserved.

Printed in Germany

Dear Owner,

We would like to thank you for your purchase of a Porsche Cayenne. Judging by the car you have chosen, you are a motorist of a special breed, and you are probably no novice when it comes to automobiles.

Remember however, as with any vehicle, you should take time to familiarize yourself with your Porsche and its performance characteristics. Always drive within your own unique capabilities as a driver and your level of experience with your Porsche. Ensure that anyone else driving your Porsche does the same. To prevent or minimize injury, always use your safety belts. Never consume alcohol or drugs before or during the operation of your vehicle.

This Owner's Manual contains a host of useful information. Please take the time to read this manual before you drive your new Porsche. Become familiar with the operation of your Porsche car for maximum safety and operating pleasure. The better you know your Porsche, the more pleasure you will experience driving your new car.

Always keep your Owner's Manual in the car, and give it to the new owner if you ever sell your Porsche.

A separate Maintenance Booklet explains how you can keep your Porsche in top driving condition by having it serviced regularly.

A separate Warranty and Customer Information Booklet contains detailed information about the warranties covering your Porsche.

For U.S. only:

If you believe that your vehicle has a fault which could cause a crash, injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying Porsche Cars North America, Inc. (Porsche Cars N.A.).

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety problem exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you and your dealer, or Porsche Cars N.A..

To contact NHTSA, you may call the Vehicle Safety Hotline toll-free at 1–888–327–4236 (TTY:

1-800-424-9153); go to

http://www.safercar.gov; or write to: Administrator, NHTSA, 400 Seventh Street, SW., Washington. DC 20590.

You can also obtain other information about motor vehicle safety from http://www.safercar.gov.

Your car has thousands of parts and components which have been designed and manufactured in accordance with Porsche's high standards of engineering quality and safety.

Any alteration of the vehicle may negate or interfere with those safety features built into the vehicle. Modifications may be carried out on your vehicle only if approved by Porsche.

Your Porsche is intended to be used in a safe manner obeying the local laws and in the light of driving conditions faced by you, and in accordance with the instructions provided in this Owner's Manual.

Do not misuse your Porsche by ignoring those laws and driving conditions, or by ignoring the instructions in this manual.

Any alteration or misuse of the vehicle can lead to accidents and severe or fatal personal injuries.

Regularly check your vehicle for signs of damage.

Damaged or missing aerodynamic components such as spoilers or underside panels affect the driving behavior and therefore must be replaced immediately.

Your car may have all or some of the components described in this manual.

Should you have difficulty understanding any of the explanations of features or equipment installed in your vehicle, contact your authorized Porsche dealer. He/She will be glad to assist you. Also check with your dealer on other available options or equipment.

Throughout this booklet, left is designated as the driver's side of the vehicle, and right as the passenger's side of the vehicle.

Text, illustrations and specifications in this manual are based on the information available at the time of printing.

It has always been Porsche's policy to continuously improve its products. Porsche, therefore, reserves the right to make changes in design and specification, and to make additions or improvements in its product without incurring any obligation to install them on products previously manufactured.

We wish you many miles of safe and pleasurable driving in your Porsche.

/ Important!

For your own protection and longer service life of your car, please heed all operating instructions and special warnings. These special warnings use the safety alert symbol, followed by the words **Danger, Warning and Caution**. These special warnings contain important messages regarding your safety and/or the potential for damage to your Porsche. Ignoring them could result in serious mechanical failure, serious personal injury or death.

- Do not alter your Porsche. Any alteration could create dangerous conditions or defeat safety engineering features built into your car.
- Do not misuse your Porsche. Use it safely, and consistently with the law, according to the driving conditions, and the instructions in this manual.

Alteration or misuse of your Porsche could cause accidents and severe or fatal personal injuries.

Note to owners

In Canada, this manual is also available in French. To obtain a copy contact your dealer or write to:

Note aux proprietaires

Au Canada on peut se procurer un exemplaire de ce Manuel en français auprès du concessionaire ou du:

Porsche Cars Canada, Ltd. Automobiles Porsche Canada, LTEE

5045 Orbitor Drive Building #8, Suite 200 Mississauga, Ontario Canada L4W 4Y4

Telephone number for customer assistance: 1-800-PORSCHE / Option 3

Setting and operating vehicle components when driving



There is a danger of accident if you set or operate the on-board computer, radio, navigation system, telephone or other equipment when driving.

This could distract you from the traffic and cause you to lose control of the vehicle.

- Operate the components while driving only if the traffic situation allows you to do so safely.
- ► Carry out any complicated operating or setting procedures only with the vehicle stationary.

Portable Fuel Containers



Portable fuel containers, full or partially empty, may leak, causing an explosion, or result in fire in case of an accident.

Never carry additional fuel in portable containers in your vehicle.

Engine Exhaust



Engine exhaust is dangerous if inhaled. Engine exhaust fumes have many components which you can smell. They also contain carbon monoxide (CO), which is a colorless and odorless gas.

Carbon monoxide can cause unconsciousness and even death if inhaled.

Never start or let the engine run in an enclosed, unventilated area.
 It is not recommended to sit in your car for prolonged periods with the engine on and the car not moving.

California Proposition 65 Warning



Engine exhaust, some of its constituents, and certain vehicle components contain or emit chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. In addition, certain fluids contained in vehicles and certain products of component wear contain or emit chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

Vehicles with SportDesign package



Risk of damage. On vehicles with Sport-Design package, front, rear, and side member trim are painted and located lower on the vehicle. Off-road driving can seriously damage these trim parts.

- ▶ When driving off-road, make sure these parts are not damaged.
- Make sure there is sufficient clearance between obstacles and the underside of the vehicle.
- ▷ Avoid driving through water.
- ▶ Do not use side member trim as a running board.

Fuel Quality

Your engine is designed to provide optimum performance and fuel economy using **unleaded premium fuel with an octane rating of 98 RON (93 CLC or AKI)**. Porsche therefore recommends the use of these fuels in your vehicle.

Porsche also recognizes that these fuels may not always be available. Be assured that your vehicle will operate properly on unleaded premium fuels with octane numbers of at least **95 RON (90 CLC or AKI)**, since the engine's "Electronic Oktane™ knock control" will adapt the ignition timing, if necessary.

▷ Do not use fuel additives without Porsche approval.

Fuels containing ethanol

▶ Do not use any fuels containing more than 10 percent ethanol by volume.

We recommend, however, to change to a different fuel or station if any of the following problems occur with your vehicle:

- Deterioration of driveability and performance.
- Substantially reduced fuel economy.
- Vapor lock and non-start problems, especially at high altitude or at high temperature.
- Engine malfunction or stalling.

Dear Porsche Owner

A lot has gone into the manufacture of your Porsche, including advanced engineering, rigid quality control and demanding inspections. These engineering and safety features will be enhanced by you...

the safe driver...

- who knows his car and all controls.
- who maintains the vehicle properly,
- who uses driving skills wisely and always drives within her/his own capabilities and the level of familiarity with the vehicle.

You will find helpful hints in this manual on how to perform most of the checks listed on the following pages. If in doubt, have these checks performed by your authorized Porsche dealer.

Before driving off...

Check the following items first

- ► Turn the engine off before you attempt any checks or repairs on the vehicle.
- ▶ Be sure the tires are inflated correctly. Check tires for damage and tire wear.
- ▶ See that wheel bolts are properly tightened and not loose or missing.
- Check engine oil level, add if necessary. Make it a habit to have engine oil checked with every refueling.
- Check all fluid levels such as windshield washer and brake fluid levels.
- ▶ Be sure the vehicle battery is well charged and cranks the engine properly.
- ▶ Check all doors and lids for proper operation and latch them properly.
- Check and if necessary replace worn or cracked wiper blades.
- See that all windows are clear and unobstructed.
- Check air intake slots and area between engine compartment lid and windshield. Ensure that these areas are free of snow and ice, so the heater and the windshield wipers work properly.

- If a child will be riding in the vehicle, check child seat/child seat restraint system to ensure that restraints are properly adjusted.
- Check all exterior and interior lights for operation and that the lenses are clean.
- Check the headlights for proper aim, and if necessary, have them adjusted.
- ▷ Check under the vehicle for leaks.
- ▶ Be sure all luggage is stowed securely.

Emergency equipment

It is good practice to carry emergency equipment in your vehicle.

Some of the items you should have are: window scraper, snow brush, container or bag of sand or salt, emergency light, small shovel, first-aid kit, etc.

In the driver's seat...

- ▷ Check operation of the horn.
- Position seat for easy reach of foot pedals and controls. To reduce the possibility of injury from the airbag deployment, you should always sit back as far from the steering wheel as is practical, while still maintaining full vehicle control.
- ▶ Adjust the inside and outside rear view mirrors.
- ▶ Buckle your safety belts.
- ▶ Check operation of the foot and parking brake.
- Check all warning and indicator lights with ignition on and engine not running.
- ▶ Start engine and check all warning displays for warning symbols.
- ▶ Never leave an idling car unattended.
- Lock doors from inside, especially with children in the car to prevent inadvertent opening of doors from inside or outside. Drive with doors locked.

On the road...

- Never drive after you have consumed alcohol or drugs.
- ▷ Always have your safety belt fastened.
- Always drive defensively. Expect the unexpected.
- ▶ Use signals to indicate turns and lane changes.
- ► Turn on headlights at dusk or when the driving conditions warrant it.
- Always keep a safe distance from the vehicle in front of you, depending on traffic, road and weather conditions.
- Reduce speed at night and during inclement weather.
 Driving in wet weather requires caution and re-
- duced speeds, particularly on roads with standing water, as the handling characteristics of the vehicle may be impaired due to hydroplaning of the tires.
- Always observe speed limits and obey road signs and traffic laws.
- When tired, get well off the road, stop and take a rest. Turn the engine off. Do not sit in the vehicle with engine idling.
 Please observe the chapter "ENGINE EX-HAUST" on Page 4.

- When parked, always put the handbrake on and put the gearshift lever in neutral or the selector lever in position P.
 On hills also turn the front wheels toward the curb.
- When emergency repairs become necessary, move the vehicle well off the road. Turn on the emergency flasher and use other warning devices to alert other motorists. Do not park or operate the vehicle in areas where the hot exhaust system may come in contact with dry grass, brush, spilled fuel or other flammable material.
- ▶ Make it a habit to have the engine oil checked with every refueling.

Break in hints for the first 2,000 miles (3,000 kilometers)

The following tips will be helpful in obtaining optimum performance from your new Porsche.

Despite the most modern, high-precision manufacturing methods, the moving parts must still wear in with each other. This wearing-in occurs mainly in the first 2,000 miles (3,000 km).

Therefore:

- ▶ Preferably take longer trips.
- Avoid frequent cold starts with short-distance driving whenever possible.
- ▶ Avoid full throttle starts and abrupt stops.
- Do not exceed maximum engine speed of 4,200 rpm (revolutions per minute).
- ▶ Do not run a cold engine at high rpm either in Neutral or in gear.
- Do not let the engine labor, especially when driving uphill. Shift to the next lower gear in time (use the most favorable rpm range).
- Never lug the engine in high gear at low speeds. This rule applies at all times, not just during the break-in period.

 Do not participate in motor racing events, sports driving schools, etc. during the first 2,000 miles (3,000 kilometers).

There may be a slight stiffness in the steering or other controls during the break-in period which will gradually disappear.

Break in brake pads

New brake pads and discs have to be "broken in", and therefore only attain optimal friction when the car has covered several hundred miles or km. The slightly reduced braking ability must be compensated for by pressing the brake pedal harder. This also applies whenever the brake pads and brake discs are replaced.

New tires

New tires do not have maximum traction. They tend to be slippery.

Break in new tires by driving at moderate speeds during the first 60 to 120 miles (100 to 200 km). Longer braking distances must be anticipated.

Engine oil and fuel consumption

During the break-in period oil and fuel consumption may be higher than normal.


Please observe the chapter "ENGINE DATA" on Page 401.

As always, the rate of oil consumption depends on the quality and viscosity of oil, the speed at which the engine is operated, the climate and road conditions, as well as the amount of dilution and oxidation of the lubricant.

► Make a habit of checking engine oil with every refueling, add if necessary.


Overview Illustrations

Driver's cockpit 1
Steering wheel and instrument cluster 1
Centre console, front
Centre console, rear
Seat, rear1
Roof console1



Driver's cockpit

- 1.Power Lift Gate See Page 31.
- 2. Power Windows See Page 106.
- 3.Inner door Handle See Page 36.
- 4. Door mirror adjustment See Page 65.
- 5. Engine compartment lid release See Page 37.
- 6.Parking brake See Page 185.
- 7. Diagnostic socket
- 8. Parking brake release See Page 185.
- 9. Ignition lock/steering lock See Page 180.
- 10.Steering wheel adjustment See Page 70.
- 11.Seat adjustment See Page 41.
- 12.Instrument lighting knob See Page 125.
- 13.Light switch See Page 123.



Steering wheel and instrument cluster

- 1. Tiptronic rocker switches See Page 69.
- 2.Turn signals See Page 126.
- 3. Cruise control See Page 191.
- 4. Function keys See Page 71.
- 5.Horn See Page 69.
- 6. Windshield wipers See Page 132.
- 7. Tachometer See Page 140.
- 8. Clock See Page 143.
- 9. Cooling system temperature gauge See Page 141.
- 10.Multi-purpose display See Page 146.
- 11.Fuel gauge See Page 142.
- 12.Odometer See Page 142.



Centre console, front

- 1. Porsche Communication Management (PCM) See separate operating instructions.
- 2. Air conditioner See Page 77.
- 3. Ashtray/cigarette lighter See Page 259.
- 4. Cupholder See Page 257.
- 5. Reduction (Low Range), differential locks See Page 205.
- 6. Sport mode See Page 208.
- 7. Porsche Active Suspension Management (PASM) running-gear setup See Page 224.
- 8. Height adjustment, air suspension See Page 220.
- 9. Armrest, oddments trays See Page 255.
- 10.ParkAssistent warning indicator See Page 271.
- 11.Vents See Page 98.
- 12. Glove compartment See Page 254.



Centre console, rear

- 1 Cigarette lighter See Page 259.
- 2.Cupholder See Page 258.
- 3. Control panel for 4-zone air conditioning See Page 93.
- 4. Vents See Page 98.



Seat, rear

- 1. Safety belt height adjustment See Page 52.
- 2. Reading lights See Page 129.
- 3. Sunblind See Page 75.
- 4. Power windows See Page 115.
- 5. Ashtray See Page 259.
- 6. Inner door handle See Page 36.



Roof console

- 1.Sun visor See Page 74.
- 2. Automatic anti-dazzle interior mirror See Page 67.
- 3. Light switch, interior lightning See Page 128.
- 4. Glasses case See Page 253.
- 5. ParkAssistent See Page 269.
- 6. Control switch for sliding/lifting roof
 See Page 111.
 or
 Control switch for Panorama roof system
 See Page 116.
- 7. Garage door opener See Page 274.

Table of Contents

OTCHTICW IIIU3HI GHOH3	TO			Williams and Shaing Roots	103
Driver's cockpit	.11	Automatic Anti-Dazzle Mirror		Power windows	.106
Steering wheel and instrument cluster		Steering Wheel		Brief overview - sliding/lifting roof	
Centre console, front		Multi-Functional Steering Wheel		Sliding/Lifting Roof.	
Centre console, rear		Sun Visors		Brief overview –	
Seat, rear	15	Make-up mirror	/4	Panorama roof system	115
Roof console	16	Sun Blinds, Rear Side Windows	75	i anorama roor system	
11001 CONSOIC	.10			Lights, Turn Signals	
Opening and Locking	21	Air Conditioning, Parking Heater			100
Opening and Locking	21	and Heated Rear Window	76	and Windshield Wipers	122
Keys		Overview of Air Conditioning Cystems	77	Light Switch	123
Central Locking System	.24	Overview of Air-Conditioning Systems	//	Instrument Illumination	125
Brief overview – Opening and locking		Opening the Cover Flap of the	70	Automatic Headlight Beam Adjustment	
from outside	.25	Air-Conditioning Control Panel	/8	Turn signal/High Beam/	
Unlocking and locking from outside	.26	Brief Overview–	70	Headlight Flasher Stalk	.126
Opening and locking from inside		Manual Air-Conditioning	/9	Emergency flasher	126
Opening and closing		Manual Air-Conditioning	80	Interior Lighting	128
the engine compartment lid	.37	Brief Overview – Automatically Controlled	0.4	Coming Home Function (Auto Shut Off Delay	
- ·		2-Zone Air-Conditioning System	84	Door-Surrounding Lighting	
Seats, Mirrors and Steering Wheel	40	Automatically Controlled		Brief overview – Windshield wipers	
		2-Zone Air-Conditioning	85	Windshield Wiper/Washer Stalk	
Front seats		Brief Overview – Automatically Controlled		Williasticia Wiper/ Washer Stalk	1 32
Front seat with memory	.42	4-Zone Air-Conditioning System,			
Easy Entry Function		Front Control Panel	90		
Headrests		Brief Overview – Automatically Controlled			
Heated Seats – Front and Rear		4-Zone Air-Conditioning System,			
Safety Belts		Rear Control Panel	91		
Airbag Systems		Automatically Controlled			
Child Restraint Systems	.58	4-Zone Air-Conditioning			
Child Restraint Anchorages		Vents			
Brief overview – door mirrors	.64	Heated Rear Window	99		
Door Mirrors	.65	Parking Heater	100		

Multi-Purpose Display	
and Instruments	135
Instrument Panel USA Models	136
Instrument Panel Canada Models	
Oil Temperature Gage	
Tachometer	
Cooling System	
Fuel Gage	
Odometer	
Speedometer	
Clock	143
Voltmeter	144
Emission Control	
Operating the multi-purpose display	y
on the instrument panel	146
Displaying/resetting average spee	d149
Displaying range on remaining fuel	
Displaying tire pressure	149
Displaying compass	
Displaying navigation information	149
Opening the main menu	149
Operating the telephone	
via the multi-purpose display	150
Setting speed limit	
on the multi-purpose display	
Displaying warning messages	
Displaying status of level control	
Displaying status of locks/reduction	
Displaying average consumption	
Setting Tire Pressure Monitoring	
Switching off passenger compartm	ent monitoring
and inclination sensor	
on the multi-purpose display	165

Synchronous adjustment of door mirrors	166
Changing settings for opening	166
and locking the vehicle	
Setting lighting off delay	
Setting the clock	
Setting compass	
Changing language for displays	
Changing units for displays	
Resetting display to factory settings	
Overview of warning messages	
Ignition Lock/Steering Lock	
Starting and Stopping the Engine	102
Driving and Driving Safety	184
Parking Brake	
Brakes	
Brief overview – cruise control	
Cruise Control	191
Manual transmission, clutch	
Tiptronic S	
Selector Lever Positions	190
Driving Programs for On-Road and Off-Road Driving.	20.4
Power-Transmission	204
	210
and Running-Gear Control Systems	210
and Height Adjustment	220
Porsche Active	220
Suspension Management (PASM)	224
Porsche Dynamic	224
Chassis Control (PDCC)	225
Off-Road Driving	220

Luggage Compartment, Loadspace and Storage
Rear Seats
Loadspace 239
Cargo management system 240
Luggage Compartment Cover
Luggage safety net
Ski Bag
Roof Transport System
Car Audio Operation/Tips
Porsche Communication Management (PCM) 251
Fire Extinguisher
Storage
Cupholder257
Ashtray, front
Cigarette Lighter
Trailer Hitch261
Trailer Coupling
Loading Information
Parking268
Parking Aids
Swivelling down mirror glass as parking aid 273
Garage Door Opener
Alarm System and Theft Protection 276
Alarm System.
Passenger Compartment Monitoring, Inclination
O

Maintenance and Car Care	. 281
Exercise Extreme Caution when Working	
on your Vehicle	282
Engine Oil Level	
Engine Oil Recommendation	
Coolant Level	
Brake-Fluid Level	291
Power Steering	
Changing Air Cleaner	294
Changing Particle Filter	294
Automatic Transmission Fluid	294
Manual Transmission Oil	294
Wiper Blades	295
Emission Control System	298
Fuel Economy	
Operating Your Porsche in other Countries	
Fuel	301
Portable Fuel Containers	
Fuel Recommendations	
Fuel Evaporation Control	
Car Care Instructions	306
Minor Repairs	. 315
Exercise Extreme Caution when Working	
on your Vehicle	216
Tires/Wheels	
Jack	
Tool Kit	
Spacers	
Wheel Bolts	
Changing Wheels	
Flat Tire	

Lifting the Vehicle with a Lifting Platform	
or Garage lift	
Electrical System	
Battery	
Replacing the remote control battery	
Emergency Starting with Jumper Cables	
Replacing Bulbs	
Headlights	
Tail light	
License Plate Lights	
Headlight Adjustment	
Bulb Chart	
Towing	394
Tire Pressure and Technical Data	398
Vehicle Identification	399
Vehicle Identification Engine Data	399 401
Vehicle Identification Engine Data Transmission	399 401 402
Vehicle Identification	399 401 402 403
Vehicle Identification	399 401 402 403
Vehicle Identification Engine Data Transmission Tires, Rims, Tracks Tire Pressures, Cold Weights	399 401 402 403 406 408
Vehicle Identification Engine Data Transmission Tires, Rims, Tracks Tire Pressures, Cold Weights Ground Clearance	399 401 402 403 406 408
Vehicle Identification Engine Data Transmission Tires, Rims, Tracks Tire Pressures, Cold Weights Ground Clearance Capacities	399 401 402 403 406 408 409
Vehicle Identification Engine Data Transmission Tires, Rims, Tracks Tire Pressures, Cold Weights Ground Clearance Capacities Dimensions	399 401 402 403 406 408 409 411
Vehicle Identification Engine Data Transmission Tires, Rims, Tracks Tire Pressures, Cold Weights Ground Clearance Capacities	399 401 402 403 406 408 409 411

Opening and Locking

(eys	. 2
Central Locking System	. 2
Brief overview – Opening and locking	
rom outside	. 2
Jnlocking and locking from outside	. 2
Opening and locking from inside	. 3
Opening and closing the	
engine compartment lid	. 3

Never invite car theft!

An unlocked car with the key in the ignition lock invites car theft.

A steering wheel lock and a gong alarm are standard equipment in your Porsche. The gong alarm will sound if you open the driver's door while the key is still in the ignition lock. It is your reminder to pull the key out of the ignition lock and to lock the doors.



Any uncontrolled movement of the vehicle may result in property damage, serious personal injury or death.

Never leave your vehicle unattended with the key in the ignition lock, especially if children and/or pets are left unattended in the vehicle. They can operate power windows and other controls. If the engine is left running, they may accidentally engage the shift lever. Serious personal injury or death could result from loss of control of the vehicle.

- ▷ Always remove the ignition key.
- ▷ Always set the parking brake.
- ▶ Lock the doors with the key or with the remote control.



Risk of a serious accident.

The steering column will lock when you remove the key while you are driving or as the car is rolling to a stop. You will not be able to steer the car.

Serious personal injury or death could result from loss of control of the vehicle.

▶ Never remove the key from the steering lock while you are driving.

To protect your vehicle and your possessions from theft, you should always proceed as follows when leaving your vehicle:

- Close windows.
- ▷ Close sliding/lifting roof or Panorama Roof System.
- ▶ Remove ignition key (switch ignition off in vehicles that have Porsche Entry & Drive).
- ▷ Engage steering lock.
- ▶ Lock storage tray between the front seats and glove compartment.
- ▶ Remove valuables (e.g. car documents, radio control module, telephone, house keys) from the car.
- ▶ Lock doors.
- ▶ Lock the glove compartment.
- ▷ Close oddment trays.
- ▷ Cover luggage compartment with the luggage compartment cover.
- ▷ Close rear lid and rear window.



A - Car kev B - Release button for key bit

Keys

Two car keys with integrated remote control are supplied with your Porsche. The car keys are designed as folding keys.

These keys operate all the locks on your vehicle.

▶ Be careful with your car keys: do not part with them except under exceptional circumstances.

- ▶ Inform your insurance company of any loss or theft of car keys or if extra or replacement kevs have been made.
- ▶ Remove the ignition key, even if leaving the vehicle only briefly.

Folding out the key bit

▶ Press release button **B**. The key bit folds out.

Folding in the key bit

▶ Press release button **B** and fold in the key bit.

Note on operation

The air conditioner settings are stored on the respective key when switching off the ignition and locking the vehicle.

Replacement keys

Car keys can only be ordered through an authorized Porsche dealer. Sometimes, this may take a long time.

You should therefore always keep a spare key on your person. Keep it in a safe place, but under no circumstances in or on the vehicle.

The key codes of new keys have to be "reported" to the vehicle control module by your authorized Porsche dealer. All keys belonging to the vehicle must also be reported again.

Note

Third parties can continue to operate the mechanical locks using the lost key.



Panic button

In dangerous situations or when one's own safety is threatened, it is possible to draw attention to the situation by triggering an alarm.

To trigger an alarm

Press button. The horn sounds and the emergency flashers flash.

To stop the alarm

▶ Press button again. The horn becomes silent and the emergency flashers go out.

Central Locking System

USA: KR55WK45032

CAN 267 104 187 Canada:

This device complies with: Part 15 of the FCC Rules RSS-210 of Industry Canada.

Operation of this device is subject to the following two conditions:

- It may not cause harmful interference, and
- it must accept any interference received including interference that may cause undesired operation.

Note

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment.

Such modification could void the user's authority to operate the equipment.

/!\ Warning!

Any changes or modifications not expressly approved by Porsche could void the user's authority to operate this equipment.

Your vehicle is equipped with a central locking system. The following are unlocked or locked together:

- Doors
- Rear lid/rear window
- Filler flap

The central locking system is always activated when the vehicle is unlocked and locked.

On the multi-purpose display of the instrument panel, you can set different variants for locking and unlocking the doors and rear lid. You can open all doors irrespective of the setting made.

The vehicle cannot be locked if the driver's door is not completely closed.

If one of the following components is not completely closed when you try to lock the vehicle the door/lid is not locked:

- vehicle doors
- rear lid
- rear window
- engine compartment lid


The indication by the emergency flasher and by the acoustic signal will be provided after all doors and lids are closed.

Brief overview - Opening and locking from outside

The Porsche Entry & Drive option can be recognized by the buttons **A** in the door handles.

This brief overview does not replace the information provided in the chapter "Opening and locking from outside". In particular, warnings are not replaced by this brief overview.





Key

Porsche Entry & Drive

What do I want to do?	What do I have to do?	What happens?
Unlocking	Using the key: Press button on the key once .	The emergency flasher flashes once. The driver's door can be opened.
	Press button on the key twice.	All vehicle doors and the rear lid can be opened.
	With Porsche Entry & Drive: Grip door handle fully.	The doors and the rear lid can be opened.
Locking	Using the key: Press button on the key. With Porsche Entry & Drive: Press the button A in the handle.	The emergency flasher flashes twice and an acoustic signal will sound twice. The doors are locked.
Locking if persons/animals are remaining in vehicle (switching off passenger compartment monitoring of the alarm system)	Beachten Sie bitte das Kapitel "TEMPORARILY DEACTIVATING PASSENGER COMPARTMENT MONITORING SYSTEM AND INCLINATION SENSOR auf Seite 278.	и
Switching off alarm	Press button on the key.	



Unlocking and locking from outside

Depending on your vehicle equipment, you can either unlock and lock it with the vehicle key or without a key by means of Porsche Entry & Drive.

With the key

Use the buttons on the key to unlock and lock the vehicle.



With Porsche Entry & Drive

On vehicles with Porsche Entry & Drive, you can unlock, lock and start the vehicle without using the

You simply have carry the key with you, e.g. in your trouser pocket.

Do not expose the vehicle key to a high level of electromagnetic radiation. This could adversely affect Porsche Entry & Drive.

Readiness for operation

If the vehicle is not unlocked within 3 days the Porsche Entry & Drive readiness for operation is switched off.

- ▶ Pull door handle **once**, to reactivate the system.
- Pull door handle **again**, to open the door.

▶ Press button **o** on the key to reactivate the system.

Note on operation

The factory settings of the vehicle are described in this chapter.

You can change the settings and store them on the respective key on the multi-purpose display of the instrument panel.

For further information on the possible settings on the multi-purpose display:

▶ Please observe the chapter "CHANGING SET-TINGS FOR OPENING AND LOCKING THE VE-HICLE" on Page 166.



Unlocking and opening doors

Unlocking driver's door with the key

- 1. Briefly press button of on the key once. The emergency flasher flashes once. The driver's door is now unlocked.
- 2. Pull the door handle.

Unlocking all vehicle doors with the key

- 1. Briefly press button of on the key **twice**. The emergency flasher flashes once. The doors are now unlocked.
- 2. Pull the door handle.



Unlocking with Porsche Entry & Drive (keyless)

The vehicle can be unlocked if you are in the area of the driver's door with the key.

- ▷ Grip door handle fully. The doors are now unlocked.
- ▶ Pull the door handle.

Note on operation

The vehicle doors are locked automatically after 30 seconds if they are not opened.

If the passenger compartment monitoring system and inclination sensor have been switched off (restricted theft protection), this also remains the case after automatic relocking.

As a result, the doors can be opened from inside only by pulling the inner door handle twice.

Locking doors

Locking with the key

- Close the door.
- ▶ Briefly press button on the key once. The emergency flasher flashes twice. The doors cannot be opened, either from outside or from inside.



Locking with Porsche Entry & Drive (keyless)

You must carry the key with you.

- Close the door.
- ▷ Briefly press the Porsche Entry & Drive locking button **A** in the door handle. The emergency flasher flashes twice and an acoustic signal will sound twice. If the car key with remote control is out of range, the doors cannot be opened, either from outside or from inside.

Note on operation for locking the doors

The vehicle cannot be locked if the driver's door is not completely closed.

Automatic door locking and automatic door unlocking



In an emergency situation where you need to exit the car through an automatically locked door, remember the following procedure to open the door.

- ▶ Unlock the doors by pressing the central locking button **or**
- ▷ pull the inside door handle **twice** to open the door.

In the multi-purpose display of the instrument panel, you have the option of selecting diverse variants of automatic door locking (AUTO LOCK) and automatic door unlocking (AUTO UNLOCK).



Unlocking and opening rear lid (vehicles with spare wheel bracket)

On vehicles with spare wheel bracket, this must be swung to the side before opening the rear lid.

For further information on opening the spare wheel bracket:

▶ Please observe the chapter "OPENING SPARE WHEEL BRACKET" on Page 351.

! \ Danger!

Risk of poisoning. Exhaust gases can enter the passenger compartment when the rear lid is open.

- ▷ Always keep the rear lid closed when the engine is running.
- ▷ Always keep the rear lid closed while driving.

The vehicle doors remain locked after unlocking the rear lid.

The rear lid is locked automatically after 30 seconds if it is not opened.

Unlocking with the key

- ▶ Press button on the key.
- ▶ Press the release handle (arrow) on the rear lid and open the rear lid.

Unlocking with Porsche Entry & Drive (keyless)



Risk of being locked out of vehicles with Porsche Entry & Drive.

▷ Do not leave the key in the vehicle if the vehicle is locked and access is gained through the rear lid. The vehicle is automatically locked when the rear lid is closed.

If the key has been left in the vehicle, the hazard warning lights flash twice **and** a warning signal sounds. The rear lid can be opened again within approx. 30 seconds. After 30 seconds have elapsed, the vehicle can be unlocked again only with the second

The rear lid is unlocked if you are in the rear area of the vehicle with the key.

▶ Press the release handle (arrow) on the rear lid and open the rear lid.

Locking the rear lid



Danger of crushing. The rear lid is automatically pulled into the lock and locked.

- ▶ Make sure that your fingers are not under the rear lid.
- ▷ Keep foreign objects or limbs away from moving parts (latch striker) of the power closing mechanism.
- ▷ Do not leave children in the car unattended.
- 1. Pull down the rear lid by means of the closing handle (arrow), and press it gently into the
 - The rear lid is automatically pulled closed and locked. (only if rear lid is unlocked)
- 2. Lock the vehicle.

Powerliftgate (Rear Lid)



Risk of poisoning. Exhaust gases can enter the passenger compartment when the rear lid is open.

- ▷ Always keep the rear lid closed when the engine is running.
- ▷ Always keep the rear lid closed while driving.

Danger of injury and damage if the rear lid is automatically opened or closed in an uncontrolled way!

- ▶ Do not leave children in the car unattended.
- ▷ Open or close the rear lid only when the vehicle is stationary.
- ▶ Never drive with the rear window or rear lid
 - Exhaust gases can enter the passenger compartment.
- ▷ Open or close the rear lid only when there are no persons, animals or objects within its movement range.
- Always observe the opening and closing operation so that movement can be stopped at any time in the event of danger.

- ▶ Make sure that there is sufficient clearance behind or above the vehicle (e.g. roof transport systems, garage ceiling).
- ▶ Remove rear rack systems before opening the rear lid automatically.



Risk of being locked out of vehicles with Porsche Entry & Drive.

▷ Do not leave the key in the vehicle if the vehicle is locked and access is gained through the rear window. The vehicle is automatically locked when the rear lid is closed.

If the key has been left in the vehicle, the hazard warning lights flash twice and a warning signal sounds. The rear lid can be opened again within approx. 30 seconds. After 30 seconds have elapsed, the vehicle can be unlocked again only with the second key.

Acoustic indication during opening/closing of the rear lid

Opening and closing of the rear lid are indicated by three warning tones.

You can have the warning tones activated/deactivated at your authorized Porsche dealer.



Opening the rear lid automatically

When the vehicle is operated with a trailer, the rear lid can only be opened with the release button on the rear lid.

There are **three** ways of opening the rear lid:

Option 1

Make sure the vehicle is unlocked if your vehicle is not equipped with Porsche Entry & Drive. Then briefly press the release handle on the rear lid.

The vehicle need not be unlocked on vehicles with Porsche Entry & Drive. You simply have carry the vehicle key with you, e.g. in your trouser pocket.





Option 2

▶ Press the button on the key for approx. 1 second.

If the vehicle is locked, the vehicle doors remain locked when the rear lid is opened.

Option 3

▶ Pull and hold the button in the driver's door with the ignition switched on until the rear lid has opened fully.

Opening is interrupted if the button is released prematurely.

Automatically closing the rear lid

Make sure that the load is not in the area of the rear lid when the lid is closed, otherwise the closing operation will be interrupted after contact with the load, and the rear lid will open again by a few inches.

▷ Briefly press the button in the rear lid trim panel.

Interrupting the opening or closing operation in the event of danger

The opening or closing operation is interrupted immediately if one of the following buttons is pressed:

▶ Press the button on the key

Release the button in the driver's door

Briefly press the button in the rear lid trim panel

Briefly press the release button on the rear lid.

Automatic operation can be continued again at any time. To do this, press the corresponding button.

Detection of obstacles during opening

The rear lid will stop moving if opening is blocked by an obstacle. A warning signal then sounds. When the obstacle has been removed, the rear lid can be opened by pressing

the button on the key

the button in the driver's door

the release button on the rear lid.

Detection of obstacles during closing

The closing operation is interrupted if closing of the rear lid is blocked by an obstacle.

A warning signal sounds and the rear lid opens again by a few inches.

When the obstacle has been removed, the rear lid can be closed by pressing one of the corresponding buttons.

Adjusting the opening height of the rear lid

The opening height of the rear lid can be individually adjusted so that the rear lid does not collide with the garage ceiling, for example.

On vehicles with level control, the vehicle height changes depending on the setting of the level control system. For this reason, always adjust the opening height with the vehicle at the highest level setting so that the rear lid cannot accidentally collide with the garage ceiling, for example.

- 1. Stand behind the vehicle and open the rear lid.
- 2. Press the button on the key to stop the automatic opening operation at around 2/3 of the opening height.
- 3. Now move the rear lid up by hand until the desired opening height is reached. Make sure that there is a sufficient minimum clearance from any obstacle.

4. Press and hold the button in the rear lid trim panel for approx. 3 seconds.

An acknowledgement signal sounds, and the direction indicators light up once.

The opening height of the rear lid has now been programmed.

The rear lid can now be closed by briefly pressing the button.

This setting cannot be deleted. If a different setting is required, repeat steps 1 to 4.

Malfunctions of the rear lid drive

The automatic function is not active if the battery voltage is too low.

If a button is pressed, the rear lid lock is unlocked and a warning signal sounds for 3 seconds. The rear lid can now be opened by hand.

▷ Charge the vehicle battery.

Emergency operation of the rear lid

A warning signal sounds for approx. 3 seconds if the automatic opening or closing operation is interrupted by a fault.

▷ Open or close the rear lid by hand.



Unlocking and opening rear window

On vehicles with spare wheel bracket, this must be swung to the side before opening the rear window.

For further information on opening the spare wheel bracket:

▶ Please observe the chapter "OPENING SPARE WHEEL BRACKET" on Page 351.

The vehicle doors remain locked after unlocking the rear lid.

The rear window is locked automatically after 30 seconds if it is not opened.

Unlocking with the key (only on vehicles without Powerliftgate)

▶ Press button on the key for approx. 2 seconds. The rear window pops open.

OR:

- ▶ Press button on the key.
- ▶ Press the release button **A** and open the window.

Unlocking with Porsche Entry & Drive (kevless)



Risk of being locked out of vehicles with Porsche Entry & Drive.

▷ Do not leave the key in the vehicle if the vehicle is locked and access is gained through the rear window. The vehicle is automatically locked when the rear window is closed.

If the key has been left in the vehicle, the hazard warning lights flash twice and a warning signal sounds. The rear window can be opened again within approx. 30 seconds. After 30 seconds have elapsed, the vehicle can be unlocked again only with the second key.

Risk of poisoning. Exhaust gases can enter the passenger compartment when the rear window is open.

- ▷ Always keep the rear lid and rear window closed when the engine is running.
- ▷ Always keep the rear lid and rear window closed while driving.

The rear window is unlocked if you are in the rear area of the vehicle with the key.

▶ Press the release button **A** and open the window.

Closing the rear window

Close the rear window and press it into the lock until it can be felt to engage.

Opening and locking from inside

The factory settings of the vehicle are described in this chapter.

You can change the settings and store them on the respective key on the multi-purpose display of the instrument panel.

For further information on the possible settings (e.g.. Auto Lock and Auto Unlock) on the multipurpose display:

▶ Please observe the chapter "CHANGING SET-TINGS FOR OPENING AND LOCKING THE VE-HICLE" on Page 166.



Locking doors

Button in the armrest

▶ Press the right half of the button in the door panel.

All vehicle doors will be locked.

The doors can be opened by pulling the inner door handle twice.

Automatic with Auto Lock

The vehicle is locked automatically when a speed of 6 km/h (4 mph) is exceeded.

Unlocking doors

Button in the armrest

▶ Press the left half of the button in the door panel.

If pressed on the front doors, all doors will be

If pressed on the rear doors, **only** the relevant door will be unlocked.

Automatic with Auto Unlock

The vehicle is automatically unlocked when the ignition key is withdrawn or the ignition is switched

Note on operation

If the vehicle was locked by remote control or with the key, it cannot be unlocked with the central locking button.



Opening doors

Opening unlocked doors

▶ Pull inner door handle once.

Opening locked doors

(Not if the vehicle was locked by pressing the button once. The doors cannot be opened in this case.)

▶ Pull inner door handle twice.



Securing rear doors

You can secure the rear doors to prevent unintentional opening when driving.

Switching child lock on and off

The child locks are fitted in the lock area of the rear doors.

The doors cannot be opened from inside when the child locks are engaged.

- ▶ To engage: Turn child lock to position A.
- ▶ To disengage: Turn child lock to position B.





Switching child protection on/off

The power windows, central locking buttons on the rear doors and the rear control panel for the air conditioning can be disabled by means of the safety button in the armrest of the driver's door.

- ▶ Press the safety button to switch child protection on and off.
 - The symbol in the safety button lights up if child protection is active.



Opening and closing the engine compartment lid

Opening

▶ Pull the release lever (arrow).

The engine compartment lid is now unlocked.



- ▶ Unlatch safety catch A .
- ▷ Open the lid completely.

Closing

- Lower lid and let it fall into the lock. If necessary, push the lid closed with the palm of your hand in the area of the lock.
- ▷ Check that the lid has correctly engaged in the

When the vehicle is in motion, a message will be displayed on the multi-purpose display of the instrument panel if the lid is not closed properly.

Malfunctions when opening and closing

Only one door is unlocked

The setting for locking and unlocking the doors and rear lid has been changed on the multipurpose display of the instrument panel. You can open all doors irrespective of the setting made.

▶ Press button of on the key twice within 2 seconds.

The vehicle cannot be unlocked

The remote control of the key may

- not function correctly due to radio waves (also radio contact between remote control and vehicle in the case of Porsche Entry & Drive),
- fail due to a fault.
- fail due to an exhausted battery.
- ▶ Unlock the vehicle with the unfolded key in the key lock.
- door lock, only the driver's door can be opened. In order to prevent the alarm system from being triggered, you must switch the ignition on within 15 seconds of opening the door.


▷ If you unlock the vehicle with the key at the

The vehicle cannot be locked

This is recognizable by the fact that the emergency flasher does not flash and there is no locking noise.

The remote control of the key may

- not function correctly due to radio waves (also radio contact between remote control and vehicle in the case of Porsche Entry & Drive),
- fail due to a fault,
- fail due to an exhausted battery.
- ▶ Lock the vehicle with the unfolded key in the kev lock.



Not all vehicle doors are locked

The central locking system has failed. The doors must be locked with the emergency locking device.

- 1. Open the passenger's door.
- 2. Remove cover A.



- 3. Press red slide **B** with the key bit in the direction of the arrow.
- 4. Fit cover **A** again.
- 5. Repeat procedure at the rear doors.
- 6. Close all doors.



7. Lock the driver's door with the key in the door lock.

Seats, Mirrors and Steering Wheel

Front seats	41
Front seat with memory	42
Easy Entry Function	
Headrests	
Heated Seats – Front and Rear	47
Safety Belts	
Airbag Systems	53
Child Restraint Systems	
Child Restraint Anchorages	63
Brief overview – door mirrors	64
Door Mirrors	65
Interior Mirror	67
Automatic Anti-Dazzle Mirror	67
Steering Wheel	69
Multi-Functional Steering Wheel	71
Sun Visors	74
Make-up mirror	74
Sun Blinds Rear Side Windows	75

Front seats



The seat may move unexpectedly if you attempt to adjust while driving. This could cause sudden loss of control, resulting in serious personal injury or death.

▷ Do not adjust seats while the vehicle is in motion. The backrest locks must be engaged at all times while the vehicle is in motion.

Safety belts only offer protection when the backrest is upright and the belts are properly positioned on the body. Improperly positioned safety belts can cause serious personal injury or death in an accident.

- ▷ Do not operate the car with the driver or passenger backrests excessively reclined.
- ▶ Porsche recommends the use of L.A.T.C.H. (Lower Anchorage and Tether for Children) equipped Porsche child seat.

Seat position

A correct sitting position is important for safe and fatigue-free driving. We recommend the following procedure for adjusting the driver's seat to suit individual requirements:

- 1. Adjust the seat height to give yourself enough headroom and a good overview of the vehicle.
- 2. Adjust the seat until, with the accelerator pedal fully depressed, your leg is straight but your entire foot still rests on the accelerator pedal.
- 3. Grip the top half of the steering wheel. Set the backrest angle and steering wheel position so that your arms are almost outstretched. However, your shoulders must still rest on the backrest.
- 4. If necessary, correct the seat fore-and-aft adjustment.
- 5. Adjust the height of the headrest so that the upper edge is at eye level or higher.



Adjusting the seat

- A Front seat height adjustment.
- B Rear seat height adjustment.



- C Fore and aft adjustment.
- D Backrest angle adjustment.
- E Lumbar support adjustment. To permit a relaxed sitting posture, the backrest curvature is infinitely adjustable in vertical and horizontal directions for individual pelvis and spinal column support.
- ▶ Press the switch in the direction indicated by the **arrows** until the desired setting is reached.



Front seat with memory

Personal seat, door mirror, steering wheel and safety belt height adjustments can be stored and recalled on the person buttons **A** and car keys.

№ Warning!

Risk of crushing due to uncontrolled recall of settings.

- ▷ Cancel automatic adjustment by pressing any of the seat adjustment buttons.
- ▷ Do not leave children in the car unattended.

Memory options

- Seat adjustment
- Door mirror adjustment

Comfort memory options

- Seat adjustment
- Door mirror adjustment
- Steering wheel and safety belt height adjust-

Recalling the settings using the vehicle key or in vehicles that have **Porsche Entry & Drive**

▷ Open the driver's door. The stored settings of the driver's seat are recalled automatically.

Cancelling setting

Automatic settings can be cancelled immediately by pressing any driver's seat setting button.

Recalling the settings with person buttons 1 - 3 (driver's and passenger's seat)

- 1. Unlock vehicle and open the driver's door.
- 2. Press the relevant person button until the stored positions have been reached

Briefly touch the person button if the ignition key is inserted or if the ignition is switched on (in vehicles that have Porsche Entry & Drive). The stored positions for each seat are recalled automatically.

Cancelling setting

Automatic settings can be cancelled immediately by pressing any seat adjustment button.

Storing driver's seat settings

Storing settings on a person button and a car key

- 1. Apply the parking brake.
- 2. Switch ignition on.

person button.

- 3. Make the required adjustments to the seat. mirror, steering wheel and safety belt.
- 4. Briefly press the **SET** memory button and, within 10 seconds, hold down one of the person buttons (1. 2 or 3) until an acknowledge tone is obtained. The settings are now stored on the desired
- 5. Withdraw car key or switch ignition off in vehicles that have Porsche Entry & Drive.
- 6. Press the **SET** memory button within 10 seconds and keep the button depressed until an acknowledge tone is obtained. The settings are now assigned to the car key.



- A Control switch for door mirror adjustment
- C Passenger mirror setting

Storing passenger mirror setting as a parking aid

If the passenger's mirror is supposed to swivel downwards when reversing, this can also be stored in the driver's seat setting.

- 1. Apply the parking brake.
- 2. Switch ignition on.
- 3. Press the relevant person button.
- 4. Engage reverse gear.

- Set the control switch **A** for the mirror setting to the passenger's side **C**.
 The passenger's mirror swivels downwards.
- 6. Adjust the passenger's mirror to the required setting.
- 7. Briefly press the **SET** memory button and, within 10 seconds, hold down the person button on which the setting is to be stored until an acknowledge tone is obtained.

Storing passenger seat settings

- 1. Apply the parking brake.
- 2. Switch ignition on.

called.

- 3. Adjust seat position and belt height.
- Briefly press the SET memory button and, within 10 seconds, hold down one of the person buttons (1, 2 or 3) until an acknowledge tone is obtained.

Automatic storage – driver's seat

If settings were changed after the driver's door was opened, these new settings are temporarily stored when the vehicle is locked.

This storage is deleted if the vehicle is unlocked with a programed key and the driver's door is opened. Then the settings of the key used is re-

44 Seats, Mirrors and Steering Wheel



Easy Entry Function

The Easy Entry function makes it easier for you to get in and out of the car.

/ Warning!

Risk of crushing if persons are behind the driver's seat when settings are recalled.

Risk of damage if the rear seat bench is folded forward when settings are recalled.

▷ Switch off the Easy Entry function if there are persons behind the driver's seat or if the rear seat bench is folded forward.

Switching Easy Entry function on and off

- ▷ Schalter A drücken.
- ▶ Press switch A.

Entering the vehicle

When the driver's door is opened, the driver's seat moves to the rear.


Once the driver's door is closed and the ignition key is inserted or, in the case of vehicles that have Porsche Entry & Drive, the ignition is switched on, the seat and steering wheel move into the stored position.

Exiting the vehicle

The steering wheel moves into the frontmost, top position.

- After the ignition key is removed or
- After the ignition is switched off and the driver's door is opened on vehicles equipped with Porsche Entry & Drive or
- When the steering column is locked.

When the driver's door is opened, the driver's seat moves to the rear.



Example: driver's seat

Headrests

Removing

Front seats

▶ Press button **A** and, at the same time, completely remove headrest.

Rear seats

- ▶ Press button **B** and push the headrest all the way down.
- ▶ Press button **A** and, at the same time, pull the headrest completely out.

Installing

Note

The middle headrest of the rear seat bench must only be fitted to the middle seat of the rear seat backrest.

- 1. Insert the headrests into the guides.
- 2. Press button **B** and, at the same time, push the headrest downwards until the desired position is reached.

Install the middle headrest of the rear seat bench only on the middle seat and push it down fully.

Adjusting

The heights of the headrests for the front seats and the outer headrests for the rear seats can be adjusted.



Improperly positioned headrests can cause serious personal injury or death in an accident.

- ▷ Adjust the headrest so that the upper edge of the headrest is at last at eye level or higher.
- ▷ Do not drive the vehicle without the headrest in place and properly adjusted.

Raising

Push headrest upwards until the desired position is reached. Additionally press button **B** on the rear seat headrests.

Lowering

▶ Press button **B** and, at the same time, push the headrest downwards until the desired position is reached.





- **A** Front seat, left **B** Front seat, right
- **Heated Seats Front and Rear**

The seat heating is ready for operation when the ignition is on. The heating power can be infinitely adjusted with the thumb wheel.

C - Rear seat, left **D** - Rear seat, right

Switching on

▶ Turn thumb wheel until the desired position is reached.

Switching off

► Turn thumb wheel to **0**.



- A Switches seat heating on
 B Switches seat heating off
 C Temperature control for left seat
 D Temperature control for right seat

Rear seat heating in vehicles with an four-zone air conditioning system

Switching on

▶ Press button A.

After the seat heating is switched on, the air conditioning display switches to seat heating mode for approx. 10 seconds.

Controlling the temperature

▶ Move button **C** or button **D** upwards or downwards until the desired position is reached.

Switching off

▶ Press button **B**.

Safety Belts



Always make sure your and your passengers' safety belts are properly fastened while the vehicle is in motion.

Failure to follow safety belt warnings may result in serious personal injury or death.

- ▶ For your and your passengers' protection, use safety belts at all times while the vehicle is in motion.
- ▶ Use appropriate child restraint systems for all small children.

Proper wearing of safety belts

- ▶ Safety belts must be positioned on the body as to restrain the upper body and lap from sliding forward. Improperly positioned safety belts can cause serious personal injury in case of an accident.
- ▶ The shoulder belt should always rest on your upper body. The shoulder belt should never be worn behind your back or under your arm.
- ▶ For maximum effectiveness, the lap belt should be worn low across the hips.
- Pregnant women should position the belt as low as possible across the pelvis. Make sure it is not pressing against the abdomen.
- ▷ Belts should not be worn twisted.

- ▶ Do not wear belts over rigid or breakable objects in or on your clothing, such as eye glasses, pens, keys, etc. as these may cause injury.
- ▷ Several layers of heavy clothing may interfere with proper positioning of belts.
- ▶ Belts must not rub against sharp objects or damage may occur to the belt.
- ▶ Two occupants should never share the same belt at the same time.

Care and maintenance

- ▶ Keep belt buckles free of any obstruction that may prevent a secure locking.
- ▶ Belts that have been subjected to excessive stretch forces in an accident must be inspected or replaced to ensure their continued effectiveness in restraining you. The same applies to belt tensioner systems which have been triggered. In addition, the an-

chor points of the belts should be checked.

- ▷ If safety belts do not work properly, see your authorized Porsche dealer immediately.
- ▶ If the belts show damage to webbing, bindings, buckles or retractors, they should be replaced to ensure safe operation.
- ▷ Do not modify or disassemble the safety belts in your vehicle.

- ▶ The belts must be kept clean or the retractors may not work properly. Please observe the chapter "CAR CARE IN-STRUCTIONS" on Page 306.
- ▶ Never bleach or dye safety belts.
- ▷ Do not allow safety belts to retract until they are completely dry after cleaning or this may cause damage to the belt.

Belt tensioner

Depending on the force of a collision, fastened seat belts are automatically tightened in an accident.

The belt tensioners are triggered in:

- Front and rear impacts
- Side impacts (only belt tensioners of the front seats are triggered)
- In cases of vehicle rollover

Maintenance Notes

The belt tensioner system can be triggered only once; the system must be replaced afterwards.

If there is a fault in the belt tensioner system, the airbag warning light lights up.

Work may be performed on the belt tensioner system only by an authorized Porsche dealer. Smoke is released when the belt tensioners are triggered.

This does not indicate a fire in the vehicle.



Safety Belt Warning System

An audio-visual warning system is interconnected with the driver's safety belt.

Every time the ignition is turned on, the gong will sound for about 6 seconds to remind driver and passenger to buckle up.

In addition, the gong will sound for approx. 90 seconds if vehicle speed exceeds 15 mph/ 24 km/h.

The safety belt warning lights in the instrument panel and multi-purpose display will go off as soon as the driver has buckled up.



Fastening the safety belt

- ▶ Assume a comfortable sitting position. Adjust the backrest of the front seat so that the belt always rests on your upper body and runs across the middle of your shoulder.
- ▶ Grasp the belt tongue and pull the belt in a slow, continuous motion across your chest and lap.

Note on operation

The belt can be blocked if the vehicle is standing at an angle or if the belt is pulled out using a jerking movement.


- ▶ The belt cannot be pulled out while accelerating and slowing down, when cornering and when driving uphill.
- ▷ Insert the belt tongue into the appropriate buckle on the inboard side of the seat, until it locks securely with an audible click.
- ▶ Make sure that belts are not trapped or twisted, and that they are not rubbing on sharp edges.
- ▶ The horizontal section of the belt should always fit snugly across the pelvis. Therefore, after fastening the belt, always pull the diagonal part of the belt upwards.
 - Pregnant women should position the belt as low as possible across the pelvis, and ensure that it is not pressing against the abdomen.
- Pull on the diagonal section of the belt now and again during the journey to ensure that the horizontal section remains tight.



▶ Make sure that the belts and buckles fit correctly on the rear seat bench.

Releasing the safety belt

- ▶ Hold the belt tongue.
- ▶ Press the red button (arrow).
- ▷ Guide belt tongue to the reel.



Safety belt height adjustment

The heights of the belt deflectors for the driver's seat, passenger's seat and the outer rear seats can be adjusted.

Adjust the height of the safety belt so that it runs across the middle of the shoulder, not against the neck.

Adjusting belt height manually

- ▷ Upward push belt deflector up.
- ▷ Downward press button A and move belt deflector.



Adjusting belt height electrically

▷ Operate rocker switch **B** in the desired direction until the optimal belt adjustment is reached.

On vehicles with comfort memory, seat belt height adjustment can be stored on the person buttons and vehicle keys and recalled with these.

▷ Please observe the chapter "FRONT SEAT WITH MEMORY" on Page 42.

Airbag Systems

The airbags in combination with the safety belts make up a safety system which offers the driver and the passenger the greatest known protection from injuries in case of accident.

Your vehicle is equipped with weight sensing for the passenger's seat in accordance with U.S. Federal/Canadian Motor Vehicle Safety Standard 208.

Even if your vehicle is equipped with airbags, the safety belts must be worn at all times. because the front airbag system is only actuated by frontal collisions with an impact of sufficient severity.

Below the deployment threshold of the airbag system, and during types of collisions which do not cause the actuation of the system, the safety belts provide the primary protection to the occupants when correctly worn. Therefore, all persons within the vehicle must wear safety belts at all times (in many states, state law requires the use of safety belts).

▶ Please observe the chapter "SAFETY BELTS" on Page 49.

The **front airbags** are located under the padded steering wheel panel on the driver's side and, on the passenger's side, in the dashboard.

The **side airbags** for the front seats are installed on the side in the seat backrests.

The **head airbags** are installed above the doors in the roof area.

!\ Danger!

To provide optimal occupant protection, airbags must inflate at very high speed. If you are not wearing your safety belt or are too close to the airbag when it is deployed, inflating airbags can result in serious personal iniury or death.

Improper handling of weight sensing can unintentionally impair switching the passenger's airbag off and on.

- ▶ Make sure there are no people, animals or objects between the driver or passenger and the area into which the airbag inflates.
- ▷ Sit back as far from the dashboard or steering wheel as is practical, while still maintaining full vehicle control.
- ▷ Always hold the steering wheel by the outer rim. Never rest your hands on the airbag panel.
- ▶ Always fasten seat belts because triggering of the airbag system depends on the force and angle of impact.
- ▷ Do not transport heavy objects on or in front of the passenger seat. These could impair the function of the airbag, the seat belts, and weight sensing.
- ▷ Do not hang objects (e.g., jackets, coats, coat hangers) over the backrest.

- ▶ Always keep the lid of the door storage compartment closed. Objects must not protrude out of the door storage compartment.
- ▶ No changes must be made to the wiring or components of the airbag system.
- ▶ Do not add any additional coverings or stickers to the steering wheel or in the area of the passenger airbag, side airbags and head airbags. Doing so may adversely affect the functioning of the airbag system or cause harm to the occupants if the airbag system should deploy.
- ▷ Do not modify the seat coverings. Do not attach additional cushions, protective coverings, or pillows to the passenger's seat. Do not affix things to the passenger's seat or cover it with other materials. Do not cover the back of the backrest. Do not make changes to the passenger's seat and to the seat base fra-
- ▷ Do not undertake any wiring for electrical accessory equipment in the vicinity of the airbag wiring harnesses. Doing so may disable the airbag system or cause inadvertent inflation.
- ▶ If the warning light comes on, the airbag system should be repaired immediately by your authorized Porsche dealer.
- ▷ Always keep feet in the footwell while driving. Do not put feet on the dashboard or the seat area. Do not lean against the inside of the door or outside the window while the vehicle is moving.

- ▶ Using accessories not approved by Porsche can cause the weight sensing to be impaired.
- ▷ Do not squeeze objects, such as the fire extinguisher, or first aid kit under the seat.
- Only have seats removed and installed by an authorized Porsche dealer so that weight sensing components will not be damaged.
- ▷ Give your passenger all of the information in this chapter.

Note

Airbag components (e.g. steering wheel, seats) may be disassembled only by an authorized Porsche dealer.

▶ When disposing of a used airbag unit, our safety instructions must be followed. These instructions can be obtained at any authorized Porsche dealer.

Function of the airbag system

Airbags are a supplemental safety system. Your primary protection comes from your safety belts.

The front airbags are triggered during a frontal collision of sufficient force and direction. In the event of a side impact of corresponding force, the side airbag on the impact side is triggered.

The inflation process generates the amount of gas required to fill the airbags at the necessary pressure in fractions of a second.

Airbags help to protect the head and upper body. while simultaneously damping the motion of the driver and passenger in the impact direction in the event of a frontal impact or side impact.

In order to help provide protection in severe collisions which can cause death and serious injury, airbags must inflate extremely rapidly. Such high speed inflation has a negative but unavoidable side effect, which is that it can and does cause injuries, including facial and arm abrasions, bruising and broken bones. You can help minimize such injuries by always wearing your safety belts.

There are many types of accidents in which airbags are not expected to deploy. These include accidents where the airbags would provide no benefit, such as a rear impact against your vehicle. Other accidents where the airbags are designed not to deploy are those where the risk of injury from the airbag deployment could exceed any protective benefits, such as in low speed accidents or

higher speed accidents where the vehicle decelerates over a longer time. Since airbag deployment does not occur in all accidents, this further emphasizes the need for you and your passengers to always wear safety belts.

Your vehicle is equipped with a crash sensing and diagnostic module. This module will record the use of the seat belt restraint system by the driver and front passenger when the airbags and/or belt tentioner are triggered.

Precondition for activating the restraint systems:

▶ Ignition is switched on.

Advanced Airbag

Your vehicle is equipped with weight sensing for the passenger's seat in accordance with U.S. Federal/Canadian Motor Vehicle Safety Standard 208.

Depending on the weight acting on the passenger's seat, the passenger's airbag will automatically be switched on and off.

Depending on the angle and force of impact, the passenger's airbag which is switched-on will be triggered during a collision.

Precondition for switching the passenger's airbag on and off, depending on weight:

▶ Ignition is switched on.

Seat adjustment for the passenger's seat

If the seat is in an extreme position (e.g., the backrest is in contact with the rear seat bench), the backrest can warp. Warping of the backrest can lead to malfunctions.

- ▷ Correct the seat adjustment. The seat is not jammed and is self-supporting. The backrest is in the upright position.
- ▶ Do not transport a load and objects in the rear footwell or under the passenger's seat. If the load or objects are under the seat, they can cause malfunctions.

If the weight on the passenger's seat is reduced significantly, e.g., by supporting weight on the armrest, the passenger's airbag can be switched off.

▷ Select an upright seat position, and do not support weight on the armrests or lean out of the window. Always keep feet in the footwell while driving. Do not put feet on the dashboard or the seat area. Do not lean against the inside of the door or outside the window while the vehicle is moving.

If the passenger's seat is warped significantly, a message is displayed in the multi-purpose display in the instrument panel:

- Correct the seat adjustment.
- ▶ Please observe the chapter "OVERVIEW OF WARNING MESSAGES" on Page 172.

Vehicle modifications to accommodate persons with disabilities

Because modifications to your vehicle could compromise your advanced airbag system, please call 1-800-PORSCHE prior to having your vehicle modified.

Automatic deactivation of the passenger airbags



The use of a child restraint system in the front passenger seat can result in serious personal injury or death to the child from an airbag deployment.

To reduce risk of injury from an inflating airbag in an accident. Porsche strongly recommends:

▶ Under all normal circumstances, the child seat must be placed in the rear. Do not use a child restraint system in the front passenger seat.

Before transporting a child on the passenger seat:

- ▶ Please observe the chapter "CHILD RES-TRAINT SYSTEMS" on Page 58.
- When an up to one-year old child is seated in the child restraint system, the front airbag is automatically deactivated on the passenger si-
- When an adult is seated in the front seat the front airbag remains active on the passenger's side.



A - PASSENGER AIRBAG OFF indicator lamp

Note on operation

Although not desired, it can occur in the case of heavier children that the passenger airbags remain active or, in the case of very light adults or young persons, that the passenger airbag is deactivated.

The condition of the passenger airbag system is shown by the indicator lamp A in the central console.

▶ If in doubt, fasten the child restraint system on the rear bench or transport the passenger on the rear bench.

Note

▶ After switching on the ignition, the PASSEN-GER AIRBAG OFF warning light lights up for a few seconds as a check.

PASSENGER AIRBAG OFF indicator lamp lights up

The passenger's airbag is switched off.

PASSENGER AIRBAG OFF indicator lamp does not light up

- The passenger's airbag is active and ready for
- If the passenger's seat is not occupied, the PASSENGER AIRBAG OFF indicator lamp will also not light up, even though the passenger's airbag is switched off.

/!\ Danger!

Risk of serious personal injury or death due to the passenger airbag triggering unintentionally.

When the ignition is on and the up to oneyear old child is seated in the child restraint system on the passenger seat the indicator lamp "PASSENGER AIRBAG OFF" must be on.

If the "PASSENGER AIRBAG OFF" indicator lamp does not light up, it could indicate a fault in the system. In this case:

- ▶ Fasten the child restraint system on the rear bench immediately.
- rized Porsche dealer.



Warning light

Faults are indicated by a warning light on the tachometer.

- ▶ In the following cases you should immediately consult an authorized Porsche dealer in order to assure the airbag system is functioning properly:
- If the warning light does not light up when the ignition is switched on or
- If the warning light does not go out once the engine is running or
- If the warning light appears while driving.

Airbag maintenance

In order to ensure long-term functioning, the airbag system must be inspected by an authorized Porsche dealer at the intervals recommended in vour Maintenance Booklet.

Important information

If you sell your Porsche, notify the purchaser that the vehicle is equipped with airbags, and refer them to the chapter, "Airbag Systems", in the owner's manual (safety and disposal rules).

Further information on the airbag system can be found on stickers attached to the sun visors, as well as on all airbag components.

For special recommendations on the use of child restraints:

▶ Please observe the chapter "CHILD RES-TRAINT SYSTEMS" on Page 58.

Child Restraint Systems

Porsche recommends that all infants and children be restrained in child restraint systems at all times while the vehicle is in motion in accordance with applicable laws.

Use only child restraint systems with the LATCHsystem recommended by Porsche. These systems have been tested and adjusted to the interior of your Porsche and the appropriate child age groups. Other systems have not been tested and could entail an increased risk of injury.

You can obtain child seats that are LATCH compatible at your authorized Porsche dealer.

▷ Always observe the separate installation instructions for your child seat.

The use of infant or child restraints is required by law in all 50 US states and the Canadian provinces. The child restraint system should be one that complies with U.S. Federal/Canadian Motor Vehicle Safety Standards and should be secured by a lap belt or lap belt portion of a lap-shoulder belt or for child seats equipped with the LATCH sytem (Lower Anchorage and Tether for Children, also known as ISOFIX) to the LATCH anchorages. A statement by the seat manufacturer of compliance with this standard can be found on the instruction label on the restraint and in the instruction manual provided with the restraint.

¶ \ Danger!

Risk of serious personal injury or death to the child.

- ▶ Follow all child restraint instructions and warnings in this manual.
- When using an infant or child restraint system, be sure to follow all manufacturer's instructions on installation and use.
- Infants and small children should neither be held on the lap, nor should they share a safety belt with another occupant while the vehicle is in motion.
- Children too big for child restraint systems should use regular safety belts. A shoulder belt can be used providing it does not cross the face or the neck of the child.
- Choose a child restraint system according to the age and size of the child.
- Child restraint systems that are damaged or have been heavily stressed in an accident must be replaced immediately.
- Do not affix objects to child restraint systems or cover them with other materials.
- ▶ For maximum safety and protection, do not use a child restraint system in the front passenger seat.

Direction of installation for child restraint systems

Under all normal circumstances, the child seat must be placed in the rear.

▶ Do not use a child restraint system in the front passenger seat.

Children up to an age of 9 months

Children of this age must be transported in a restraint system which is fitted facing backwards.

Children in ages between an age of 9 months up to 3 years

Children of this age are transported in child restraint systems facing forward.

Children in ages from 3 to 6 years

Children of this age are transported in child restraint systems facing forward.

Children in ages from 6 to 12 years

▶ Children of this age are transported in child restraint systems facing forward.

Using child restraint systems in the front passenger seat



The use of a child restraint system in the front passenger seat can result in serious personal injury or death to the child from an airbag deployment.

To reduce risk of injury from an inflating airbag in an accident. Porsche strongly recommends:

▶ Under all normal circumstances, the child seat must be placed in the rear. Do not use a child restraint system in the front passenger seat.

However, there may be serious situations where it might be necessary to place a child in the front seat so that he/she can be kept under direct observation to prevent an immediate risk to the child (for example, while driving to the doctor or hospital). The following instructions are provided to you solely for that purpose.

- ▶ Seek appropriate advice from your authorized Porsche dealer about the possible installation of a Porsche child restraint system.
- ▶ If a child restraint system must be fastened to the passenger's seat, adjust the passenger's seat as far away from the airbag as possible.
- ▶ If emergency or other serious conditions require a child to be placed in the front seat, exercise extreme caution and defensive driving of your vehicle. You must recognize that any substantial frontal impact could result in the deployment of the passenger airbag, which could lead to serious injury or death of the child.

Child restraint system for up to one-year old children

If the child restraint system must be fastened to the passenger's seat in exceptional cases:

- make sure that the PASSENGER AIRBAG OFF indicator lamp lights up.
- adjust the passenger's seat as far away from the airbag as possible



Risk of serious personal injury or death due to the passenger airbag triggering unintentionally.

When the ignition is on and the up to oneyear old child is seated in the child restraint system on the passenger seat the indicator lamp "PASSENGER AIRBAG OFF" must be on.

If the "PASSENGER AIRBAG OFF" indicator lamp does not light up, it could indicate a fault in the system. In this case:

- ▶ Fasten the child restraint system on the rear bench immediately.
- ▶ Have the fault remedied at your nearest authorized Porsche dealer.

Child restraint system for children older than one year

Your vehicle is equipped with weight sensing for the passenger's seat in accordance with U.S. Federal Motor Vehicle Safety Standard 208. Depending on the weight acting on the passenger's seat, the passenger's airbag will automatically be switched on or off.

In case of doubt, fasten the child restraint system on the rear bench.

Small adult passengers

Make sure that the PASSENGER AIRBAG OFF indicator lamp does not light up.



Risk of serious or mortal injury due to the passenger airbag not triggering.

When the ignition is on and the small adult passenger is seated on the passenger seat, the indicator lamp "PASSENGER AIRBAG OFF" must be off.

If the "PASSENGER AIRBAG OFF" indicator lamp lights up, it could indicate a fault in the system.

In this case:

- ▷ Carry the passenger on the rear bench.
- Have the fault remedied at your nearest authorized Porsche dealer.

Automatic locking retractor

The safety belts for the front passenger and the rear bench are equipped with an automatic locking retractor for securing the child restraint system. When activated, this retractor allows you to securely fasten the child restraint system in place so that inadvertent movements will not occur.



The use of a child restraint system on the front passenger seat can result in serious personal injury or death to the child from an airbag deployment.

To reduce risk of injury from an inflating airbag in an accident, Porsche strongly recommends:

 Under all normal circumstances, the child seat must be placed in the rear.
 Do not use a child restraint system on the front passenger seat. However, there may be serious situations where it might be necassary to place a child in the front seat so that he/she can be kept under direct observation to prevent an immediate risk to the child (for example, while driving to the doctor or hospital). The following instructions are provided to you solely for that purpose.

- ▷ Seek appropriate advice from your authorized Porsche dealer about the possible installation of a Porsche child restraint system.
- ▶ If a child restraint system must be fastened to the passenger's seat, adjust the passenger's seat as far away from the airbag as possible.

Before transporting a child on the passenger seat:

- ▶ Please observe the chapter "CHILD RES-TRAINT SYSTEMS" on Page 58.
- ▶ If emergency or other serious conditions reguire a child to be placed in the front seat, exercise extreme caution and defensive driving of your vehicle. You must recognize that any substantial frontal impact could result in the deployment of the passenger airbag, which coluld lead to serious injury or death of the child.



A - PASSENGER AIRBAG OFF indicator lamp



Risk of serious personal injury or death to the child, when excessive force is acting on the passenger's seat due to the seat belt and the passenger's airbag is switched on unintentionally.

- ▶ After fastening the child restraint system, do not adjust the seat.
- ▷ Check the condition of the passenger airbag system shown by the indicator lamp A in the central console.

Activating the automatic locking retractor

- 1. If a child restraint system must be fastened to the passenger's seat, adjust the passenger's seat as far away from the airbag as possible.
- 2. Fasten child seat.
- 3. Pull the safety belt retractor completely out. At this point the locking mechanism is activated.
- 4. Insert the safety belt tongue into the buckle and make certain that it is properly latched. Make no more adjustments to the seat.
- 5. Allow the safety belt to retract until it is tight on the child restraint system. You may further tighten the belt by pulling on it to allow more of it to retract.

Make sure that excessive seat belt forces do not occur by moving the seat with the child seat installed.

Releasing the safety belt

1. Unbuckle the safety belt latch.

Then make certain that the belt has fully retracted. At this point the automatic locking feature will be disengaged.

Seek appropriate advice from your authorized Porsche dealer about the possible installation of a Porsche child restraint system.



LATCH Child Seat System

Use only child restraint systems with the LATCH system recommended by Porsche.

These systems have been tested and adjusted to the interior of your Porsche and the appropriate child age groups. Other systems have not been tested and could entail an increased risk of injury.

You can obtain child seats that are LATCH-compatible at your authorized Porsche dealer.

Always observe the separate installation instructions for your child seat.



Installing a LATCH child seat system

Markings on the right and left for the LATCH child seat anchorage can be found on the backrests of the outer rear seats.

The anchor bars **A** for the LATCH child seat anchorage can be found directly under the markings between backrest and seat cushion.

/!\ Danger!

The use of a child restraint system on the front passenger seat can result in serious personal injury or death to the child from an airbag deployment.

To reduce risk of injury from an inflating airbag in an accident. Porsche strongly recommends:

- ▶ Under all normal circumstances, the child seat must be placed in the rear. Do not use a child restraint system on the front passenger seat.
- ▶ Please see your authorized Porsche dealer for correct Porsche Child Seat availability.
- ▶ Porsche recommends the use of a Porsche Child Seat with Lower Anchorage and Tether for Children system (LATCH).
- 1. Secure the child seat to retaining lugs **A** as outlined in the operating manual for the child seat.
- 2. Pull the child seat to check that both fastening points are engaged correctly.



Warning!

Child restraint anchorages are designed to withstand only those loads imposed by correctly fitted child restraints. Under no circumstances are they to be used for adults safety belts or harnesses. Such use could result in serious personal injury or death.

- ▶ Do not misuse the child restraint anchorages. Only attach one child seat tether per anchor-
- ▶ They are not designed to withstand loads imposed by adults.

Child Restraint Anchorages

▶ Please observe the chapter "AUTOMATIC LO-CKING RETRACTOR" on Page 60.

If your child restraint seat or seats require the use of a tether strap, you will want to use the anchor points A provided behind the rear bench backrests.


To ensure proper installation, see your authorized Porsche dealer.

Brief overview – door mirrors

This brief overview does not replace the information provided in the chapter "Door mirrors". In particular, warnings are not replaced by this brief overview.

Precondition

Switch ignition on.



Switch for mirror adjustment

What do I want to do?	What do I have to do?	What do I see?
Adjusting the mirror on the driver's side	Turn switch to position ${\bf A}$ and tilt switch in the desired direction.	The mirror glass moves in the desired direction.
Adjusting the mirror on the passenger's side	Turn switch to position ${\bf C}$ and tilt switch in the desired direction.	The mirror glass moves in the desired direction.
Folding in mirrors	Turn switch to position D .	Both door mirrors fold in.
Unfolding mirrors	Turn switch to position A or C .	Both door mirrors unfold.
Heating mirrors	Turn switch to position B .	



- A Door mirror setting driver's side
- B Heat door mirror
- C Door mirror setting passenger's side
- **D** Fold in door mirrors

Door Mirrors

The convex mirror glass on the passenger's side provides a larger field of view.

✓!\ Warning!

Risk of accident. Vehicles or objects appear smaller in convex mirrors and further away than they are in reality.

- ▶ Bear this distortion in mind when estimating the distance of vehicles behind you and when reversing into a parking space.
- ▷ Also make use of the interior mirror for judging the distance.

Risk of damage to the door mirrors when washing the vehicle in a car wash.

▶ Fold in door mirrors before using the car wash.

Adjusting mirrors

- 1. Switch ignition on.
- 2. Select **A** for the driver's side or **C** for the passenger's side by turning the control switch.
- 3. Move the door mirrors in the appropriate direction by tilting the control switch.

If the electrical adjustment facility fails

▶ Adjust the mirror by pressing on the mirror face.

Adjusting the door mirrors synchronously

In the multi-purpose display of the instrument panel, you have the option of adjusting the door mirrors synchronously.

▶ Please observe the chapter "SYNCHRONOUS ADJUSTMENT OF DOOR MIRRORS" on Page 166.

Folding in door mirror

- Switch ignition on.
- ▶ Turn control switch to **D**. Both door mirrors fold in automatically.

If the electrical adjustment facility fails

▶ Fold in mirror manually.

Unfolding door mirrors

- Switch ignition on.
- ▶ Turn control switch to **A** or **C**. Both door mirrors unfold automatically.

If the electrical adjustment facility fails

▶ Unfold mirrors manually.

Door mirror heating

The door mirror heater is ready for operation when the ignition is switched on.

Switching on

▶ Turn control switch to **B**. Both door mirrors are heated.

Switching off

▶ Change the position of the control switch.

Storing door mirror settings

On vehicles with seat memory, individual door mirror settings can be stored on the person buttons of the seat memory and vehicle keys and recalled with these.

- ▶ Please observe the chapter "FRONT SEAT WITH MEMORY" on Page 42.
- ▶ Please observe the chapter "STORING PAS-SENGER MIRROR SETTING AS A PARKING AID" on Page 43.



- A Control switch for door mirror adjustment
- C Passenger mirror setting

Swivelling down mirror glass as parking aid

When reverse gear is engaged, the mirror glass on the **passenger's side** swivels down slightly to show the curb area.

Preconditions

- Vehicle must be equipped with seat memory.
- Control switch **A** must be turned to position **C** (passenger mirror's setting).
- Reverse gear must be engaged.

Moving mirror glass to its initial position with reverse gear engaged

The mirror glass swivels to its initial position when:

- The car is shifted out of reverse gear or
- ▶ The position of the control switch for the door mirror setting is changed.



Interior Mirror

Initial position – lever forward Anti-dazzle setting - lever back

Note on operation

▶ When the interior mirror is being adjusted, antidazzle lever **A** must point forward.



- E Light-emitting diodes (LED)
 F Button for automatic anti-dazzle operation
- G Light sensors

Automatic Anti-Dazzle Mirror

Sensors on the front and rear sides of the interior mirror measure the incident light. The mirrors automatically change to anti-dazzle position or revert to their normal state, depending on the light intensity.

Note on operation

The incident light in the area of light sensors **G** must not be restricted (e.g. by stickers on the windshield).

Switching off automatic anti-dazzle operation

▶ Press button **F**. Light-emitting diode **E** goes out.

Note on operation

Anti-dazzle operation switches off automatically,

- Reverse gear is engaged or
- Interior lighting and/or reading lights in the front are switched on.

Switching on automatic anti-dazzle operation

▶ Press button **F**. Light-emitting diode **E** lights up.


! Warning!

Danger of injury. Electrolyte fluid can emerge from broken mirror glass. This fluid irritates the skin and eyes.

▷ If the electrolyte fluid should come into contact with the skin or eyes, immediately rinse it off with clean water. See a doctor if necessary.

Risk of damage to paintwork and leather and plastic parts, and clothing. Electrolyte fluid can be removed only while it is still wet.

▷ Clean the affected parts with water.



Steering Wheel

Tiptronic rocker switches

The Porsche Tiptronic is a six-speed transmission and features an "automatic" and a "manual" gearshift mode.

You can change temporarily to manual mode using rocker switches **A** on the steering wheel.

▶ Please observe the chapter "TIPTRONIC S" on Page 195.

Horn

▶ Press button **B** to operate the horn.

Airbag unit

Airbag unit C is located behind the padded steering wheel boss.

In conjunction with the safety belts, the "airbag" is a safety system designed to provide the driver and passengers with maximum protection from injury in an accident.

▶ Please observe the chapter "AIRBAG SYS-TEMS" on Page 53.

Steering Wheel Heating

The steering wheel heating is switched on and off automatically when the ignition is switched on depending on the interior temperature.

On vehicles with manual air conditioning

The steering wheel heating switches itself on when the following criteria are fulfilled at the same time:

- 1. Low outside temperature.
- 2. Low engine temperature.
- 3. The interior temperature setting in the display of the air conditioning is 10 and more bars.

or at the highest level (all bars) of the interior temperature setting on the display of the air conditioning.

The steering wheel heating switches itself off again after a warming-up phase, or is switched off if one of the criteria is no longer met.

For more information about setting the interior temperature on vehicles with manual air condition-

▶ Please observe the chapter "SETTING TEMPE-RATURE" on Page 81.

Steering Wheel Adjustment



Risk of accident. The steering wheel may move further than desired if you attempt to adjust it when driving.

You can lose control of the vehicle, causing serious personal injury or death.

▷ Do not adjust the steering wheel when driving.

Risk of crushing due to uncontrolled recall of seat memory settings.

▷ Do not leave children in the car unattended.



Manual adjustment

- 1. Swivel locking lever **A** downwards.
- 2. Adapt the steering wheel setting to the backrest angle and your seat position. Move the steering wheel in the desired direction.
- gage.



Electrical adjustment

▶ Press control switch **B** in the relevant direction until the desired setting is reached.

The steering wheel setting can be stored in the seat memory.

3. Swivel locking lever **A** back until you feel it en- ▷ Please observe the chapter "FRONT SEAT WITH MEMORY" on Page 42.

Multi-Functional Steering Wheel



There is a danger of accident if you set or operate the on-board computer, radio, navigation system, telephone or other equipment when driving.

This could distract you from the traffic and cause you to lose control of the vehicle.

- ▷ Operate the components while driving only if the traffic situation allows you to do so safely.
- ▶ Carry out any complicated operating or setting procedures only with the vehicle stationary.

Depending on the equipment in your vehicle, you can use these function keys to operate the following Porsche communication systems:

- Telephone.
- Radio with CD drive,
- CD changer,
- Satelite radio.

Readiness for operation of multifunctional steering wheel

- With ignition switched on and
- With Porsche communication systems switched on.
- ▶ Please observe the operating instructions supplied for the Porsche communication systems before operating the function keys.

Note on operation

The Porsche communication systems cannot be switched on and off using the multi-functional steering wheel.



Operating the function keys

The function keys on the steering wheel (arrows) can be operated by pressing and by pulling.

Various functions may require you to press or pull the buttons several times in order to achieve the desired setting.



Steering wheel buttons - lighting

When the light switch is operated, the light switches on automatically.

Using the buttons on the back of the steering wheel (arrow), the lighting for the function keys and the rocker switches can be switched on and off.

Switching lighting off

Press button.

Switching lighting on

▶ Press button again.



Multi-functional steering wheel with telephone function

▶ Please observe the operating instructions supplied for the Porsche communication systems before operating the function keys.

- Answer the telephone
 - Take calls.
- Hang up the telephone
 - End or reject the call.
- Increase the volume of the relevant communication system
- Decrease the volume of the relevant communication system
- Switch off the sound MUTE
- Next radio station/title
 - Select the next radio station or title.
- Last radio station/title
 - Select the previous radio station or title.
- Source selection
 - Select available audio source. Depending on the equipment in your vehicle, the following sources are available: radio, CDS (single CD player), CDC (CD changer).



Multi-functional steering wheel without telephone function

▶ Please read the operating instructions supplied for the Porsche communication systems before operating the function keys.

Manual tuning

- Set radio station manually.

Scan titles, radio stations

- Scan titles, radio stations briefly.

- Increase the volume of the relevant communication system
- Decrease the volume of the relevant communication system
- Next radio station/title

- Select the next radio station or title.

Last radio station/title

- Select the previous radio station or title.

Switch off the sound

J Source selection

- Select available audio source. Depending on the equipment in your vehicle, the following sources are avai-

radio, CDS (single CD player), CDC (CD changer).



Note on operation

▶ Please note that sun visor **B** must be swivelled upwards before swivelling back sun visor A. Otherwise, sun visor **B** can no longer be swivelled upwards.



Sun Visors



Risk of injury in an accident.

- ▶ Keep the sliding cover closed while driving.
- Swing sun visor **A** down to prevent dazzle from the front.
- ▷ If you are dazzled from the side, unclip sun visor A from the inner bracket and swivel it round so that it is in front of the door window. You can also swivel sun visor **B** downwards.

Make-up mirror

The make-up mirror on the rear of the sun visor is closed with a sliding cover.

▶ The make-up mirror illumination is switched on automatically when the sliding cover is opened (arrow).



Sun Blinds, Rear Side Windows

The sun blinds in the rear door trim panels can be pulled out.



Risk of damage.

▶ Pull out sun blinds during the journey only when door windows are closed.

Pulling out sun blinds


▶ Pull out sun blind (arrow) and engage in holders A.

Retracting sun blinds

Disengage the sun blind from holders **A** and carefully guide it back into the retractor roller.

Air Conditioning, Parking Heater and Heated Rear Window

Overview of Air-Conditioning Systems	.7
Opening the Cover Flap of the	
Air-Conditioning Control Panel	. 78
Brief Overview–	
Manual Air-Conditioning	.79
Manual Air-Conditioning	.80
Brief Overview –	
Automatically Controlled	
2-Zone Air-Conditioning System	.84
Automatically Controlled	
2-Zone Air-Conditioning	.8!
Brief Overview –	
Automatically Controlled	
4-Zone Air-Conditioning System,	
Front Control Panel	.90
Brief Overview –	
Automatically Controlled	
4-Zone Air-Conditioning System,	
Rear Control Panel	.9
Automatically Controlled	
4-Zone Air-Conditioning	.92
Vents	.98
Heated Rear Window	.99
Parking Heater1	



Overview of Air-Conditioning Svstems

The following air-conditioning system types may be installed, depending on your vehicle equipment:

A - Automatically controlled 4-zone airconditioning system

The air-conditioning system controls the set interior temperature completely automatically. Temperature, air quantity and air distribution can be set individually for the front left, front right, rear left and rear right air-conditioned areas.

B - Automatically controlled 2-zone airconditioning system

The air-conditioning system controls the preselected interior temperature completely automatically. Temperature can be set individually for the left and right air-conditioned areas.

C - Manual air-conditioning system

Air quantity, air distribution and temperature can be set on the control panel of the manual air-conditioning system.

How do I recognize which is "my" airconditioning system?

- **A** Button for rear control panel is present
- **B** AUTO button and REST button present
- C Wide rocker switch and no AUTO button



Opening the Cover Flap of the Air-Conditioning Control Panel

Swivel cover flap on the handle downwards (arrow).

Brief Overview– **Manual Air-Conditioning**

This brief overview does not replace the information provided in the chapter "Manual Air-Conditioning". In particular, warnings are not replaced by this brief overview.



What do I want to do?	What do I have to do?
Setting temperature	Push button K up (warmer) or down (colder).
Setting air quantity	Push button E up (more) or down (less).
Setting air distribution	Air to windshield: Press button F . Air to central and side vents: Press button H . Air to footwell: Press button G .
Defrosting windshield	Press button A .



Note on operation

The air conditioner settings are stored on the respective remote control when switching off the ignition and locking the vehicle. The "Air flow OFF" setting is stored for approx. 60 minutes and the "Recirculated air" setting is stored for approx. 20 minutes.

- A Windshield defroster
- **B** Heated rear window
- C Recirculated air
- D Air-conditioning display
 E Air-quantity button
 F Air to windshield
- G Air to footwell
- H Air to central and side vents
- I ECON button (air-conditioning compressor off/on)
- J REST button (engine residual heat)
- K Temperature button

conditioning.

ditioning display panel.

Manual Air-Conditioning

Air quantity, air distribution, and temperature

can be set on the control panel of the manual air

This individual adjustment is shown on the air-con-

Setting temperature

▶ Push temperature button **K** up (warmer) or down (colder).

The selected temperature is shown in a bar display on the display above the button. The more bars that are displayed, the higher the temperature of the air flowing into the interior.

Note

▶ For maximum cooling, activate recirculated air button 🔼.

Setting air quantity

▶ Push air quantity button **E** up (more) or down

The selected air quantity is shown in a bar display on the display above the button.

The more bars that are displayed, the more air flows into the interior.

If the air quantity was reduced so much that "OFF" appears on the display, the outside-air supply is interrupted.



Risk of accident due to impaired vision, resulting in serious personal injury or death. If the air quantity is "OFF", the windows may mist up.

- ▷ Only select air quantity setting "OFF" for short periods.
- ▶ If windows mist up, push air quantity button **E** up to increase air quantity and select the function "Defrost windshield".

Setting air distribution

Air to windshield

Press button ... The air flows to the windshield.



Air to central and side vents

▶ Press button • ... The air flows from the central and side vents. Vents must be open.



Air to footwell

▶ Press button ▼. The air flows to the footwell.



Switching recirculating-air mode



Risk of accident due to impaired vision. resulting in serious personal injury or death. In recirculating-air mode, the windows may mist up.

- ▷ Only select recirculating-air mode for short periods.
- ▷ If windows mist up, switch recirculating-air mode off immediately by pressing the recirculating-air button again and select the function "Defrost windshield".
- Press button ... Indicator light in button lights up. The outside-air supply is interrupted and only the inside air is circulated.



Defrost windshield

▶ Press button . Indicator light in button lights up. The air flows to the windshield and the front side windows.

The windshield is demisted or defrosted as quickly as possible.

Ending the function

▶ Press button again.

ECON mode



Risk of accident due to impaired vision. resulting in serious personal injury or death. The outside air that is flowing in is not dried in ECON mode. The windows may mist up.

▷ Do not switch on ECON mode in damp weather.

In ECON mode, the air-conditioning compressor is switched off and this deactivates the cooling function (e.g. to save fuel).

The air-conditioning compressor is always switched off at temperatures below 37.4 °F (3 °C).

Switching on ECON mode

▶ Press button **ECON**.

The ECON logo appears on the air-conditioning display panel.

The air-conditioning compressor is switched

Switching off ECON mode

▶ If the interior temperature is too high, press button **ECON**.

The ECON logo disappears from the air-conditioning display panel.

The air-conditioning compressor is switched

REST mode

Using engine residual heat

The residual heat of the engine can be used to heat the interior up to 20 minutes after the ignition has been switched off.

▶ Press **REST** button. The air-conditioning settings cannot be changed in REST mode.

Ending the function

▶ Press **REST** button.

Note on operation

If the battery voltage is too low, REST mode is automatically ended.

Information on air-conditioning compressor

The air-conditioning compressor:

- May switch off briefly to ensure sufficient engine cooling if the engine is operating under extreme load.
- Switches off automatically at temperatures below approx. 37.4 °F (3 °C) and cannot be switched on, even manually.
- Operates most effectively with windows closed. If the car has been in the sun for a long time. however, it is a good idea to ventilate the

interior briefly with the windows open.

- Depending on the outside temperature and humidity, condensation can drip from the evaporator and form a pool under the car. This is normal and not a sign of leakage.
- If uncooled air flows out when the lowest temperature has been set ("LO"), switch off the air-conditioning compressor and have the fault remedied at an authorized Porsche dealer.

Brief Overview – Automatically Controlled 2-Zone Air-Conditioning System

This brief overview does not replace the information provided in the chapter "Automatically Controlled 2-Zone Air-Conditioning". In particular, warnings are not replaced by this brief overview.



What do I want to do?	What do I have to do?
Switching on automatic air-conditioning system	Press button C .
Setting temperature	Left vehicle side: Push button H up (warmer) or down (colder). Right vehicle side: Push button N up (warmer) or down (colder).
Setting air quantity	Push button G up (more) or down (less).
Setting air distribution	Air to windshield: Press button I. Air to central and side vents: Press button K. Air to footwell: Press button J.
Defrosting windshield	Press button A .



Automatically Controlled 2-Zone Air-Conditioning

Depending on various factors (e.g. sunlight, air quality), the air-conditioning system controls the preset interior temperature fully automatically.

Temperature can be set individually/separately for the two left and right air-conditioned areas.

You can manually influence the automatic system. This individual adjustment is shown on the air-conditioning display panel.

Note on operation

The air conditioner settings are stored on the respective remote control when switching off the ignition and locking the vehicle. The "Air flow OFF" setting is stored for approx. 60 minutes and the "Recirculated air" setting is stored for approx. 20 minutes.

- A Windshield defroster
- **B** Heated rear window
- C AUTO button (automatic mode)
- D Recirculated air, automatic recirculated air
- **E** Air-conditioning display
- **F** Temperature sensor
- **G** Air-quantity button
- H Temperature button for left side
- I Air to windshield
- J Air to footwell
- K Air to central and side vents
- **L** ECON button (air-conditioning compressor off/on)
- M- REST button (engine residual heat)
- N Temperature button, right side

Automatic mode

▶ Press button AUTO. Indicator light in button lights up. Air quantity and air distribution are automatically controlled and variations are compensated.

Note on operation

If necessary, the automatic system can be manually influenced.

This manual setting is retained until the appropriate function button is pressed again or the button **AUTO** is pressed.

Setting temperature

To suit personal comfort, the interior temperature can be adjusted between 61 °F and 85 °F (16 °C and 29.5 °C).

Recommendation: 72 °F (22 °C)

▶ Push temperature button up (warmer) or down (colder).

Button H: left side of vehicle Button N: right side of vehicle The selected temperature is shown on the display above the button.

If "LO" or "HI" appears on the display, the system is operating at maximum cooling or heating power. Automatic mode is switched off.

If the preselected temperature is changed, the air quantity blowing out can adjust automatically in automatic mode.

The desired temperature is reached more quickly this way.

Setting air quantity

▶ Push air quantity button **G** up (more) or down

The selected air quantity is shown in a bar display on the display above the button.

Press button **AUTO** to return to automatic mode.

If the air quantity was reduced so much that "OFF" appears on the display, the outside-air supply is interrupted.



Risk of accident due to impaired vision, resulting in serious personal injury or death. If the air quantity is "OFF", the windows may mist up.

- ▷ Only select air quantity setting "OFF" for short
- ▶ If windows mist up, push air quantity button **G** up to increase air quantity and select the function "Defrost windshield".

Setting air distribution



▲ Air to windshield

▶ Press button ▲. The air flows to the windshield.



Air to central and side vents

▶ Press button ■. The air flows from the central and side vents. Vents must be open.



Air to footwell

▶ Press button ▼. The air flows to the footwell.

Ending air distribution functions

- ▶ Press the relevant button again or
- ▶ Press button AUTO.

Accepting settings for driver's side for the entire vehicle

The MONO function allows temperature settings for the driver's side to be accepted for the entire vehicle.

Switching MONO function on

The temperature settings for the driver's side can be accepted for the entire vehicle.

▶ Press button **AUTO** for 2 seconds. The MONO logo appears on the air-conditioning display panel.

Ending MONO function

- ▶ Press button **AUTO** for 2 seconds **or**
- ▶ Change the settings in the air-conditioned areas.

Switching automatic recirculating-air mode on

▶ Press button once. Indicator light in button lights up. Control of the outside-air supply depends on the air quality.

Note

The recommended operating mode is automatic recirculating-air mode.



Switching recirculating-air mode



Risk of accident due to impaired vision. resulting in serious personal injury or death. In recirculating-air mode, the windows may mist up.

- ▷ Only select recirculating-air mode for short periods.
- ▷ If windows mist up, end recirculating-air mode by pressing the recirculating-air button again and selecting the function "Defrost windshield".
- ▶ Press button twice. Indicator light in button lights up. The outside-air supply is interrupted and only the inside air is circulated.

Note on operation

When the air-conditioning compressor is switched off manually or automatically, recirculating-air mode ends after approx. 3 minutes.



Defrosting the windshield

Indicator light in button lights up. The air flows to the windshield and the front side windows. The windshield is demisted or defrosted as

Ending the function

quickly as possible.

Press button again or Press button Auto.

ECON mode



Risk of accident due to impaired vision. resulting in serious personal injury or death. The outside air that is flowing in is not dried in ECON mode. The windows may mist up.

▷ Do not switch on ECON mode in damp weather.

In ECON mode, the air-conditioning compressor is switched off and this deactivates the cooling function (e.g. to save fuel).

The air-conditioning compressor is **always** switched off at temperatures below 37.4 °F (3 °C).

Switching on ECON mode

▶ Press button **ECON**.

The ECON logo appears on the air-conditioning display panel.

The air-conditioning compressor is switched

Switching off ECON mode

▶ If the interior temperature is too high, press button **ECON or** press button AUTO.

The ECON logo disappears from the air-conditioning display panel.

The air-conditioning compressor is switched

REST mode

Using engine residual heat

The residual heat of the engine can be used to heat the interior up to 20 minutes after the ignition has been switched off.

▶ Press **REST** button. The air-conditioning settings cannot be changed in REST mode.

Ending the function

▶ Press **REST** button.

Note on operation

If the battery voltage is too low, REST mode is automatically ended.

Information on air-conditioning compressor

The air-conditioning compressor:

- May switch off briefly to ensure sufficient engine cooling if the engine is operating under extreme load.
- Switches off automatically at temperatures below approx. 37.4 °F (3 °C) and cannot be switched on, even manually.
- Operates most effectively with windows closed.
 - If the car has been in the sun for a long time. however, it is a good idea to ventilate the interior briefly with the windows open.
- Depending on the outside temperature and humidity, condensation can drip from the evaporator and form a pool under the car. This is normal and not a sign of leakage.
- If uncooled air flows out when the lowest temperature has been set ("LO"), switch off the air-conditioning compressor and have the fault remedied at an authorized Porsche dealer.

Sensors

To avoid affecting the performance of the air-conditioning system:

▷ Do not cover the sun sensor on the dashboard and the temperature sensor **F** in the front control panel of the air-conditioning system.

Brief Overview – Automatically Controlled 4-Zone Air-Conditioning System, Front Control Panel

This brief overview does not replace the information provided in the chapter "Automatically Controlled 4-Zone Air-Conditioning". In particular, warnings are not replaced by this brief overview.



What do I want to do?	What do I have to do?
Switching on automatic air-conditioning system at front	Press button C .
Setting temperature at front	Left side: Push button H up (warmer) or down (colder). Right side: Push button Q up (warmer) or down (colder).
Setting air quantity at front	Left side: Push button G up (more) or down (less). Right side: Push button R up (more) or down (less).
Setting air distribution at front	Air to windshield, left or right side: Press button ${\bf I}$ or ${\bf P}$. Air to central and side vents, left or right side: Press button ${\bf K}$ or ${\bf N}$. Air to footwell, left or right side: Press button ${\bf J}$ or ${\bf O}$.
Defrosting windshield	Press button A .

Brief Overview – Automatically Controlled 4-Zone Air-Conditioning System, Rear Control Panel

This brief overview does not replace the information provided in the chapter "Automatically Controlled 4-Zone Air-Conditioning". In particular, warnings are not replaced by this brief overview.



What do I want to do?	What do I have to do?
Switching on automatic air-conditioning system at rear	Press button C .
Setting temperature at rear	Left side: Push button H up (warmer) or down (colder). Right side: Push button S up (warmer) or down (colder).
Setting air quantity at rear	Left side: Push button G up (more) or down (less). Right side: Push button T up (more) or down (less).
Setting air distribution at rear	Air to side window, left or right side: Press button I or P . Air to central vent, left or right side: Press button K or R . Air to footwell, left or right side: Press button J or Q .



Automatically Controlled 4-Zone Air-Conditioning

Depending on various factors (e.g. ambient temperature, sunlight, air quality), the air-conditioning system controls the preset interior temperature fully automatically.

Temperature, air quantity and air distribution can be set individually/separately for the four air-conditioned areas front left, front right, rear left and rear right.

You can manually influence the automatic system. This individual adjustment is shown on the air-conditioning display panel.

Note on operation

The air conditioner settings are stored on the respective remote control when switching off the ignition and locking the vehicle. The "Air flow OFF" setting is stored for approx. 60 minutes and the "Recirculated air" setting is stored for approx. 20 minutes.

Control panel, front

- A Windshield defroster
- **B** Heated rear window
- C AUTO button (automatic mode) REST button (engine residual heat)
- D Recirculated air, automatic recirculated air
- E Air-conditioning display
- F Temperature sensor
- **G** Air-quantity button, left
- H Temperature button, left
- I Air to windshield, left
- J Air to footwell, left
- K Air to left central and side vents
- L Setting for rear air-conditioned areas
- M- ECON button (air-conditioning compressor off/on)
- N Air to right central and side vents
- O Air to footwell, right
- P Air to windshield, right
- Q Temperature button, right
- R Air-quantity button, right

Sensors

To avoid affecting the performance of the air-conditioning system:

▷ Do not cover the sun sensor on the dashboard and the temperature sensor **F** in the front control panel of the air-conditioning system.



AUT Automatic mode

You can switch to automatic mode for the front and rear air-conditioned areas, independently of one another.

▶ Press AUTO button **C** on the front or rear control panel.

The indicator light in button **C** of the front control panel and the AUTO indication in the rear display panel are lit.

Air quantity and distribution are automatically controlled and variations are compensated.

If necessary, the automatic system can be manually influenced.

Note on operation

This manual setting is retained until the appropriate function button is pressed again or the AUTO button C is pressed.

Control panel, rear

- C AUTO button (automatic mode)
- **F** Air-conditioning/seat heating display
- **G** Air-quantity button, left
- H Temperature button, left; seat heating, left
 I Air to vent, left door post
- J Air to footwell, left
- **K** Air to left central vent (center console)
- O Seat heating off/on
 P Air to vent, right door post
 Q Air to footwell, right
- **R** Air to right central vent (center console)
- S Temperature button, right; seat heating, right
- T Air-quantity button, right

Setting temperature

To suit personal comfort, the interior temperature for each of the four air-conditioned areas can be adjusted between 61°F and 85°F (16°C and 29.5°C).

Recommendation: 72°F (22°C)

Push temperature button up (warmer) or down (colder).

Left air-conditioned area, front: Button **H** Right air-conditioned area, front: Button Q

Left air-conditioned area, rear: Button H Right air-conditioned area, rear: Button \$

The selected temperature is shown on the display above the button.

If "LO" or "HI" appears on the display, the system is operating at maximum cooling or heating power.

If the preselected temperature is changed, the air quantity blowing out can adjust automatically in automatic mode.

The desired temperature is reached more quickly this way.

Setting air quantity

The air quantity can be selected individually for each of the four air-conditioned areas.

Push air quantity button up (more) or down (less).

Left air-conditioned area, front: Button G Right air-conditioned area, front: Button R

Left air-conditioned area, rear: Button G Right air-conditioned area, rear: Button T The selected air quantity is shown in a bar display on the display above the button. The more bars that are displayed, the more air flows into the interior.

▶ Press AUTO button **C** to return to automatic mode.

If the air quantity on the front control panel was reduced so much that "OFF" appears on the display. the outside-air supply is interrupted.

∕!\ Warning!

Risk of accident due to impaired vision. resulting in serious personal injury or death. If the air quantity is "OFF", the windows may mist up.

- ▷ Only select air quantity setting "OFF" for short periods.
- ▶ If windows mist up, push air quantity buttons **G** and **O** up to increase air quantity and select the function "Defrost windshield".

Setting air distribution

Air to windshield and side windows

The air quantity can be selected individually for each of the four air-conditioned areas.

- Front control panel: The air flows to the windshield.
- Rear control panel: The air flows to the respective side window.
- ▶ Press button ...



Air to central and side vents

- ▶ Press button
- Front control panel: The air flows from the front central and side
- Rear control panel: The air flows to the center vents.
- ▶ Vents must be open.



Air to footwell

▶ Press button ▼. The air flows to the footwell.

Ending air distribution functions

- ▶ Press the relevant button again or
- ▶ Press the AUTO button C.

Accepting settings for driver's side for the entire vehicle

The MONO function allows the temperature and air quantity settings for the driver's side to be accepted for the entire vehicle.

Switching on MONO function

▶ Press button Press button Press button Press button In the front control panel for 2 seconds.

The MONO logo appears on the air-conditioning display panel.

Ending MONO function

- ▶ Press button Auto in the front control panel for 2 seconds or
- ▶ Change the settings in the air-conditioned areas.



Defrosting the windshield

▶ Press button on the front control panel. Indicator light lights up.

The air flows to the windshield and the front side windows.

The windshield is demisted or defrosted as quickly as possible.

Ending the function

- ▶ Press button again or
- ▶ Press the button AUTO.



Switching automatic recirculatingair mode on

▶ Press button on the front control panel

Indicator light in button lights up. Control of the outside-air supply depends on the air quality.

Note

The recommended operating mode is automatic recirculating-air mode.



Switching recirculating-air mode



Risk of accident due to impaired vision. resulting in serious personal injury or death. In recirculating-air mode, the windows may mist up.

- ▷ Only select recirculating-air mode for short periods.
- ▶ If windows mist up, end recirculating-air mode by pressing the recirculating-air button again and selecting the function "Defrost windshield".
- ▶ Press button on the front control panel twice.

Indicator light in button lights up.

The outside-air supply is interrupted and only the inside air is circulated.

Note on operation

When the air-conditioning compressor is switched off manually or automatically, recirculating-air mode ends after approx. 3 minutes.

ECON mode



Risk of accident due to impaired vision. resulting in serious personal injury or death. The outside air that is flowing in is not dried in ECON mode. The windows may mist up.

▷ Do not switch on ECON mode in damp weather.

In ECON mode, the air-conditioning compressor is switched off and this deactivates the cooling function (e.g. to save fuel).

The air-conditioning compressor is always switched off at temperatures below 37.4 °F (3 °C).

Switching on ECON mode

▶ Press button **ECON**.

The ECON logo appears on the air-conditioning display panel.

The air-conditioning compressor is switched

Switching off ECON mode

▶ If the interior temperature is too high, press button **ECON or** press button AUTO.

The ECON logo disappears from the air-conditioning display panel.

The air-conditioning compressor is switched

AUTO REST mode

Using engine residual heat

The residual heat of the engine can be used to heat the interior up to 20 minutes after the ignition has been switched off.

▶ Press button on the front control panel. The air-conditioning settings cannot be changed in RFST mode.

Ending the function

▶ Press button AUTO.

Note on operation

If the battery voltage is too low, REST mode is automatically ended.

Information on air-conditioning compressor

The air-conditioning compressor:

- May switch off briefly to ensure sufficient engine cooling if the engine is operating under extreme load.
- Switches off automatically at temperatures below approx. 37.4 °F (3 °C) and cannot be switched on, even manually.
- Operates most effectively with windows closed. If the car has been in the sun for a long time. however, it is a good idea to ventilate the interior briefly with the windows open.
- Depending on the outside temperature and humidity, condensation can drip from the evaporator and form a pool under the car. This is normal and not a sign of leakage.
- If uncooled air flows out when the lowest temperature has been set ("LO"), switch off the air-conditioning compressor and have the fault remedied at an authorized Porsche dealer.



Disabling control panel for air-conditioned areas at the rear

Power windows, central locking buttons on the rear doors and rear control panel for the air conditioning can be disabled using the safety button in the armrest of the driver's door.



Switching child protection on/off

▶ Press the safety button to switch child protection on and off. The symbol in the safety button lights up if child protection is active.



Controlling rear air-conditioned areas with the front control panel

The Symbol appears on the display. The rear air-conditioned areas can be controlled from the front control panel.

Ending the function

▶ Press button again.

Note on operation

The function is ended automatically 10 seconds after the last settings are made.

Rear seat heating

The rear seats can also be heated in vehicles with four-zone air conditioning.

▶ For further information on the rear seat Please observe the chapter "REAR SEAT HEA-TING IN VEHICLES WITH AN FOUR-ZONE AIR CONDITIONING SYSTEM" on Page 48.



- **A** Continuous opening and closing **B** Setting vent direction

Vents

Opening vents

- ▶ Rotate thumb wheel **A** upward.
- **Closing vents**
- ▶ Rotate thumb wheel **A** downward.

Changing air flow direction

▷ Swivel vent fins **B** in the desired direction.

Note on operation

Fresh air or conditioned fresh air can be delivered from all vents depending on the air distribution setting.

Fresh-air intake

In order to ensure unhindered air intake:

▶ Keep the fresh-air intake between the windshield and the engine compartment lid free from snow, ice and leaves.



Heated Rear Window

The heated rear window is ready for operation when the ignition is on.

Switching on

▶ Press button **B**. Indicator light in button lights up.

Depending on the outside temperature, the heating switches off automatically after approx. 5 to 20 minutes. The heating can be switched back on again by pressing the switch again.

Switching off

Press button **B**. Indicator light in button goes out.



A - "-" button

B - TIMER button

C - ON/OFF button

D - "+" button

Parking Heater

The parking heater features two functions: parking heating and parking ventilation.

The parking heater is ready for use regardless of the ignition key position.

The parking heater is also used as an auxiliary heater. Operation of the parking heater is therefore clearly audible when outside temperatures are low, even if the parking heater has been manually switched off.

! Danger!

Risk of poisoning due to carbon monoxide (CO). The parking heater consumes fuel and emits exhaust fumes. Exposure to such fumes can cause unconsciousness, serious personal injury or death.

- ▷ Switch off the parking heater before refueling.
- ▷ Do not operate the parking heater in enclosed spaces (e.g. a garage).

The parking heater is operated using the following buttons on the front air-conditioning control panel:



Switch parking heater on and off Activate program

TIMER Start programming Call memories



Set ON times Activate heating function

Set ON times

Activate ventilating function

100 Air Conditioning, Parking Heater and Heated Rear Window

Notes on operation

The parking heater runs on fuel, and it therefore cannot be switched on after the reserve warning lights up.

▶ For further information on the fuel reserve warning: Please observe the chapter "FUEL RESERVE WARNING" on Page 142.

The parking heater must be operated at least once per month with the engine cold.

Ignition off: When the parking heater is running, the remaining running time is shown on the display panel.

Operation of the parking heater is clearly audible when outside temperatures are low and the engine is cold.



Switching parking heater on and

Switching on

▶ Press ON/OFF button ₩. The most recently activated parking heating or parking ventilation function is switched on.

Switching off

▶ Press ON/OFF button <u> again.</u>

Note on operation

▶ After switching off the parking heater using ON/OFF button , wait for at least 2 minutes before you press the button again. The combustion chamber is cleaned.



E - Parking ventilation symbol

F - ON time symbol

G - Memory symbol

H - ON time

I - Parking heating symbol

Programming the parking heater

The parking heater has three independent memories for programming the ON times. The ON time, together with the associated parking heating or parking ventilation function, can be programed in each memory.

Complete programming of the parking heater requires definition of the

- Function and
- ON time.

Programming function

- 1. Switch ignition off.
- 2. Press TIMER button on the front air-conditioning control panel. The symbols for the parking heating I or parking ventilation **E** function flash on the display.
- 3. Select function. Press button + for parking heating or button — for parking ventilation.

If no other entry is made within 10 seconds, the display returns to its initial status.

However, the selected function is retained and is activated when the parking heater is next turned

▶ For further information on switching parking heater on and off: Please observe the chapter "SWITCHING PAR-KING HEATER ON AND OFF" on Page 101.

Programming ON times

- 1. Switch ignition off.
- 2. Press TIMER button.
- 3. Select function (parking heating or parking ventilation).
- 4. Select the memory using button **TIMER**. The desired memory can be selected by pressing button **TIMER** several times.
- 5. Set ON time using the + and buttons. Pressing the buttons adjusts the time on a minute-by-minute basis. If the button is kept depressed, the time is adjusted faster. ON times are only valid for 24 hours.
- 6. Press ON/OFF button Displays **F** and **G** flash for approx. 10 seconds. Flashing of the displays can be ended before this time has elapsed by pressing the ON/OFF button *ill* again.

After ON/OFF button we has been pressed ON time H, clock symbol F and memory G are displayed for 2 minutes.

The display then goes out.

The parking heater has now been programed and the selected memory is active (symbol G is lit).

Note on operation

Only **one** memory can be active at any one time.

Activating the memory

The parking heater runs for 30 minutes. It then switches itself off automatically.

The program must be reactivated for every subseauent run.

To do this:

- 1. Switch ignition off.
- 2. Press button TIMER.
- 3. Select function (parking heating or parking ventilation).
- 4. Select the memory using button TIMER. The ON time that was last saved is displayed.
- 5. Press ON/OFF button The program is reactivated. Displays F and G flash for approx. 10 seconds. The ON/OFF button we can be pressed again to switch off the displays before this time has

elapsed. After the ON/OFF button www has been pressed, the ON time H, clock symbol F and memory **G** are displayed for 2 minutes.

The display then goes out.

The parking heater has now been programed and the selected memory is active (symbol G is lit).

Note on operation

Only **one** memory can be active at any one time.

Example:

The parking heater is to activate the parking heating function at 9:48 a.m. To do this:

- 1. Switch ignition off.
- 2. Press button **TIMER** on the front air-conditioning control panel.

The symbols for the parking heating or parking ventilation function flash on the display.

- 3. Press button +. This selects the parking heating function.
- 4. Select the memory using button **TIMER**.
- 5. Set ON time to 9:48 a.m. using the and **—** buttons.
- 6. Press ON/OFF button The parking heater has now been programed and the selected memory is active.

Note on operation

If the parking heater is switched on manually prior to program start of an active memory, this will delete the programming.

The memory must be reactivated if it is needed. If the memory is not reactivated, the parking heater will not switch on.

Parking heater faults

Initial start-up following period of nonutilization

If you have not used the parking heater for several weeks, the system may require the parking heater to be switched on several times before it actually "starts up".

▶ Please take a break of approximately 5 minutes between each individual switch-on attempt.

Requirement for initial start-up of the parking heater:

Cold engine.

Have the parking heater checked by an authorized Porsche dealer in the following cases:

- If the parking heater fails to "start-up" after the 3rd switch-on attempt.
- In the event of faults in the parking heater, no function symbol appears on the display – only the remaining running time is shown. The display flashes on briefly and then goes completely dark.
- In the event of a serious accident, the parking heater switches off automatically for safety reasons.

The parking heater is not ready for operation.

- If the temperature rises, the overheating protection switches the parking heater off automatically. The parking heater is not ready for operation.
- The parking heater is switched off automatically if the voltage is too low. The parking heater is temporarily unavailable.

Windows and Sliding Roofs

Power windows	106
Brief overview - sliding/lifting roof	110
Sliding/Lifting Roof	111
Brief overview –	
Panorama roof system	115

Power windows



Risk of injury when the door windows close. This applies especially if the windows are closed with the comfort function.

When this function is in operation the window goes up automatically.

- Make sure that fingers, hands, arms or other body parts are not in the way when the windows close.
- Remove the ignition key or switch ignition off in vehicles that have Porsche Entry & Drive to shut off power to the window switches when the vehicle is not attended by a responsible person. Always take the ignition key with you when leaving the vehicle. Uninformed persons could injure themselves by operating the power windows.
- In case of danger, immediately release the car key or the button in the door handle in vehicles that have Porsche Entry & Drive.
- ▷ Do not leave children in the car unattended.

Risk of an accident.

Do not put anything on or near the windows that may interfere with the driver's vision.

Note on operation

Always keep the side windows closed while driving off-road.

106 Windows and Sliding Roofs

Readiness for operation of power windows

- With ignition switched on or
- A maximum of 10 minutes with door closed and ignition key withdrawn, but only until driver's or passenger door is first opened.
 The one-touch operation for closing the door windows is available only when the ignition is switched on.

Opening/closing windows

Opening window with the rocker switch

Press rocker switch until the window has reached the desired position.



- A Power window in driver's door
- B Power window in passenger's door
- C Left rear power window
- D Right rear power window

Note on operation

Rocker switches **A** and **B** in the driver's door have a two-stage function:

- If the switch in question is pressed or pulled to the first level, the front window is opened or closed manually.
- If the switch is completely pressed or pulled to the second level, the front window is opened or closed automatically (one-touch operation).
 Press or pull again to stop the window in the desired position.



Power windows in passenger's door and rear doors

Closing window with the rocker switch

- Pull rocker switch until the window has reached the desired position.

One-touch operation for front windows

▶ Pull or press rocker switch to its final position in the driver's door. Window moves to its final position. Press or pull again to stop the window in the desired position.

Note on operation

If a door window is blocked during closing, it will stop and open again by several centimetres. However, this is **not** the case:

- If the rocker switch is pressed again within 10 seconds of the window being blocked and
- The windows are closed using the vehicle key in the door lock (comfort function).

The windows close with their full closing force.

/ Warning!

Risk of serious personal injury. If the rocker switch is pulled again within 10 seconds of the window being blocked, the window will close with its full closing force.

▶ Take care to ensure that nobody can be injured when the windows close.

One-touch operation is disabled for 10 seconds after the door window is obstructed.



Disabling power windows in the rear doors

The power windows, central locking buttons on the rear doors and the rear control panel for the air conditioning can be disabled by means of the safety button in the armrest of the driver's door.



Switching child protection on/off

▶ Press the safety button to switch child protection on and off.

The symbol in the safety button lights up if child protection is active.



If you unlock the vehicle with the key at the door lock, only the driver's door is unlocked. In order to prevent the alarm system from being triggered, you must switch the ignition on within 15 seconds of opening the door.

On vehicles with and without Porsche Entry & Drive

Opening/closing windows with vehicle key



Danger of injury. The window will close with its full closing force.

- ▶ Take care to ensure that nobody can be injured when the windows close.
- ▶ Hold the car key in the door lock in the unlocking or locking position until the windows have reached the desired position.



On vehicles with Porsche Entry & Drive

Closing windows with button in door handle



Danger of injury. The window will close with its full closing force.

- ▶ Take care to ensure that nobody can be injured when the windows close.
- ▶ Hold the button in the door handle when locking the vehicle until the windows and the Panorama roof system have reached the desired position.

Note on operation

The comfort function remains available for approx. 30 seconds after the vehicle has been locked.

Storing final position of the door windows


The end positions of the door windows are lost when the battery is disconnected and reconnected. The one-touch operation of the windows is disabled.

Perform these procedures for all windows:

- 1. Close window completely once by pulling rocker switch.
- 2. Open window completely again by pressing rocker switch.

Brief overview - sliding/lifting roof

This brief overview does not replace the information provided in the chapter "Sliding/lifting roof". In particular, warnings are not replaced by this brief overview.



Switch in the roof console

What do I want to do?	What do I have to do?	What do I see?	
Opening roof	Turn switch to position C . Or:	Roof opens.	
	Turn switch to position B . (noise-optimised position)		
Lifting roof	Turn switch to position D .	Roof is lifted.	
Close roof	Turn switch to position A.	Roof closes.	

Sliding/Lifting Roof

The electric sliding/lifting roof is made of singlesheet safety glass. It is equipped with a slidingroof cover that can be infinitely adjusted manually to protect against the sun.

The sliding/lifting roof is operated using a knob in the roof console.



Risk of injury when operating or automatically closing the sliding/lifting roof.


- ▶ Take care to ensure that nobody can be injured when the sliding/lifting roof is operated.
- ▷ Always withdraw ignition key when leaving the vehicle or switch ignition off in vehicles that have Porsche Entry & Drive. Always take the ignition key with you when leaving the vehicle. Uninformed persons (e.g. children) could injure themselves by operating the sliding/lifting roof.
- ▷ In case of danger, release the knob or car key immediately and operate the sliding/lifting roof in the opposite direction.
- ▶ Always keep the sliding/lifting roof and the side windows closed while driving off-road.

Readiness for operation of the sliding/ lifting roof

- With ignition switched on.
- With ignition key withdrawn until door is first opened, but only for a maximum of 10 minutes.

Readiness function of the sliding/lifting roof switches off after 10 minutes

If the vehicle is unlocked, the sliding/lifting roof can no longer be operated after 10 minutes (to save the vehicle battery). The power supply is switched back on when the ignition is switched on or the engine started.



- A Closes sliding/lifting roof completely
- **B** Opens sliding/lifting roof to comfort setting
- C Opens sliding/lifting roof completely
- **D** Opens sliding/lifting roof in lift position

Note on operation

Using the automated presetting system, every usable sliding/lifting roof position can be controlled directly with the knob.

A - Closing sliding/lifting roof completely

▶ Turn knob to switch position A.

Note on operation

The sliding/lifting roof is equipped with a force limiter. If the sliding/lifting roof is obstructed during the closing process, the sliding/lifting roof opens again immediately.

Using the force limiter to close the sliding/ lifting roof

- Remove the obstruction.
- ▶ Turn knob to position A again.

B - Opening sliding/lifting roof to comfort setting

▶ Turn knob to switch position **B**.

The sliding/lifting roof opens in switch position **B** until it reaches the best position relative to noise. It can be opened fully, however, if you continue to turn the switch beyond the limit to position **C**.

C - Opening sliding/lifting roof completely

▶ Turn knob beyond stop position **B** to switch position C.

This requires a somewhat greater effort. Once released, the knob rebounds to position B.

D - Lifting sliding/lifting roof

▶ Turn knob between switch positions **A** and **D** until it reaches the required position. The roof is lifted completely in switch position **D**.

Comfort function on vehicles without Porsche Entry & Drive

Closing the sliding/lifting roof

▶ Hold the vehicle key in the door lock in the locking position until the windows and the sliding/lifting roof have reached the desired position.

Comfort function on vehicles with Porsche Entry & Drive

Closing the sliding/lifting roof

- ▶ Hold the car key in the door lock in the locking position until the windows and the sliding/ lifting roof have reached the desired position
- ▶ Hold the button in the door handle when locking the vehicle until the windows and the sliding/lifting roof have reached the desired position.


Emergency operation of sliding/lifting roof

If the sliding/lifting roof is defective, this can be closed or opened manually.


∕!\ Warning!

Risk of serious personal injury and damage to the sliding/lifting roof during emergency operation.


- ▶ Take care to ensure that nobody can be injured when the sliding/lifting roof is operated.
- ▷ During and after emergency operation, the sliding/lifting roof may no longer be operated with the rocker switch.



- 1. Open the glasses case in the roof console (arrow).
- 2. Unclip cover A.



3. Remove key **B** from the lower storage tray (underneath the rubber mat) in the center console.



- 4. Insert the key in opening **C**. This requires a somewhat greater effort.
- 5. Close sliding/lifting roof
 To close the roof turn to the right.
 To open the roof turn to the left.
- 6. Remove the key and return it to the storage tray.
- 7. Clip in cover.
- ▶ Have the fault remedied at an authorized Porsche dealer.

Brief overview – Panorama roof system

This brief overview does not replace the information provided in the chapter "Panorama roof system".

In particular, warnings are not replaced by this brief overview.



Elements of the Panorama roof system

Switch in the roof console

What do I want to do?	What do I have to do?	What do I see?
Open roof completely (roof elements 2 and 3)	Turn switch to position C .	Roof elements 2 and 3 open.
Open roof element 2	Turn switch to position B .	Only roof element 2 opens.
Open roof element 3	Turn switch to position E .	Only roof element 3 opens.
Lift roof element 3	Turn switch to position D .	Only roof element 3 is lifted.
Close roof	Turn switch to position A .	All opened roof elements are closed.


Panorama roof system

The Panorama roof system of your Porsche consists of a total of four roof elements.

Roof element 1 is the draft deflector. This adjusts itself according to the speed, and helps protect from the disturbing effects of the wind when the Panorama roof system is open, especially at high speeds or from turbulent air flow.

Both roof elements 2 and 3 can be moved by activating the knob in the vehicle's longitudinal direction. Roof element 3 can also be raised. This allows the interior to be better ventilated.

Roof element 4 is a fixed glass element and completes the Panorama roof system.



- 1 Draft deflector
- 2 Sliding roof element
- 3 Sliding/lifting roof element
- 4 Fixed glass element

Caution!

Risk of damage when activating the Panorama roof system due to improperly atteched roof elements.

- ▷ Check that the roof elements are securely attached before starting to drive.
- Make sure there is sufficient clearance between the Panorama roof system and the attached roof elements.

Readiness for operation of the Panorama roof system

- With ignition switched on.
- With ignition key withdrawn until door is first opened, but only for a maximum of 10 minutes.

Readiness function of the Panorama roof system switches off after 10 minutes

If the vehicle is unlocked, the Panorama roof system can no longer be operated after 10 minutes (to save the vehicle battery). The power supply is switched back on when the ignition is switched on or the engine started.



- A Close Panorama roof system completely
- **B** Open sliding roof element completely
- C Open Panorama roof system completely
- D Sliding/lifting roof element in lift position
- **E** Open sliding/lifting roof element completely

Note on operation

Using the automated presetting system, every usable roof position can be controlled directly with the knob.

▷ Always keep the Panorama roof system and the side windows closed while driving off-road.

✓!\ Warning!

Risk of injury when operating or automatically closing the Panorama roof system.

- ▶ Take care to ensure that nobody can be injured when the Panorama roof system is operated.
- ▷ Always withdraw ignition key when leaving the vehicle or switch ignition off in vehicles that have Porsche Entry & Drive. Always take the ignition key with you when leaving the vehicle. Uninformed persons (e.g. children) could injure themselves by operating the Panorama roof system.
- ▷ In case of danger, operate the knob in the opposite direction or release the car key immediately.

A - Closes Panorama roof system completely

▶ Turn knob to switch position **A**.

B - Opens sliding roof element completely

▶ Turn knob to switch position **B**. Roof element 2 will be opened completely. The roller blind will open automatically to the selected opening width.

C - Opens Panorama roof system completely

▶ Turn knob beyond the stop position **B** to switch position C.

Roof elements 2 and 3 will be opened completely.

The roller blind will open automatically to the selected opening width.

D - Raises sliding/lifting roof element

Turn knob to switch position **D**. Roof element 3 will be raised completely. The roller blind does not change position here.

E - Opens sliding/lifting roof element completely

- ▶ Turn knob to switch position **E**.
- ▶ **Roof element 3** will be opened completely. The roller blind will open automatically to the selected opening width.

Comfort function on vehicles without Porsche Entry & Drive

Opening and closing the Panorama roof system

▶ Hold the vehicle key in the door lock in the unlocking or locking position until the windows and the Panorama roof system have reached the desired position.

Comfort function on vehicles with Porsche Entry & Drive

Opening and closing the Panorama roof system

▶ Hold the vehicle kev in the door lock in the unlocking or locking position until the windows and the Panorama roof system have reached the desired position.

Closing the Panorama roof system

▶ Hold the button in the door handle when locking the vehicle until the windows and the Panorama roof system have reached the desired position.

Force limiter for the Panorama roof system

All roof elements are equipped with a force limiter. If the sliding roof or the sliding/lifting roof element is obstructed during the closing or opening process, the respective roof element opens or closes again immediately.

Closing a roof element after triggering the force limiter

- Remove the obstruction.
- 2. Turn knob to position A again.

Electric emergency closing function



Risk of injury from the emergency closing function for the Panorama roof system. The force limiter is not available and the roof elements will close with full force.

▶ Take care to ensure that nobody can be injured when the Panorama roof system is closing.

If the roof cannot be closed due to dirt, ice, or similar substances:

- 1. Turn knob to position A.
- 2. Hold the knob in position A until all roof elements are completely closed.

Save final position of the Panorama roof svstem

After disconnecting/reconnecting the vehicle battery or if the vehicle battery is discharged, or after emergency starting with jumper cables, the final positions of the Panorama roof system are lost.



Risk of injury when closing the Panorama roof system. The force limiter is not available and the roof elements will close with full force.

- ▶ Take care to ensure that nobody can be injured when the Panorama roof system is closing.
- 1. Switch ignition off.
- 2. Turn knob to position A.
- 3. Switch ignition on.
- 4. Hold knob in position **A**. The closing process begins after around 5 seconds. Hold the knob in position until the roller blind and all roof elements are completely closed. The procedure lasts approximately 20 seconds.

Note on operation

If the procedure is interrupted, saving the final positions must be started from the beginning.



Roller blind

A roller blind is integrated into the Panorama roof system and can be adjusted by activating the rocker switch in the roof console.

Opening/closing the roller blind

The rocker switch has a two-stage function:

- If the rocker switch is pressed to the first stage, the roller blind opens or closes as long as the rocker switch is being pressed.
- If the rocker switch is pressed completely, the roller blind opens or closes to the final position.

Opening the roller blind

▶ Press rocker switch to the rear **F**.

Closing the roller blind

▶ Press rocker switch to the front **G**.

Note

If the rocker switch is pressed completely while the roof elements are moving, the roller blind opens or closes to the final position after the roof elements have reached the selected position.

Roller blind cleaning position

- 1. Close Panorama roof system and roller blind completely.
- 2. Turn knob to position **C**. The Panorama roof system opens completely.
- 3. When the Panorama roof system has reached the final position, hold the rocker switch G to the front for longer than 3 seconds, until the roller blind is completely closed.
- 4. Remove dirt (e.g., leaves).
- 5. Keep the rocker switch **F** pressed to the rear. until the roller blind is completely closed.
- 6. Close sliding roof element.



Risk of damage if the Panorama roof system and roller blind are in the roller blind cleaning position while driving.

▷ Close the Panorama roof system completely one time before driving off.

Emergency operation of the Panorama roof system


Use emergency operation only under exceptional circumstances if the electric emergency closing function cannot be implemented and the end position cannot be stored.

▷ Before using emergency operation, please check whether the fuse is defective. After the fuse has been changed, the limit positions of the Panorama roof system will have to be stored again.




Danger of injury and risk of damage when closing the roof.

- ▶ Take care to ensure that nobody can be injured when the roof elements are activated.
- ▷ Do not operate the Panorama roof system with the knob during and after emergency operation



- 1. Fold up armrest.
- 2. Remove key B from the lower storage tray (underneath the rubber mat) in the center console.



- 3. Unclip cover.
- 4. Insert the key in opening **H** or **I** until it can be felt and heard to engage.

This requires a somewhat greater effort.

- **H** Emergency operation for the sliding roof element and the draft deflector
- I Emergency operation for the sliding/lifting roof element

Hold the key in this position and turn.
 To close the roof – turn clockwise.
 To open the roof – turn counter-clockwise.

Note on operation

When using emergency closing for the sliding/ lifting roof element, make sure that the roof element is completely closed (center position between sliding and lifting roof position).

- 6. Remove the key and return it to the storage tray.
- 7. Clip in cover.

To rule out malfunctions in the system, the final positions of the Panorama roof system must be saved again after emergency operation.

Please observe the chapter "SAVE FINAL POSITION OF THE PANORAMA ROOF SYSTEM" on Page 118.

Lights, Turn Signals and Windshield Wipers

Light S	Switch	12
Instrun	nent Illumination	12
Autom	atic Headlight Beam Adjustment	12
Turn si	gnal/High Beam/	
Headlig	ght Flasher Stalk	12
Emerg	ency flasher	12
Interior	Lighting	12
Comin	g Home Function (Auto Shut Off Delay) 13
Door-S	urrounding Lighting	13
Brief o	verview – Windshield wipers	13
Windsh	nield Winer/Washer Stalk	13



Light switch with driving light assistant

Light Switch

Light is switched off.

auto Automatic driving light assistant

-0 0€ Side lights

Lincence plate light, instrument illuminati-



Low beam, high beam

Only when the ignition is switched on



Light switch without driving light assistant

Fog lights

Only when side lights or low beam are switched on: Pull switch to first click. Indicator light lights up.



Rear fog light

Pull switch to second click. Indicator light lights up.

Note on operation

If the ignition key is withdrawn and the door is opened while the lights (not the parking light) are on, an acoustic signal (gong) warns of possible battery discharge.

In some countries, differences are possible due to provisions of law.

Automatic driving light assistant

The driving light assistant is a comfort function. Your Porsche's driving light (low beam) is switched on and off automatically, irrespective of the ambient brightness.

Despite possible support by the driving light assistant, it is the responsibility of the driver to switch on the driving light using the conventional light switch in accordance with the relevant national regulations.

Activating the headlights using the driving light assistant does not therefore absolve the driver of responsibility for the correct operation of the driving light.

The low beam is switched on automatically in the following situations:

- Dusk
- Darkness
- Travelling through tunnels
- Rain (in conjunction with the rain sensor)
- Highway driving

Note on operation

Fog is not recognized.

▶ In the event of fog, the driving light must be switched on manually.



Risk of accident due to driving without lights.

▷ Always carefully monitor the automatic driving light control.

Off delay and door-surrounding lighting

Off delay and door-surrounding lighting are active when the automatic driving light assistant is switched on.

- ▶ Please observe the chapter "DOOR-SURROUN-DING LIGHTING" on Page 130.
- ▶ Please observe the chapter "COMING HOME FUNCTION (AUTO SHUT OFF DELAY)" on Page 130.

Highway function

The light is switched on at speeds of over 87 mph (140 km/h). If you are travelling slower than 40 mph (65 km/h), the driving light is switched off after a delay of approx. 2 minutes, if the external lighting conditions permit.

Rain function

The driving light is switched on after five seconds of continuous wiper operation.

The driving light is switched off approx. 4 minutes after the wipers have stopped.



A - Instrument lighting knob



Instrument Illumination

When the light is switched on, the brightness of the instrument illumination can be adjusted by turning thumb wheel A.

Automatic Headlight Beam Adjustment

Vehicles with Bi-Xenon headlights feature automatic headlight beam adjustment.

When the ignition and the low beam are switched on, the level of the headlight beam automatically changes in accordance with the vehicle load. The level of the headlight beam is automatically kept constant during acceleration and braking.

Checking operation

- 1. Switch the low beam on.
- 2. Switch ignition on.

The light beam first dips all the way down and is then adapted to the vehicle load. It this test item is not met, the headlight beam adjustment system must be checked by an authorized Porsche dealer.



Turn signal/High Beam/Headlight Flasher Stalk

Turn signals, low beam and high beam are ready for operation when the ignition is on.

- 1 Turn signal light, left
- 2 Turn signal light, right Move the stalk to the upper or lower pressure

point – turn signals flash three times

- 3 High beam (push forward)
- 4 Headlight flasher (pull backward) Lever in center position - low beam (when the light is switched on)

Note on operation

When the high beam is switched on or the headlight flasher is operated, the blue indicator light on the speedometer is lit.

Parking light

The parking light can only be switched on when the ignition is switched off.

▶ Move the lever up or down to switch on the right or left parking light.



Emergency flasher

The emergency flasher is ready for use regardless of the ignition lock position.

Switching on and off

▶ Press button A to switch on. Press button **A** again to switch off.

All turn signal lights and indicator lights on the dashboard flash when the switch is operated.



Risk of an accident resulting in serious personal injury or death.

- ▶ Whenever stalled or stopped for emergency repairs, move the car well off the road. Switch on the emergency flasher and mark the car with road flares or other warning devices.
- ▷ Do not remain in the car. Someone approaching from the rear may not realize your vehicle is stopped and cause a collision.

Danger of fire.

▷ Do not park or operate the vehicle in areas where the hot exhaust system may come in contact with dry grass, brush, fuel spill or other flammable material.

Hot engine compartment components can burn skin on contact.

▷ Before working on any part in the engine compartment, turn the engine off and let it cool down sufficiently.



A, C- Switch for individual reading lights **B** - Switch for interior light

Interior Lighting

Reading lights, front

Switching on

▶ Press button **A** or **C**.

Switching off

▶ Press button A or C.

Interior light, front

Switching on

▶ Move switch **B** to the left.

Switching on and off automatically

▶ Move switch **B** to the right. The lights are switched on when a door is unlocked or opened or when the ignition key is withdrawn from the ignition lock. The lights are switched off with a delay of approx. 30 seconds after the door is closed. The light goes out immediately as soon as the ignition key is inserted in the ignition lock or the vehicle is locked.

Switching off

▶ Move switch **B** to center position.



Reading lights, rear left

Rear reading lights

Switching on

▶ Move toggle switch forward.

Switching on and off automatically

▶ Move toggle switch to center position. The lights are **switched on** when a door is unlocked or opened or when the ignition key is withdrawn from the ignition lock. The lights are switched off with a delay of approx. 30 seconds after the door is closed. The light goes out immediately as soon as the ignition is switched on or the vehicle is locked.

Switching off 0

▶ Move toggle switch back.



A - Button for dimming the comfort lighting

Comfort Lighting

The footwell and door panel lighting improve your orientation inside the vehicle when it is dark. These lights are switched on when the vehicle is unlocked and switched off again automatically when the vehicle is locked.

Dimming (adjusting the brightness of) the comfort lighting

Once the last door is closed, the footwell and door panel lights are dimmed to the set value.

The comfort lighting is dimmed using button A in the front roof console.

▶ Hold down button **A** until the level of brightness that you require is reached.

Coming Home Function (Auto Shut Off Delay)

The following lights remain switched on for a certain period to allow you to get out of the vehicle safely and with the best possible view at dusk or in darkness:

- Lights in the door mirrors
- Side marker light
- Lincense plate lights.

Note on operation

- ▷ Set light switch to auto.
- ▶ Please observe the chapter "LIGHT SWITCH" on Page 123.

The lights are switched off when the vehicle is locked or, at the latest, after the Coming Home light that has been set on the multi-purpose display has expired.

▶ Please observe the chapter "SETTING LIGH-TING OFF DELAY" on Page 169.

Door-Surrounding Lighting

The door-surrounding lighting enables passengers to enter the vehicle safely. Obstacles on the ground (e.g. puddles) can be identified more

The area in front of the vehicle is illuminated with the following lights when the vehicle is unlocked by remote control or by Porsche Entry & Drive:

- Low beam
- Lights in the door mirrors
- Side marker light
- License plate lights.

Note on operation

- ▷ Set light switch to auto.
- Please observe the chapter "LIGHT SWITCH" on Page 123.

The door-surrounding lighting switches off after the Coming Home light (light that is used during twilight hours) that has been set on the multi-purpose display has expired or when the ignition is switched on.

▶ Please observe the chapter "SETTING LIGH-TING OFF DELAY" on Page 169.

Brief overview – Windshield wipers

This brief overview does not replace the information provided in the chapter "Windshield wiper/ washer stalk".

In particular, warnings are not replaced by this brief overview.





Windshield wiper stalk

Rain sensor rotary switch

What do I want to do?	What do I have to do?
Automatic wiping at front (rain sensor)	Press the stalk to detent position 1.
Rain sensor adjustment	Adjust rotary switch A in the stalk upwards (wipe more often) or downwards (wipe less often).
Wiping at front	Slow: Move the stalk to detent position 2 . Fast: Move the stalk to detent position 3 . Once: Briefly press stalk to position 4 .
Spraying and wiping at front	Pull stalk to position 5 and hold.
Wiping at rear	Normal: Press stalk to position 6 . Once: Briefly move stalk to position 7 .
Spraying and wiping at rear	Keep stalk pressed in position 7 .

Windshield Wiper/Washer Stalk



Danger of injury when the windshield wipers operate unintentionally.

Risk of damage to the engine compartment lid, windshield and wiper system.

- ▷ Only wipe the windshield when sufficiently wet. otherwise it could be scratched.
- ▶ Loosen frozen wiper blades before driving off.
- ▷ Do not operate headlight washer when it is frozen.
- Always switch off windshield wipers in car wash to prevent them wiping unintentionally (rain sensor operation).
- ▷ Do not operate headlight washer in car wash-
- ▷ Always switch off windshield wipers before cleaning the windshield to avoid unintentional operation (rain sensor operation).
- ▷ Always hold the wiper arm securely when replacing the wiper blade.

▷ Always switch the windshield wipers off (position **0**) before opening the engine compartment lid. If the wiper arms are not in end position, they will automatically move to this position when the engine compartment lid is opened. This will happen even if the ignition is

The wiper arms remain in this position until the lid is closed and the wiper system is switched off and then on again.



- 0 Windshield wipers off
- 1 Front windshield wiper rain sensor operation
- ▶ Move wiper stalk upwards to the first click.

Notes on operation

The amount of precipitation which has settled on the windshield is measured. Wiper speed is automatically adjusted accordingly.



The rain sensor remains switched off if the wiper lever is already in position 1 when the ignition is switched on.

To switch the rain sensor on again:

- ▶ Move wiper stalk to position **0** and then to position **1** – switching on is confirmed by one wipe of the windshield - or
- ▷ Operate windshield washer system 5 switching on is confirmed by three wipes of the windshield - or
- ▶ Change the sensitivity of the rain sensor with four-stage switch A.



Changing the sensitivity of the rain sensor

Sensitivity can be set with switch **A** in 4 stages:

- ▶ Adjust rotary switch A upwards high sensitivity. The setting is confirmed by one wipe of the windshield.
- ▷ Adjust rotary switch A downwards low sensitivity.

2 - Front windshield wiper - slow

▶ Move wiper stalk upwards to the second click.

3 - Front windshield wiper - fast

▶ Move wiper stalk upwards to the third click.

At speeds of less than approx. ca. 2.5 mph (4 km/h), rain sensor operation mode is automatically activated if the windshield wiper is switched on. If you exceed a speed of approx. 5 mph (8 km/h), the system switches to the pre-selected wiper level.

4 - Front windshield wiper - one-touch oper-

▶ Move wiper stalk downwards. The front windshield wipers go through one wipe cycle.

5 - Front windshield wipers and washer system

▶ Pull wiper stalk towards the steering wheel. The washer system sprays and wipes while the lever is pulled towards the steering wheel. When the wiper lever is released, a few wipes are executed.

Headlight washer (on vehicles with Bi-Xenon headlights):

The washer sprays only while low beam or high beam is switched on.

To activate the headlight washer system, the wiper lever must be pulled for a longer period of time.

The headlight washer can be re-activated at the earliest after five washing cycles. The spray duration is limited.

Maintenance Note

- ▷ If heavily soiled, repeat wash.
- ▶ Persistent dirt (e.g. insect remains) should be regularly removed. Please observe the chapter "CAR CARE IN-STRUCTIONS" on Page 306.

The front windshield washer nozzles are heated when the ignition is on, as a precaution against freezing. However, this does not replace the use of antifreeze.

6 - Rear window wiper - intermittent operation

▶ Move wiper stalk forwards to the first click. The rear window wiper wipes at preset intervals.

7 - Rear window wiper - one-touch operation

Push wiper stalk forward briefly. The washer system sprays and the rear window wiper goes through three wipe cycles.

Rear window wiper and washer system

▶ Push wiper stalk forwards as far as it will go. The washer system sprays and wipes while the lever is pulled away from the steering wheel. When the wiper lever is released, a few drying wipes are executed.

Maintenance Note

▶ Periodically clean the wiper blades with window cleaner, especially after the vehicle has been washed in a car wash. We recommend the Porsche window cleaner. In the event of heavy soiling (e.g. insect residue), the blades can be cleaned with a sponge or a cloth.

If the wiper blades rub or squeak, this may have the following causes:

If the vehicle is washed in an automatic car wash. wax residues may adhere to the windshield. These wax residues can be removed only by using window cleaner concentrate.

- ▶ Please observe the chapter "WASHER FLUID" on Page 292.
- ▶ Please contact your authorized Porsche dealer for further information.

The wiper blades may be damaged.

▶ Replace wiper blades as soon as possible.

Multi-Purpose Display and Instruments

Ilnstrument Panel USA Models	136	Swite
Instrument Panel Canada Models	138	pass
Oil Temperature Gage	140	and i
Tachometer	140	on th
Cooling System	141	Sync
Fuel Gage	142	Chan
Odometer		and I
Speedometer	143	Setti
Clock	143	Setti
Voltmeter		Setti
Emission Control	145	Chan
Operating the multi-purpose display		Char
on the instrument panel	146	Rese
Displaying/resetting average speed	149	Over
Displaying range on remaining fuel	149	Igniti
Displaying tire pressure	149	Start
Displaying compass		
Displaying navigation information	149	
Opening the main menu	149	
Operating the telephone		
via the multi-purpose display	150	
Setting speed limit		
on the multi-purpose display	152	
Displaying warning messages	153	
Displaying status of level control	154	
Displaying status of locks/reduction	154	
Displaying average consumption	155	
Setting Tire Pressure Monitoring	155	

witching off	
assenger compartment monitoring	
nd inclination sensor	
n the multi-purpose display	165
ynchronous adjustment of door mirrors	166
hanging settings for opening	
nd locking the vehicle	166
etting lighting off delay	169
etting the clock	169
etting compass	170
hanging language for displays	171
hanging units for displays	171
esetting display to factory settings	171
verview of warning messages	172
nition Lock/Steering Lock	180
tarting and Stopping the Engine	182

Instrument Panel USA Models

Warning and indicator lights on the tachometer



Emission Control warning light (Check Engine)



Airbag warning light



Safety belt warning light



PSM warning light



ABS warning light



Cruise control readiness

Indicator lights in central instrument panel

- Turn signal indicator light, left
- Turn signal indicator light, right

Warning and indicator lights on the speedometer



Trailer turn signal Indicator light



Rear fog light indicator light



Tire pressure warning light



Differential locking indicator light



Brake warning light



Fog light indicator light



General warning Observe warning message on the multipurpose display!



High beam indicator light

- A Oil temperature gage
- **B** Tachometer
- C Clock
- D Clock reset button
- E Cooling system temperature gage
- F Multi-purpose display
- G Fuel gage
- H Reset button for trip counter display
- Speedometer
- J Mileage displays
- K Voltmeter



Instrument Panel Canada Models

Warning and indicator lights on the tachometer



Emission Control warning light (Check Engine)



Airbag warning light



Safety belt warning light



PSM warning light



ABS warning light



Cruise control readiness

Indicator lights in central instrument panel

- - Turn signal indicator light, left

Turn signal indicator light, right

Warning and indicator lights on the speedometer



Trailer turn signal Indicator light



Rear fog light indicator light



Tire pressure warning light



Differential locking indicator light



Brake warning light



Fog light indicator light



General warning Observe warning message on the multipurpose display!



High beam indicator light

- A Oil temperature gage
- **B** Tachometer
- C Clock
- D Clock reset button
- E Cooling system temperature gage
- F Multi-purpose display
- G Fuel gage
- H Reset button for trip counter display
- Speedometer
- J Mileage displays
- K Voltmeter





Oil Temperature Gage

A warning message will appear on the multi-purpose display of the instrument panel if the engine oil temperature is too high.

- ▶ Reduce speed and engine load immediately if the red zone is reached.
- ▶ For information on the warning message on the multi-purpose display: Please observe the chapter "OVERVIEW OF WARNING MESSAGES" on Page 172.



Tachometer

The start of the red zone on the tachometer scale is a visual warning of the maximum permissible engine speed.

If the red zone is reached during acceleration, fuel feed is interrupted in order to protect the engine.



Cooling System

▶ If the cooling system is in any way faulty, consult your authorized Porsche dealer.

Temperature gage

USA: Display in °F Canada: Display in °C

Pointer to the left - engine cold

▷ Avoid high engine speeds and heavy engine loading.

Pointer in the middle - normal operating temperature

The pointer may move up to the red area when engine is heavily loaded and outside temperature is high, but should return to "normal" when engine load is reduced.

Engine coolant temperature warning

A warning message will appear on the multi-purpose display of the instrument panel if the engine coolant temperature is too high.

- Switch engine off and let it cool.
- ▶ Check radiator and air passages in front end of car for obstructions.
- Check coolant level. Add coolant if necessary.
- ▶ Please have the fault remedied at an authorized Porsche dealer.
- ▶ For further information on coolant, checking the coolant level and topping up coolant: Please observe the chapter "COOLANT LEVEL" on Page 289.

Note on operation

To prevent excessive temperatures, the cooling air guides must not be restricted by covers (e.g. films, "stone guards").

Engine coolant level warning

A warning message will appear on the multi-purpose display of the instrument panel if the engine coolant level is too low.

- ▷ Switch engine off and let it cool.
- ▶ Top off coolant. Please have the cause of the fault remedied at an authorized Porsche dealer.
- ▶ For further information on coolant, checking the coolant level and topping up coolant: Please observe the chapter "COOLANT LEVEL" on Page 289.
- ▶ For information on the warning message on the multi-purpose display: Please observe the chapter "OVERVIEW OF WARNING MESSAGES" on Page 172.



Risk of engine damage.

- ▷ Do not continue driving if the warning persists even when the engine coolant level is correct.
- ▶ Have the fault remedied at your nearest authorized Porsche dealer.





Fuel Gage

When the ignition is on the fuel level is displayed.

- ▶ For information on fuel quality and filling quan-
 - Please observe the chapter "CAPACITIES" on Page 411.
- ▶ For information on fuel and refueling: Please observe the chapter "REFUELING" on Page 303.
- ▶ If the vehicle's inclination changes (e.g. going uphill/downhill), minor deviations in the indication may occur.



Fuel reserve warning

When the ignition is switched on or the engine is running, the warning light on the multi-purpose display of the instrument panel lights up if less than 3 gallons (12 liters) of fuel remains in the tank or the range on remaining fuel falls below approx. 30 miles (50 km).

▶ Fill up at the next opportunity.



A shortage of fuel may cause damage to the emission control system.

- ▷ Never drive the tank dry.
- ▶ If the warning lights have come on, do not take turns at high speed.
- ▶ For further information on the emission control

Please observe the chapter "HOW EMISSION CONTROL WORKS" on Page 299.



Odometer

The upper display counts the total mileage, the lower display counts the short trips.

After exceeding 6213 miles (9999 kilometers), the short trip counter returns to 0.

Resetting the short trip counter to "O"

▶ Press button **A** for approx. 1 second





Clock **A** is adjusted on the multi-purpose display in the instrument panel:

- ▶ Press button **B**. The SETTINGS > CLOCK menu is automatically opened on the multi-purpose display.
- ▶ For information on setting the clock: Please observe the chapter "SETTING THE CLOCK" on Page 169.

Speedometer

The digital speedometer is integrated on the multipurpose display of the instrument panel.

An analog display is also located on the right next to the multi-purpose display in the instrument panel.

Clock

! Warning!

Risk of loss of control or accident, resulting in serious personal injury or death.

9:48

- ▷ Do not reach through the steering-wheel spokes while driving.
- ▶ In the event of a sudden turn or airbag deployment, serious personal injury could result if hand is positioned through steering wheel spokes.



Voltmeter

The voltmeter indicates the vehicle electrical system voltage.

Normal range: 12 to 16 volts.

The voltage may drop considerably when the vehicle is being started.

If the indicator is continually below 12 volts when the engine is running:

▶ Please have the battery charging system checked at an authorized Porsche dealer.

Battery/alternator

A warning message will appear on the multi-purpose display of the instrument panel if the voltage drops significantly.

- ▶ Stop in a safe place and switch off the engine.
- ▶ For information on the warning message on the multi-purpose display: Please observe the chapter "OVERVIEW OF WARNING MESSAGES" on Page 172.

Possible causes

- Defect in the battery charging system
- Broken drive belt

/ Warning!

Risk of engine damage with resultant loss of control and accident, leading to serious personal injury or death.

A broken drive belt means there is no power assistance to the steering (more effort is required to steer) and engine cooling fails.

- ▷ Do not continue driving.
- ▶ Have the fault remedied at your nearest authorized Porsche dealer.

Danger of steering assistance failing during a long trip in the water if the drive belt slips.

▶ If the steering assistance fails, more effort will be required to steer.

Emission Control



Check engine warning light

The emission control system detects malfunctions early that could, for example, cause increased pollutant emissions or consequential damage. Faults are indicated by a continuously lit or flashing instrument panel warning light. The faults are recorded in the control unit's fault memory.

The warning light in the instrument panel lights up when the ignition is switched on as a bulb check and goes out approx. 4 seconds after the engine starts. If the warning light does not light up, have the bulb replaced promptly.

The warning light in the instrument panel flashes to indicate operating states (e.g. engine misfiring) which might cause damage to certain parts of the emission control system.

- ▷ In this case, immediately reduce the engine load by easing off the accelerator.
- ▷ In order to avoid consequential damage to the engine or emission control system (e.g. catalytic converter), have the fault diagnosed and rectified immediately at the nearest authorized Porsche dealer.

If the warning light in the instrument panel lights up permanently without flashing before and remains on while driving, it suggests:

- a potential engine control problem and the need for system service or
- an improperly fastened tank cap or
- the vehicle was refueled while the engine was running.
- ▶ Stop immediately at a suitable and secure place and check tank cap for proper fastening. If tank cap was fastened correctly, see your authorized Porsche dealer for service as soon as possible.

✓!\ Caution!

If the check engine warning light in the instrument panel is flashing, serious catalytic converter damage and power loss will soon occur.

Prolonged driving with the check engine warning light on could cause damage to the emission control system. It also could affect fuel economy and driveability.

▶ Have the fault remedied at the nearest authorized Porsche dealer immediately.

Operating the multi-purpose display on the instrument panel

On-board computer information can be displayed on the multi-purpose display. Additional functions are also available in the main menu which allow you to change the settings for your vehicle.

/!\Warning!

There is a danger of accident, resulting in serious personal injury or death if you set or operate the multi-purpose display, radio, navigation system, telephone or other equipment while driving. Operating these devices while driving could distract you from traffic and cause you to lose control of the vehicle.

- ▷ Operate these components while driving only if the traffic situation allows you to do so safely.
- ▶ Carry out any complicated operating or setting procedures only with the vehicle stationary.

It is not possible to describe all details of the functions in this Owner's Manual.

The examples clearly demonstrate the functional principle and clarify the menu structure.

Note on operation

Depending on the equipment of your vehicle. some information or functions may not be available on the multi-purpose display (e.g. navigation, audio system, compass or tire pressure)

Various menus can only be called up when the vehicle is stationary.

Note

The multi-purpose display is ready for operation only when the ignition is on.

Note on operation

By selecting the menu items MAIN MENU > SETTINGS > FACTORY SET. vou can reset all individual settings to the basic factory settings.



Operating principle

The multi-purpose display is operated by means of the rocker switch **A** and the ENTER button **B** on the windshield wiper stalk.

Selection or setting

Using the rocker switch A, you can move the bar up and down to select menu items, change between display screens and make settings.

Confirmation

Press the ENTER button **B** to confirm the selected entry. The selected item is then activated.

Operating example: Displaying average consumption

Select items with rocker switch on the wiper stalk in each case and confirm by pressing the ENTER button.



1. MAIN MENU >VEHICLE INFO Select and confirm



2. Select Ø CONSUM.



3. Confirm selection. The average consumption is now displayed.

Returning to starting menu



4. Select BACK.



5. Confirm selection. VEHICLE INFO menu appears.



6. Select BACK.



7. Confirm selection. MAIN MENU menu appears.




8. Select BACK.



9. Confirm selection. Basic display appears.

Menu overview of the multi-purpose display



Displaying/resetting average speed

Displaying average speed

1. Switch ignition on.



2. Select Ø MPH.

The average speed is displayed. The displayed values are based on the distance travelled since the last reset to "zero".

Resetting average speed



3. Select Ø MPH. The average speed is displayed.



4. Press the ENTER button for longer than 1 second. The value is cleared.

Displaying range on remaining fuel

1. Switch ignition on.



2. Select remaining range. The range on remaining fuel is displayed.

The range on remaining fuel is continuously recomputed while driving based on fuel level, current consumption and average consumption.

Displaying tire pressure

This display is available only in conjunction with the Tire Pressure Monitoring option.

1. Switch ignition on.



2. Select TYRE PRESS. The tire pressures are displayed.

The current tire pressures at the actually present levels are displayed in the "Tyre pressure" screen of the on-board computer. These values would be identical to those of a pressure gage connected to the four valves. These pressures change while the vehicle is being driven.

- The tire pressures increase as the temperature in the tires rises, e.g. during high-speed motorway driving.
- The tire pressures decrease as the temperatures drop, e.g. during journeys in cold regions (such as mountains).

The values displayed therefore do not allow conclusions to be drawn about possible pressure deviations.

▶ In order to display pressure deviations from the prescribed pressure, select the menu item TYRE PRESS. in the MAIN MENU.

Displaying compass

This display is available only in conjunction with the Compass or PCM option.

1. Switch ignition on.



2. Select COMPASS. The compass is displayed.

Displaying navigation information

Navigation information can also be displayed on the multi-purpose display.

This display is available only in conjunction with the Navigation (PCM) option.

1. Switch ignition on.



2. Select NAVIGATION. The navigation arrows are displayed.

Opening the main menu

1. Switch ignition on.



2. Select MAIN MENU.



3. Confirm selection. The main menu is displayed.

The main menu contains the following functions:

▶ PHONE MPH-I IMIT VFHICLE INFO TYRE PRESS. SETTINGS

Operating the telephone via the multi-purpose display

Note

The telephone function of the multi-purpose display is linked to both the PCM and the multifunctional buttons on the steering wheel as well as the control stalk.

A SIM card must be inserted in the drawer of the PCM as a prerequisite for telephone operation.

If the link to the network is lost, no PIN is entered, no SIM card is inserted or the telephone is switched off, a corresponding indication will appear.



1. Press the ENTER button. The display reverts to the last menu.

Note

The phone number of an incoming call is shown on the multi-purpose display. The name of the caller is shown only if the caller is stored in the telephone book.

Accepting, refusing, ending a call

Incoming calls are shown on the multi-purpose display (PHONE INFO must be activated).

Display on display screen



1. Select ACCEPT or REFUSE.



2. Confirm selection. After the call is accepted, END appears in the menu.

Ending a call



3. Select END.



4. Confirm selection. The call is ended.



Displaying telephone calls on the multipurpose display

Automatic indication of an incoming call on the multi-purpose display can be switched on or off with the PHONE INFO menu.

- ON Incoming calls are automatically indicated on the multi-purpose display.
- OFF Incoming calls are **not** indicated on the multi-purpose display.



- 1. MAIN MENU
 - > PHONE
 - > PHONE INFO Select and confirm.



2. Select ON or OFF.



3. Confirm selection. The selected item is then accepted.

Displaying last numbers and last-number redial

The LAST NUMBERS menu shows the most recent entries dialled via the respective SIM card.



1. MAIN MENU > PHONE



> LAST NUMBERS Select and confirm.



2. Select entry from the list.




3. Confirm selection. The connection with the selected party is established.

Displaying important numbers and calling

The IMPORTANT NOS. menu shows the entries stored as important numbers on the SIM card.



- 1. MAIN MENU
 - > PHONE





2. Select entry from the list.



3. Confirm selection. The connection with the selected party is established.

Note on operation:

If the rocker switch is pressed for longer than one second, the initial letters for which entries exist are shown.

This allows the desired entry to be found more quickly.

Displaying telephone book, selecting party and calling

The PHONE BOOK menu shows the entries of the telephone book that are stored on the SIM card.



1. MAIN MENU > PHONE



> PHONE BOOK Select and confirm.



2. Select entry from the list.



3. Confirm selection. The connection with the selected party is established.

Note on operation:

If the rocker switch is pressed for longer than one second, the initial letters for which entries exist are shown.

This allows the desired entry to be found more quickly.

Displaying missed calls, calling back party

The telephone numbers of the rejected calls are shown in the MISSED CALLS menu. The numbers are stored on the SIM card.



- 1. MAIN MENU
 - > PHONE
 - > MISSED CALLS Select and confirm.



- 2. Select entry from the list.
- 3. Confirm selection. The connection with the selected party is established.

Note on operation:

If the rocker switch is pressed for longer than one second, the initial letters for which entries exist are shown.

This allows the desired entry to be found more quickly.



Setting speed limit on the multipurpose display

A speed limit can be entered to monitor the driving speed. When it is exceeded, a signal sounds and the multi-purpose display displays the message LIMIT EXCEEDED.

Accepting current speed

You can define the current speed as the speed limit in the menu MPH-LIMIT.



- 1. MAIN MENU >MPH-LIMIT
- Select and confirm



- 2. Select CURRENT MPH.
- 3. Confirm selection. LIMIT ACTIVE is activated automatically and the selected speed limit is shown.



Presetting speed

You can define a speed limit in the menu MPH-LIMIT.



- 1. MAIN MENU >MPH-LIMIT Select and confirm
- 2. Select MPH SET.



3. Set desired limit: - Press briefly: Limit is set in increments of 1 mph (around 1.6 km/h). - Press for longer than 2 seconds: Limit is set in increments of 10 mph (16 km/h).



4. Confirm selection. LIMIT ACTIVE is activated automatically.



Activating or deactivating the limit



1. MAIN MENU >MPH-LIMIT Select and confirm.



2. Select LIMIT ACTIVE.



3. Confirm selection.







4. Select BACK.



5. Confirm selection. Sub-menu MPH-LIMIT is displayed.



Example: Front side light warning message

Displaying warning messages

All current warnings and information relating to the traffic safety of the vehicle can be displayed in the menu WARNINGS.



Warning messages indicate possible faults.

▷ Go to an authorized Porsche dealer immediately.



1. MAIN MENU >VEHICLE INFO Select and confirm.



2. Select WARNINGS.



3. Confirm selection. NO WARNING is displayed if the vehicle is in perfect condition. Any warning messages which are present are displayed.



4. Press repeatedly to display the warnings one after the other.



5. Confirm selection. VEHICLE INFO menu is displayed.



Displaying status of level control

The ground clearance of vehicles equipped with level control is shown in the LEVEL menu.



1. MAIN MENU >VEHICLE INFO Select and confirm.



2. Select LEVEL.



3. Confirm selection. The current level settings are displayed.



4. Confirm selection. VEHICLE INFO menu is displayed.

Note on operation

The level control is adjusted by means of the rocker switch behind the gearshift lever in the center console.

For information on level control and height adjustment:

Please observe the chapter "AIR SUSPENSION WITH LEVEL CONTROL AND HEIGHT ADJUST-MENT" on Page 220.

Displaying status of locks/reduction

The selected driving programs for Low Range/ High Range as well as the engaged locks can be displayed.



1. MAIN MENU >VEHICLE INFO Select and confirm.



2. Select LOCKS/REDUCT.



- **3.** Confirm selection. The current settings for
 - Longitudinal lock on/off
 - Reduction on/off
 - Transverse axle differential lock on/off are displayed.



4. Confirm selection. VEHICLE INFO menu is displayed.



Note on operation

The driving programs are set by means of the rocker switch behind the gearshift lever in the center console.

▶ For information on the programs for Off Road and On Road driving and engaging locks/ reduction:

Please observe the chapter "DRIVING PROGRAMS FOR ON-ROAD AND OFF-ROAD DRIVING" on Page 204.



Displaying average consumption



1. MAIN MENU >VFHICLF INFO Select and confirm.



2. Select Ø CONSUM.



3. Confirm selection. The average consumption is displayed. The displayed value is based on the distance travelled since the last

Resetting average consumption



4. Select RESET.

reset to "zero".



5. Press the ENTER button for longer than 1 second. The value is set to "- -.-".



Setting Tire Pressure Monitoring



Risk of serious personal injury or death. Driving the vehicle with low tire pressure increases risk of a tire failure and resulting loss of control. Furthermore, low tire pressure increases rate of wear of the affected tires.

Despite the advantages offered by Tire Pressure Monitoring, it is not a substitute for proper tire maintenance, and it is still the driver's responsibility to update the settings in the multi-purpose display and maintain the correct tire pressure, even if under-inflation has not reached the level to trigger illumination of Tire Pressure Monitoring low tire pressure message. Low tire pressure reduces the road safety of the vehicle and destroys the tire and wheel.

▶ When a flat tire has been displayed, immediately stop in a suitable place and check the tires for damage. If necessary, remedy the

- damage with tire sealant or fit the spare wheel.
- ▷ Do not by any means continue to drive with leaking tires.
- ▷ Sealing the tire with the tire sealant is only an emergency repair so you can drive to the next authorized Porsche dealer. The maximum permitted speed is **50 mph** (80 km/h).
- ▶ Defective tires must be immediately replaced by an authorized Porsche dealer. Tire repairs are not permissible under any circumstances.
- ▷ Do not drive with tires whose tire pressure drops again in a short period of time. Have tires checked by an authorized Porsche dealer.
- ▶ If Tire Pressure Monitoring is defective (e.g. defective wheel transmitters), contact an authorized Porsche dealer immediately and have the damage repaired. The tire pressure will not be monitored by defective Tire Pressure Monitoring. For information on warning messages on the multi-purpose display: Please observe the chapter "OVERVIEW OF WARNING MESSAGES" on Page 172.
- ▶ Tire Pressure Monitoring gives a warning about tire damage due to insufficient tire pressure as well as about a gradual loss of pressure due to foreign objects. Tire Pressure Monitoring cannot warn you about tire damage that occurs suddenly (e.g. flat tire due to acute external effects).

- ▷ If a tire pressure message is displayed, correct the tire pressure at the next opportunity.
- ▷ Incomplete entries or selection of the wrong tires on the multi-purpose display affect correct indication of warnings and messages. The settings in the TYRE PRESSURE menu must be updated after wheel changes, use of a spare wheel or changes in vehicle loading.
- ▶ Use only the pressure differences shown in the TYRE PRESSURE menu or from tire pressure messages or warnings when correcting the tire pressure.
- ▶ Tires lose air over time without a tire defect being present. A tire pressure warning will then appear on the multi-purpose display. Correct tire pressure.

Functional description of Tire Pressure Monitoring

Tire Pressure Monitoring continuously monitors tire pressure and tire temperature on all four wheels and warns the driver when the tire pressure is too low.

The display as well as the settings for Tire Pressure Monitoring take place on the multipurpose display in the sub-menu TYRE PRESSURE.

However, the tire pressure must still be set manually on the wheel.

The deviations in the tire pressures from the required pressures are shown in the sub-menu TYRE PRESSURE.

Example:

If the tire pressure display shows "-4 psi (-0.3 bar)", you must increase the tire pressure by 4 psi (0.3 bar).

The tire pressures to be monitored are fixed in the Tire Pressure Monitoring system and cannot be changed.

The following settings must be made to permit correct monitoring.

- Tires

Select the type and size of the tires fitted on the vehicle.

- Load

Select the type of loading.

Note on operation

Settings can be made only when the vehicle is stationary.

▶ For information on tires and wheels: Please observe the chapter "TIRES/WHEELS" on Page 317.



Setting the tire type and size



Incomplete entries or selection of the wrong tires on the multi-purpose display affect correct indication of warnings and messages.

- ▶ The settings must be updated in the TYRE PRESSURE menu after changing a wheel, filling with tire sealant or adding air (after previous warning "Flat tyre").
- ▶ Please observe the chapter ""FLAT TYRE" WARNING" on Page 159.


The settings of the multi-purpose display must be updated after changing wheels or tyres on the vehicle.

The tire type **and** tire size must be selected even if the settings for the new set of wheels are the same as for the old wheels.






1. MAIN MENU >TYRE PRESS.





2. Select TYRES.





4. Select tire type (e.g. SUMMER). The list with the possible tire sizes (e.g. for the selection SUMMER) is displayed.



5. Select tire size (e.g. 18 inch).



6. Confirm selection. The current settings are displayed. After driving off, the system starts to teach the wheels and wheel positions on the vehicle. During this time, the tire pressure warning light on the speedometer flashes about 60 seconds and lights up thereafter permanently, and no current tire pressure information is available on the displays.

Note

Information on the tire size and type can be found on the tire sidewall. For further information on the details on the tire sidewall:

▶ Please observe the chapter "INSCRIPTION ON RADIAL TIRE" on Page 327.

Note on operation

Before fitting tires approved by Porsche with a size which is not already stored in the multipurpose display, the missing information should be supplemented in the multi-purpose display.

▶ Go to an authorized Porsche dealer immediately.

/!\ Warning!

Risk of accident due to excessive speed. This could lead to serious personal injury or death.

- ▷ Always observe the permissible maximum speed of the respective tire.
- ▶ Exceeding maximum tire speed could result in a tire burst, causing loss of control of the vehicle. This could lead to serious personal injury or death.
 - Moreover, Porsche recommends obeying all traffic laws at all times to maintain the safety of yourself and all vehicle occupants.

The speed code letter indicates the maximum permissible speed for the tire.

▶ This letter appears on the tire sidewall: Please observe the chapter "INSCRIPTION ON RADIAL TIRE" on Page 327.



Setting vehicle loading and adjusting tire pressure

The tire pressure must be adjusted according to the vehicle load.

A distinction is made between two types of loading:

- Partial load up to 3 people and 46 lbs (21 kg) of luggage
- Full load more than 3 people and 46 lbs (21 kg) of luggage





2. Select LOAD.



3. Confirm selection. The LOAD menu is displayed. Select corresponding load type (e.g. FULL LOAD).



4. Confirm selection. The set load status is shown.

Deviations from the required pressure are shown in the sub-menu MAIN MENU>TYRE PRESSURE>SETTINGS (filling information).

▷ Correct the tire pressure according to this information.



"Flat tyre" warning

The warning threshold for output of this warning message is speed-dependent.

At a speed of below 100 mph (160 km/h), this warning indicates a pressure loss of at least 7 psi (0.5 bar); at a speed of above 100 mph (160 km/h), the warning indicates a pressure loss of at least 6 psi (0.4 bar). The message indicates the wheel in which the pressure loss has been detected. The deviation from the required pressure is displayed for the corresponding wheel. The tire pressure warning light on the speedometer lights up in addition to the warning message. This significant pressure loss is a danger to road safety.

▶ The warning message can be acknowledged while driving. To do this, press the ENTER button on the wiper stalk. The tire pressure warning light on the speedometer remains lit. The measure display SELECTION AFTER WARNING appears only after the ignition is switched back on again.



The display shows: SELECTION AFTER WARNING

- 1. Stop the vehicle immediately in a suitable
- 2. Check the indicated wheel for damage.
- 3. Fill the tire or change the wheel, as appropriate.

- Adding air

(**Example:** If the tire pressure display shows "-7 psi (-0.5 bar)", you must increase the tire pressure by 7 psi (0.5 bar)).

On vehicles without air suspension: Please observe the chapter "CHECKING TIRE PRESSURE WITH A PRESSURE GAGE" on Page 346.

On vehicles with air suspension: Please observe the chapter "INFLATING TIRES." ON VEHICLES WITH AIR SUSPENSION" on Page 348.

or

- Changing wheel with spare wheel or collapsible spare wheel

For information on jacking up the vehicle: Please observe the chapter "LIFTING THE VEHICLE WITH A LIFTING PLATFORM OR GARAGE LIFT" on Page 337.

For information on changing a wheel: Please observe the chapter "LIFTING THE VEHICLE WITH A JACK" on Page 338.

- Sealing with tire sealant.

For information on handling and filling the sealant: Please observe the chapter "TIRF SEALANT" on Page 334.

- 4. Switch ignition on again. The "Flat tyre" warning first appears again on the multi-purpose display. The display changes to SELECTION AFTER WARNING after a few seconds.
- 5. Select the action which has been carried out on the vehicle on the display with the rocker switch.
 - ADD AIR or
 - WHEEL CHANGE > SPARE WHEEL > Spare wheel type or
 - SEALING SET
- 6. Press the ENTER button.

Warning!

Risk of accident, resulting in serious personal injury or death. The spare wheel and collapsible spare wheel are not equipped with wheel transmitters and are not monitored by Tire Pressure Monitoring.

▶ The spare wheel and collapsible spare wheel must be used only over short distances.



Risk of accident resulting in serious personal injury or death if a collapsible spare wheel or tire sealant is in use.

- Avoid hard acceleration and high cornering speeds.
- ▶ Do not exceed maximum speed of 50 mph (80 km/h).
- ▶ Please observe the safety and operating instructions on the tire compressor.
- ▶ Have the tire or wheel replaced by an authorized Porsche dealer as soon as possible.

Note

If a collapsible spare wheel or tire sealant is used. a warning reminder appears on the multi-purpose display if the speed limit of 50 mph (80 km/h) is exceeded.

Note on operation

If you do not confirm a selection or confirm a selection without carrying out the task described for this selection, this will affect correct indication of warnings and messages.

Depending on the selection made, a corresponding message will appear when the ignition is switched on, when driving off or while driving.

For further information on warning messages on the multi-purpose display:

Please observe the chapter "OVERVIEW OF WARNING MESSAGES" on Page 172.



"Tyre pressure too low" message

This message indicates pressure loss of at least 4 psi (0.3 bar).

The message indicates the wheel in which the pressure loss has been detected. The deviation from the required pressure is displayed for the corresponding wheel.

The message appears only when the vehicle is stationary. It appears for the first time when the ignition is switched off and then each time the ignition is switched on until the tire pressure has been corrected to the required value.

The message is shown for 10 seconds on the multi-purpose display. It can be suppressed immediately by pressing the ENTER button.

▷ Check the tire pressure at the next opportunity and fill the tires.

Example: If the tire pressure display shows "-4 psi (-0.3 bar)", you must increase the tire pressure by 4 psi (0.3 bar).

The spare wheel and collapsible spare wheel are not equipped with wheel transmitters and are not monitored by Tire Pressure Monitoring.

Wheel change (without warning)

The settings of the multi-purpose display must be updated after changing wheels or tires on the vehicle.

Please observe the chapter "SETTING THE TIRE TYPE AND SIZE" on Page 157.

Setting spare wheel/sealant (without warning)

If you have fitted a spare wheel or collapsible spare wheel or used tire sealant without being requested to do so by a "Flat tyre" warning on the multi-purpose display, you must subsequently update the settings in the TYRE PRESSURE submenu.

Setting spare wheel.



- 1. MAIN MENU >TYRE PRESS.
 - >SETTINGS
 - > TYRES
 - > SPARE WHEEL Select and confirm.



2. Select SPARE WHEEL.



(filling information).

The required tire pressures are displayed here. Select BACK.



4. Confirm selection. The basic display appears.



The spare wheel is not equipped with a wheel transmitter and is not monitored by Tire Pressure Monitoring. The tire pressure warning light on the speedometer flashes about 60 seconds and lights up thereafter permanently when the ENTER button is pressed. The value "_" is displayed in the submenu TYRE PRESSURE (filling information) at the position of the spare wheel.

The reminder SPARE WHEEL/SEALING SET OPERATION? appears each time the ignition is switched on. For information on spare wheel/ sealing set operation: Please observe the chapter "NOTE ON SPARE WHEEL/SEALING SET OPERA-TION" on Page 163.

Warning!

Risk of accident, resulting in serious personal injury or death. The spare wheel is not equipped with a wheel transmitter and is not monitored by Tire Pressure Monitoring.

▶ The spare wheel must be used only over short distances.

For information on handling and fitting/ removing the spare wheel: Please observe the chapter "SPARE WHEEL" on Page 350.

Setting collapsible spare wheel.



1. MAIN MENU >TYRE PRESS.

>SETTINGS > TYRES

are displayed.

> SPARE WHEEL Select and confirm.



2. Select COLLAP. WHEEL.

3. Confirm selection. The required pressure and speed limit for the collapsible spare wheel

The collapsible spare wheel is not equipped with a wheel transmitter and is not monitored by Tire Pressure Monitoring. The tire pressure warning light on the speedometer flashes about 60 seconds and lights up thereafter permanently when the ENTER button is pressed. The value "_" is displayed in the sub-menu TYRE PRESSURE (filling information) at the position of the collapsible spare wheel.

A warning appears on the multi-purpose display if the speed limit of 50 mph (80 km/h) is exceeded.

The reminder SPARE WHEEL/SEALING SET OPERATION? appears each time the ignition is switched on.

For information on spare wheel/sealing set operation: Please observe the chapter "NOTE ON SPARE WHEEL/SEALING SET OPERATION" on Page 163.

Warning!

Risk of accident, resulting in serious personal injury or death. The collapsible spare wheel is not equipped with a wheel transmitter and is not monitored by Tire Pressure Monitoring.

▶ The collapsible spare wheel must be used only over short distances. For information on handling the collapsible spare wheel: Please observe the chapter "COLLAPSIBLE SPARE WHEEL" on Page 344.

✓!\ Warning!

Risk of accident, resulting in serious personal injury or death if a collapsible spare wheel is in use.

- ▷ Avoid hard acceleration and high cornering speeds.
- ▶ Do not exceed maximum speed of 50 mph (80 km/h).
- ▶ Please observe the safety and operating instructions on the tire compressor.
- an authorized Porsche dealer as soon as possible.

Setting tire sealant/sealing set



1. MAIN MENU



- >SETTINGS > TYRES
 - > SPARE WHEEL Select and confirm.



2. Select SEALING SET.



3. Confirm selection. The display automatically returns to the TYRE PRESSURE sub-menu (filling information).

▶ Inflate tires according to the displayed pressure differences.

A warning appears on the multi-purpose display if the speed limit of 50 mph (80 km/h) is exceeded.

The reminder SPARE WHEEL/SEALING SET OPERATION? appears each time the ignition is switched on.

For information on spare wheel/sealing set operation: Please observe the chapter "NOTE ON SPARE WHEEL/SEALING SET OPERATION" on Page 163.



Risk of accident, resulting in serious personal injury or death if a tire repaired with tire sealant is in use.

- ▶ Avoid hard acceleration and high cornering speeds.
- ▶ Do not exceed maximum speed of 50 mph (80 km/h).
- ▶ Please observe the safety and operating instructions on the tire compressor.

SEALANT" on Page 334.

▶ Use tires repaired with sealant only over short distances. For information on handling and filling the sealant: Please observe the chapter "TIRE

Note on spare wheel/sealing set operation

Each time the ignition is switched on, the reminder SPARE WHEEL/SEALING SET OPERATION? appears for approx. 10 seconds if a spare wheel type (spare wheel, collapsible spare wheel or sealing set) has been set.



- 1. Select YES or NO:
 - YES if a spare wheel, collapsible spare wheel or tire sealant is still being used.
 - NO if the spare wheel, collapsible spare wheel or tire sealant has been removed.



2. Confirm selection.

The selected item is then accepted. The current settings are displayed if NO is selected.



▷ Set the fitted wheel set with tire type and tire

Please observe the chapter "SETTING THE TIRE TYPE AND SIZE" on Page 157.

Note on operation

The reminder SPARE WHEEL/SEALING SET OPERATION? goes out automatically after approx. 10 seconds if no selection is made during this time. The original selection "YES" is then maintained.

Faults in Tire Pressure Monitoring

In the event of faults. Tire Pressure Monitoring cannot monitor the tire pressure. A distinction is made between partial monitoring and inactive system.

In the case of partial monitoring, the tire pressure warning light on the speedometer flashes about 60 seconds and lights up thereafter permanently. **No** message is output on the multi-purpose display.

If Tire Pressure Monitoring is not active, the tire pressure warning light on the speedometer flashes about 60 seconds and lights up thereafter permanently. A corresponding message is output on the multi-purpose display.

The warning light goes out as soon as all faults have been remedied.

Tire Pressure Monitoring switches to partial monitoring if:

 there are up to two wheel transmitters not present or faulty (e.g. a spare wheel or collapsible spare wheel is fitted that does not have a wheel transmitter).

In the event of partial monitoring, the value " " is displayed in the sub-menu TYRE PRESSURE (filling information) at the position of the faulty or missing wheel transmitter.

Tire Pressure Monitoring is not active in the following cases:

Tire Pressure Monitoring is faulty.

- at least three wheel transmitters for Tire Pressure Monitoring are faulty or not present,
- temporarily after changing a wheel,
- too many wheel transmitters have been detected.
- there is external interference by other radio sources, e.g. wireless headphones,
- tire temperatures are too high.

For information on messages on the multi-purpose

Please observe the chapter "OVERVIEW OF WARNING MESSAGES" on Page 172.

Notes on tire pressure

Pressure increase as the result of temperature increase

In accordance with physical principles, the tire pressure changes as the temperature changes. The tire pressure increases or decreases by around 1.5 psi (0.1 bar) for every 18 °F (10 °C) change in temperature.

Tire pressure specifications

The tire pressure must match the prescribed value (required pressure).

You can find information on the tire pressure for cold tires 68 °F (20 °C):

- in the sub-menu TYRE PRESSURE (filling information):

as a required pressure for each axle if Tire Pressure Monitoring has not yet been taught the corresponding values.

- in the front left door aperture for each wheel,
- in the Technical Data chapter in this Owner's Manual: Please observe the chapter "TIRE PRESSURES, COLD" on Page 406.

If Tire Pressure Monitoring has been taught the corresponding values, the deviations from the required pressure are shown in the sub-menu TYRE PRESSURE (filling information) independently of the tire temperature. The correct tire pressure adjustment can be made for a wheel on the basis of this display information even if the tires are warm.

Insufficient tire filling pressure can cause tires to overheat when driving and thus be damaged even invisibly.

Hidden tire damage is not eliminated by subsequently correcting the tire pressure.

- ▶ For this reason, always make sure that the tire pressure is correct.
- ▶ For further information on maintenance and care of tires and wheels: Please observe the chapter "TIRES/WHEELS" on Page 317.

Switching off passenger compartment monitoring and inclination sensor on the multi-purpose display

The passenger compartment monitoring system and the inclination sensor (protection against towing) can be temporarily deactivated in the ALARM sub-menu.

When the doors are locked again, the ultrasound passenger compartment monitoring system and inclination sensor are activated once more. Further important information concerning this topic can be found in a separate chapter:

▶ Please observe the chapter "TEMPORARILY DEACTIVATING PASSENGER COMPARTMENT MONITORING SYSTEM AND INCLINATION SENSOR" on Page 278.

Note on operation

▷ Comfort settings can be made only when the vehicle is stationary.



Switching passenger compartment monitoring on/off

The alarm is triggered if motion is detected in the interior with the doors closed (e.g., if a window is broken in a theft).






2. Select INTERIOR.



3. Confirm selection.



Switching inclination sensor on/off

The alarm is triggered if the vehicle is raised markedly at one end with the doors locked (e.g. theft with a breakdown truck).



1. MAIN MENU

>SETTINGS

> COMFORT > ALARM

Select and confirm.



2. Select ANGLE.

3. Confirm selection. Inclination sensor is activated

Inclination sensor is deactivated



Synchronous adjustment of door mirrors

Note on operation

Comfort settings can be made only when the vehicle is stationary.

When this function is active, the mirrors move simultaneously and in the same direction.



1. MAIN MENU >SETTINGS

> COMFORT

> MIRRORS Select and confirm.



2. Select SYNCH.



3. Confirm selection.

SYNCHRONOUS ADJUSTMENT is activated

SYNCHRONOUS ADJUSTMENT is deactivated

Changing settings for opening and locking the vehicle

Note on operation

Comfort settings can be made only when the vehicle is stationary.

You can set different variants of locking and unlocking the doors and the rear lid as well as the check-back signal when locking and unlocking the vehicle and save them on the respective remote control.

- 1. Using the rocker switch and the ENTER button on the wiper stalk, select MAIN MENU> SETTINGS> COMFORT> DOOR OPFNING
- 2. Set the desired function.
- 3. Switch ignition off.
- 4. Close the driver's door.
- 5. Press button \mathbf{a} on the car key. The settings are now stored on this car key.



Setting door unlocking

Door unlocking can be set on an individual basis.





- **2.** Select one of the three options:
 - SINGLE DOOR

Only the driver's door is unlocked. The door on the access side is unlocked on vehicles equipped with Porsche Entry & Drive.

- VEH. SIDE

Both doors on the driver's side are unlocked.

The doors on the access side are unlocked on vehicles equipped with Porsche Entry & Drive.

- ALL
- All doors are unlocked.



3. Confirm selection.

Note on operation

If the unlocking button of on the remote control is pressed a second time within 2 seconds, all vehicle doors are unlocked, independent of the affected setting.



Setting door opening signal

If the function TURN SIGNALS is active, door unlocking and locking is confirmed by the emergency flashers flashing.

If the function HORN is active, door unlocking and locking is confirmed by an acoustic signal.



- 1. MAIN MENU >SETTINGS
 - > COMFORT
 - > DOOR OPENING
 - > SIGNAL
 - Select and confirm.



- 2. Select TURN SIGNALS or HORN.
- **3.** Confirm selection. Selection is activated.
 - Selection is deactivated.

Setting rear lid locking

When the TAILGATE function is active, rear access (rear lid, rear window and spare wheel bracket) is included in the central locking system.

Access is possible when the vehicle is stationary and unlocked.

At speeds higher than 4 mph (6 km/h), release is blocked until a door is opened with the vehicle stationary.

When the TAILGATE function is deactivated, access is only possible using button on the remote control.



- 1. MAIN MENU
 - >SETTINGS
 - > COMFORT
 - > DOOR OPENING Select and confirm.



- 2. Select TAILGATE.
- 3. Confirm selection.
 - Locking is activated.
 - Locking is deactivated.

Setting AUTO LOCK (automatic door locking) and AUTO UNLOCK (automatic door unlocking)



- MAIN MENU >SFTTINGS
 - > COMFORT
 - > DOOR OPENING
- Select and confirm. 2. Select AUTO LOCK or



- AUTO UNI OCK. 3. Confirm selection.
 - Selection is activated.
 - Selection is deactivated.

AUTO LOCK and AUTO UNLOCK variants

You can set 4 different variants of automatic door locking (AUTO LOCK) and automatic door unlocking (AUTO UNLOCK).

Doors locked using AUTO LOCK can always be opened by pulling the inner door handle twice regardless of the setting for door unlocking.

Option 1: **AUTO LOCK off and AUTO UNLOCK off**

The doors do not lock and unlock automatically.

Option 2: AUTO LOCK on and AUTO UNLOCK off

Doors lock automatically when a speed of approx. 4 mph (6 km/h) is exceeded.

Option 3: AUTO LOCK on and AUTO UNLOCK on

Doors lock automatically when a speed of approx. 4 mph (6 km/h) is exceeded.

On vehicles without Porsche Entry & Drive, the doors are unlocked automatically when the ignition kev is withdrawn.

On vehicles equipped with Porsche Entry & Drive, the doors are unlocked when the ignition is switched off twice.

Option 4: AUTO LOCK off and AUTO UNLOCK on

The doors do not lock automatically.

If the doors are locked with the central locking system button:

On vehicles without Porsche Entry & Drive, the doors are unlocked automatically when the ignition key is withdrawn.

On vehicles equipped with Porsche Entry & Drive, the doors are unlocked when the ignition is switched off twice.



Setting lighting off delay

You can set the duration the lights remain on after the vehicle is locked.



1. MAIN MENU





2. Select OFF DELAY.



3. Confirm selection. The set off delay time is now active.



4. Select the time input field.



5. Confirm selection.



6. Set the off delay time (Coming Home function):

The time is adjusted by pressing the rocker switch. Delay times of 15, 30 or 60 seconds can be set.



7. Confirm selection.



Setting the clock



1. MAIN MENU >SETTINGS



> CLOCK Select and confirm.



2. Select xx:xx SET.



3. Confirm selection.



4. Select hours or minutes display.



5. Confirm selection. The desired time can now be set.



6. Set the desired time: The time is adjusted in hour or minute increments by pressing the rocker switch.



7. Confirm selection.


Selecting 12 h mode




8. Select 12 h-MODE.



9. Confirm selection.






Note on operation

There is also a button on the instrument panel to call the CLOCK menu:

▶ Please observe the chapter "CLOCK" on Page 143.



Setting compass

If you drive your vehicle across the magnetic field zone set on the multi-purpose display, you must enter your current zone in the COMPASS menu (see illustration).



1. MAIN MENU >SETTINGS

> COMPASS

Select and confirm.



2. Select SET ZONE xx.



3. Confirm selection.



4. Select zone. The setting is changed in increments of 1 by pressing the rocker switch.



5. Confirm selection.

Calibrating compass

In rare cases, external disturbances may necessitate calibration of the compass. The warning message "CAL." then appears on the multipurpose display.

▷ To calibrate the compass, follow the displayed instruction DRIVE IN A FULL CIRCLE.

The display returns to the main menu after successful calibration.



Changing language for displays



- 1. MAIN MENU
 - >SETTINGS
- > LANGUAGE Select and confirm.
- 2. Select the desired language.
- **3.** Confirm selection.

Note

Changing the language will affect the entire multipurpose display.

Changing units for displays



- 1. MAIN MENU
- >SETTINGS > UNITS
 - Select and confirm.



2. Select the desired category (e.g. SPEEDOMETER).



3. Confirm selection.



4. Select the desired unit (e.g. MPH).



5. Confirm selection.

Available categories and units

- Speedometer: km/h - km, mph - mls
- Consumption: 1/100 km, km/l, MPG (UK), MPG (US)
- Temperature: °C - CELSIUS, °F - FAHRENHEIT
- Tire pressure: bar, psi



Resetting display to factory settings

All settings made (Clock, Comfort, Lights, Units, Language) can be reset to the factory settings.

Note

All personal settings made up to this point will be deleted by resetting to the factory settings.



- 1. MAIN MENU >SETTINGS
 - > FACTORY SET Select and confirm.
- 2. Select RESET.



3. Confirm selection.

Overview of warning messages

If a warning message appears, always refer to the corresponding chapters in this Owner's Manual. Warning messages are issued only if all measurement preconditions are met. Therefore, check all fluid levels regularly – in particular, always check the engine oil level after refueling.

Light on instrument panel	Warning message on the multi-purpose display		Meaning/measures	
		Steering faulty	Steering lock engaged. Have the fault remedied at an authorized Porsche dealer.	
		Ignition lock faulty	Do not continue driving. Have the fault remedied at an authorized Porsche dealer.	
		System fault	Have the fault remedied at an authorized Porsche dealer.	
		Key not recognised in vehicle	Make sure that you have the remote control with you.	
	(Turn ignition key to the left for 2 seconds	To lock the steering, turn the ignition key to the left and hold for 2 seconds.	
		Key: replace battery	Replace the remote-control battery.	
	\odot	Move steering wheel	Turn the steering wheel so that the steering wheel lock can engage/disengage.	
		Key not found	Make sure that you have the remote control with you.	
		Move selector lever to position P	Tiptronic S: The vehicle could roll away. The ignition key can be withdrawn only in Tiptronic selector lever position P .	
		Press brake pedal	Apply the brake when starting.	
		Move selector lever to position P or N	Tiptronic S: The vehicle can be started only in position P or N .	

Light on instrument panel	Warning message on the multi-purpose display		Meaning/measures
		Depress clutch	Manual transmission: Depress clutch pedal when starting.
		Immobilizer active	Have the fault remedied at an authorized Porsche dealer.
	⊹© ;	Check left static cornering light	Check bulb.
	-; @ ;-	Check right static cornering light	Check bulb.
EO	÷ ⊕ -	Check dynamic cornering light	Have the fault remedied at an authorized Porsche dealer. If the warning message appears, the high beam indicator light on the speedometer flashes additionally.
	÷ © ÷	Check dipped beam	Check bulb.
	- <u>:</u> @-	Check trailer lights	Check bulb.
	- <u>:</u> ∰-	Check direction indicators	Check bulb.
	- <u>:</u> ∰-	Check high beam	Check bulb.
	- <u>:</u> ∰-	Check licence plate light	Check bulb.
	- <u>:</u> @-	Check fog lights	Check bulb.
	- <u>:</u> @-	Check reversing lights	Check bulb.
	÷ @ ÷	Check front side lights	Check bulb.
	(D	Check headlight beam adjustment	Have the fault remedied at an authorized Porsche dealer.
	3	Daytime driving lights off	Daytime driving lights switch off when the engine is shut off. Switch on lights if necessary.

Light on instrument panel	instrument display		Meaning/measures	
	- <u>:</u> @-	System fault headlamp	Have the fault remedied at an authorized Porsche dealer.	
		Check passenger seat setting	Weight sensing is impaired on the passenger's seat (Advanced Airbag). Correct the seating position, set the backrest upright, do not support weight on the armrests, or lift on the handles.	
<u></u>			Airbag faulty. Have the fault remedied at an authorized Porsche dealer.	
<u>*</u>	茶	Seat belt	Fasten seat belt.	
<u>(!)</u>	<u>(!)</u>	Caution flat tyre Check tyres	Tire Pressure Monitoring detects a pressure loss of at least 6 psi (0.4 bar) or a larger leak. Stop in a suitable place and check tires. Change wheel if necessary.	
<u>(!)</u>	<u>(l)</u>	Check spare wheel required pressure: 3.4 bar/50 psi	Appears about every 6 months. Check if the pressure of the mounted spare wheel matches the required pressure manually, as it is not monitored electronically.	
<u>(!)</u>	<u>(l)</u>	Tyre pressure too low Add air	Tire Pressure Monitoring detects a pressure loss of at least 4 psi (0.3 bar). Correct tire pressure at the next opportunity.	
<u>(!)</u>	<u>(!)</u>	Collapsible spare wheel/sealing set max. 50 mph (80 km/h)	Observe maximum permitted speed.	
<u>(!)</u>	(!)	Collapsible spare wheel Required pressure: 3.5 bar/ 51 psi max. 50 mph (80 km/h)	Information on driving with a collapsible spare wheel after selection in spare wheel menu. Observe maximum speed of max. 50 mph or 80 km/h and required pressure of 51 psi or 3.5 bar.	
<u>(!)</u>	(2)	System not active	Tire Pressure Monitoring faulty. Have the fault remedied at an authorized Porsche dealer. Select new set of wheels in the tire pressure menu after changing the wheels.	

Light on instrument panel	Warning message on the multi-purpose display	Meaning/measures
<u>(!)</u>	System not active Brief disturbance	External interference (e.g. wireless headphones) or excessive temperature (over 248 °F/120 °C) at the wheel transmitters. Tire Pressure Monitoring will reactivate itself.
<u>(!</u>)	System not active Too many wheel transmitters	Tire Pressure Monitoring detects more than 4 wheel transmitters (e.g. winter wheels in the luggage compartment) Tire Pressure Monitoring will reactivate itself after the additional wheel transmitters have been removed.
<u>(!)</u>	No monitoring System learning	After the tire type and size are selected in the tire pressure menu, Tire Pressure Monitoring re-learns the tires.
<u>(!)</u>	Wheel change? Make new selection	The tire type and size of the changed tires have not been updated for Tire Pressure Monitoring. The display changes when the vehicle is stationary: Select corresponding tire type and tire size.
<u>(!)</u>	When vehicle stops: Hit selection	The message appears after driving off if the warning "Flat tyre" has been cleared but the selection on the display SELECTION AFTER WARNING has not been made properly. Make selection on the multi-purpose display when the vehicle is stationary.
	Engine temperature too high	Coolant or engine oil temperature is too high. Switch engine off and let it cool. Check coolant or engine oil level. Add coolant or engine oil if necessary.
	Check coolant level	Switch engine off and let it cool. Check coolant level. Add coolant if necessary.
	Warning battery/generator	Stop in a suitable place and switch engine off. Do not continue driving. Have the fault remedied at an authorized Porsche dealer.
	Start engine	The battery discharges if the engine is not running and loads are switched on. Start the vehicle or switch the loads off.

Light on instrument panel	Warning message on the multi-purpose display		Meaning/measures	
		Electric load Switch-off	Vehicle electrical system is overloaded. Certain loads (e.g. heated rear window, seat heating) will be switched off.	
Ö			Stop immediately at a suitable and secure place and check tank cap for proper fastening. If tank cap was fastened correctly, consult your authorized Porsche dealer.	
	6	Please refuel		
	<u> </u>	Add washer fluid		
		Oil level monitoring Failure	Have the fault remedied at an authorized Porsche dealer.	
		Check oil level	Check the oil level using the oil dipstick as soon as possible and add engine oil if necessary.	
	***	Oil pressure too low	Immediately stop in a suitable place and switch engine off. Do not continue driving. Check engine oil level. Add oil if necessary. Do not continue driving if the warning light comes on even when the oil level is correct. Have the fault remedied at an authorized Porsche dealer.	
	***	Oil pressure monitoring Failure	Have the fault remedied at an authorized Porsche dealer.	
		Service in 1864 mls (3000 km)	Service indicator Bring the vehicle in for service no later than after the distance shown has been covered. Please observe the additional informa- tion in the "Maintenance" booklet.	
		Service now	Service indicator Have your vehicle serviced at an authorized Porsche dealer.	
(1)		Brake pads	Have the brake pads replaced at an authorized Porsche dealer.	

Light on instrument panel	Warning message on the multi-purpose display	Meaning/measures
(I)	Warning Brake proportioning	Stop immediately in a suitable place. Do not continue driving. Have the fault remedied at an authorized Porsche dealer.
ABS	ABS failure	Drive carefully. Have the fault remedied at an authorized Porsche dealer.
(A)	PSM failure	Drive carefully. Have the fault remedied at an authorized Porsche dealer.
(I)	Warning Brake fluid level	Stop immediately in a suitable place. Do not continue driving. Have the fault remedied at an authorized Porsche dealer.
(!)	Parking brake	Parking brake not released.
	PSM on	Porsche Stability Management was switched on.
(A)	PSM off	Porsche Stability Management was switched off.
	PHC unavailable	The Porsche Drive-off Assistant (manual transmission) is not available.
(I)	Brake booster faulty	Greater brake pedal force necessary. Drive carefully to the nearest authorized Porsche dealer.
	Chassis sport	Current setting of Porsche Active Suspension Management
	Chassis normal	Current setting of Porsche Active Suspension Management
	Chassis comfort	Current setting of Porsche Active Suspension Management
	Chassis system faulty	Handling may be affected. Adapt your speed to the changed conditions. Have the fault remedied at an authorized Porsche dealer.
	Warning chassis system	The side tilt of the vehicle is significantly greater when cornering. Drive carefully at an appropriate speed to the nearest authorized Porsche dealer.

Light on instrument panel	Warning message on the multi-purpose display		Meaning/measures
	₹	Warning chassis system	Stop at a suitable place. Do not continue driving. Have the fault remedied at an authorized Porsche dealer.
	₹	Chassis system faulty	Drive carefully to the nearest authorized Porsche dealer.
	<u>(!)</u>	Spare wheel filling	Collapsible spare wheel is being filled by level-control compressor. Do not drive off!
	\$	Regulation switched off	Level control has been switched off (to jack up the vehicle).
	ক্	Not permissible	The prerequisites for setting the desired level have not been met.
	\$	Pressure accumulator charging	Level control temporarily unavailable.
Ι	I	Four-wheel drive system faulty	Have the fault remedied at an authorized Porsche dealer.
	I	Shift not possible; Speed too high	Tiptronic S: When changing between Low Range and High Range, the limit speed (Low Range program) must not be exceeded.
	I	Shift only possible in neutral	Tiptronic S: The Tiptronic selector lever must be in position N when changing between Low Range and High Range.
	I	Possible only when stopped in neutral with brake	Manual transmission: The vehicle must be stationary, the brakes must be applied and the gearshift lever must be in the neutral position when changing between Low Range and High Range.
I	I	Warning parking lock! Apply parking brake!	Do not continue driving. Apply the parking brake. Have the fault remedied at an authorized Porsche dealer.
		Failure sport mode	Have the fault remedied at an authorized Porsche dealer.
		Sport mode only usable without reduction	Sport mode cannot be selected when the off-road driving program (Low Range) is engaged.
	<u></u>	Limit exceeded.	The set speed limit has been exceeded.

Light on instrument panel	Warning message on the multi-purpose display	Meaning/measures
	₿	Spare wheel is not locked. Danger of injury and damage. Before driving off always lock the spare wheel correctly.
	•	Driver's door open All unlocked doors and lids are displayed when the vehicle exceeds 2 mph (3 km/h).
	•	Passenger's door open All unlocked doors and lids are displayed when the vehicle exceeds 2 mph (3 km/h).
	!	Rear left door open All unlocked doors and lids are displayed when the vehicle exceeds 2 mph (3 km/h).
	<u>.</u>	Rear right door open All unlocked doors and lids are displayed when the vehicle exceeds 2 mph (3 km/h).
		Hood open All unlocked doors and lids are displayed when the vehicle exceeds 2 mph (3 km/h).
	Ė	Rear lid open. All unlocked doors and lids are displayed when the vehicle exceeds 2 mph (3 km/h).
	i	Rear window open All unlocked doors and lids are displayed when the vehicle exceeds 2 mph (3 km/h).
	System fault	Several systems may have failed. Have the fault remedied at an authorized Porsche dealer.



Ignition lock positions: **0** - Initial position

- 1 Ignition on
- 2 Start engine
- 3 Ignition off

Ignition Lock/Steering Lock

The ignition lock has a total of four ignition lock positions.

Note on operation

The car key rebounds to the initial position from every ignition lock position.



Ignition lock positions with Porsche Entry & Drive:

- **0** Initial position
- 1 Ignition on
- 2 Start engine
- 3 Ignition off

For vehicles that have Porsche Entry & Drive you do not need to insert the key into the ignition lock again but merely keep it with you. The ignition key is replaced by a control unit in the ignition lock, which always remains in the ignition lock, unless the vehicle is being towed.

Removing the control unit from the ignition

▶ Press button **A** and remove the control unit.

Ignition lock position 0

Initial position

The ignition key cannot be withdrawn when the ignition is switched on or when the engine is started.

To withdraw the ignition key:

- ▷ Stop the vehicle.
- **▷** On vehicles with Tiptronic S: Move selector lever to position P.
- ▷ Switch ignition off.
- ▶ Withdraw the ignition key.

Note on operation

The vehicle battery discharges if the ignition key is left inserted.

If the vehicle battery is dead, the key can not be pulled out of the ignition lock.

Ignition lock position 1

Ignition on

▶ Turn ignition key to position 1. Ignition is switched on.

Note on operation

All electrical equipment can be switched on. The warning lights light up for a lamp check.

▶ Please observe the chapter "INSTRUMENT PA-NEL USA MODELS" on Page 136.

If a load is not switched on for 10 minutes after switching on the ignition, the ignition must be switched on again.

Turn the ignition key to ignition lock position 3 (ignition off) first.

Ignition lock position 2

Starting engine

- ▷ Operate footbrake.
- ▶ Fully depress and hold the clutch pedal **or on** vehicles with Tiptronic S: move the selector lever to position **P** or **N**.
- ▷ Do not press the accelerator pedal. The engine control module will provide the correct starting mixture.
- ▶ Turn ignition key to ignition lock position **2**.

- ▷ Do not operate the starter longer than approx. 10 seconds. If necessary, repeat the starting procedure af
 - ter a pause of approx. 10 seconds. Turn the ignition key to ignition lock position 3 (ignition off) first.
- ▷ Do not warm up the engine when stationary. Drive off immediately. Avoid high revolutions and full throttle until the engine has reached operating temperature.
- ▶ If battery output is insufficient, jump leads can be used to start the engine. Please observe the chapter "EMERGENCY STARTING WITH JUMPER CABLES" on Page 372.

Notes on operation

The first operation of the starter is ended automatically when the engine starts. If the engine does not start, subsequent starter operations will not be ended automatically.

When the engine is started, the warning lights must go out.

Ignition lock position 3

Ignition off

▶ Turn ignition key to ignition lock position **3**.

Locking the steering column

Vehicles without Porsche Entry & Drive

The steering column is automatically locked when the ignition key is withdrawn from the ignition lock.

The steering column is automatically unlocked when the ignition key is inserted into the ignition lock.

Vehicles with Porsche Entry & Drive

The steering column is automatically locked when the ignition is switched off and the vehicle is locked.

Manually locking the steering column on vehicles with Porsche Entry & Drive

- ▶ Depress the clutch on vehicles with manual transmission.
- ▷ Once the ignition is switched off, turn the control unit again to ignition lock position 3 and hold it there for 2 seconds.

The steering column is locked.

The steering column is automatically unlocked by turning the control unit from ignition lock position **0**.

Starting and Stopping the Engine

- ▶ Please observe the chapter "IMMOBILIZER" on Page 280.
- ▶ Please observe the chapter "EMISSION CONTROL SYSTEM" on Page 298.



Risk of poisoning. Exhaust gas contains colorless and odorless carbon monoxide (CO), which is toxic even in low concentration. Carbon monoxide can cause unconsciousness and even death if inhaled.

▶ Never start or let the engine run in an enclosed, unventilated area. It is not recommended to sit in your car for prolonged periods with the engine on and the car not moving.

An unattended vehicle with a running engine is potentially hazardous. If warning lights should come on to indicate improper operation, they would go unnoticed.

▶ Never leave the engine idling unattended.

Danger of fire.

- ▶ Do not drive or park your car where combustible materials, such as dry grass or leaves, can come into contact with the hot exhaust system.
- ▶ If your car catches on fire for any reason, call the fire department. Do not endanger your life by attempting to put out the fire.

Starting vehicles with manual transmission

- Operate footbrake.
- ▶ Fully depress and hold the clutch pedal.
- ▶ Put the gearshift lever in neutral.
- ▷ Do not press the accelerator pedal. The engine control module will provide the correct starting mixture.
- ▶ Turn ignition key to ignition lock position 2.
- ▷ Do not operate the starter longer than approx. 10 seconds. If necessary, repeat the starting procedure after a pause of approx. 10 seconds. Turn the ignition key back to ignition lock position 3 first.

The first operation of the starter is ended automatically when the engine starts. If the engine does not start, subsequent starter operations will not be ended automatically.

- ▷ Do not warm up the engine when stationary. Drive off immediately. Avoid high revolutions and full throttle until the engine has reached operating temperature.
- ▶ If battery output is insufficient, jump leads can be used to start the engine.
- ▶ Please observe the chapter "EMERGENCY STARTING WITH JUMPER CABLES" on Page 372.

Note on operation

To ensure a good charge condition for the battery and thus its ability to start the engine, all electrical accessories which are not required should be switched off when the ignition is switched on and when engine revolutions are low (in stop and go traffic).

Starting vehicles with Tiptronic S

- ▷ Operate footbrake.
- ▶ Move selector lever to position P or N.
- ▷ Do not press the accelerator pedal. The engine control module will provide the correct starting mixture.
- ▶ Turn ignition key to ignition lock position 2.
- ▷ Do not operate the starter longer than approx. 10 seconds. If necessary, repeat the starting procedure after a pause of approx. 10 seconds. Turn the ignition key back to ignition lock position 3 first.

The first operation of the starter is ended automatically when the engine starts. If the engine does not start, subsequent starter operations will not be ended automatically.

- ▷ Do not warm up the engine when stationary. Drive off immediately. Avoid high revolutions and full throttle until the engine has reached operating temperature.
- ▶ If battery output is insufficient, iump leads can be used to start the engine. Please observe the chapter "EMERGENCY STARTING WITH JUMPER CABLES" on Page 372.

Note on operation

To ensure a good charge condition for the battery and thus its ability to start the engine, all electrical accessories which are not required should be switched off when the ignition is switched on and when engine revolutions are low (in stop and go traffic).

Stopping

- ▶ Withdraw the ignition key only when the vehicle is stationary, otherwise the steering lock engages and the vehicle cannot be steered.
- ▷ Only switch the ignition off when the vehicle comes to a stop, as there is no steering assistance and brake boost when the engine is switched off.
- ▶ **Always** withdraw the ignition key and engage the parking brake when leaving the vehicle. The control unit always remains in the ignition lock in vehicles that have Porsche Entry & Drive.

Note on operation

The vehicle battery discharges if the ignition key is left inserted.

/!\ Warning!

Danger of injury. Hot engine compartment components can burn skin on contact.

▶ Before working on any part in the engine compartment, turn the engine off and let it cool down sufficiently.

Radiator fans

The radiator and radiator fans are in the front of the car.



Danger of injury. After the ignition is switched off, the engine compartment and coolant temperatures are monitored for approx. 30 minutes. During this period, and depending on temperature, the radiator fan may continue to run or start to run.

Carry out work in these areas only with the engine off and exercise extreme caution.

Driving and Driving Safety

Parking Brake	185
Brakes	186
Brief overview – cruise control	
Cruise Control	191
Manual transmission, clutch	194
Tiptronic S	195
Selector Lever Positions	196
Driving Programs for On-Road	
and Off-Road Driving	204
Power-Transmission	
and Running-Gear Control Systems	210
Air Suspension with Level Control	
and Height Adjustment	220
Porsche Active	
Suspension Management (PASM)	224
Porsche Dynamic	
Chassis Control (PDCC)	225
Off-Road Driving	226



Parking Brake

The parking brake acts on the rear wheels and serves to secure the car while parked.

▶ Use the parking brake only after the vehicle has come to a full stop.

Applying the parking brake

▶ Press down firmly on the foot pedal. The warning light in the instrument panel lights

A message will be displayed on the multi-purpose display of the instrument panel if the parking brake is not released before moving

If the brake is not fully set, the vehicle may roll without control.

▶ Before exiting the vehicle, make sure that the parking brake is fully applied and the vehicle is not moving at all.

! Danger!

Risk of serious personal injury or death. A partially engaged parking brake may allow the vehicle to roll, causing serious personal injury or death to any person in its path.

- ▶ Engage the parking brake fully.
- ▶ Please observe the chapter "OVERVIEW OF WARNING MESSAGES" on Page 172.

Releasing the parking brake

▶ Press on the footbrake and pull handle **A** of the parking brake.

The warning light and the message disappear.





Parking Brake warning light USA





Parking Brake warning light Canada

The warning lights will go out after the parking brake is fully released.

The warning lights are not an indicator that the parking brake is fully applied; it is only intended to be a warning to release the parking brake before driving the car.



A partially engaged brake will overheat the rear brakes, reduce their effectiveness and cause excessive wear.

- ▶ Release the parking brake fully.
- ▶ When parking your car, press down firmly on the foot pedal.
- ▶ Move the selector lever to "P" (Tiptronic) or move the gearshift lever to reverse or first gear (Manual transmission).
- ▷ On hills also turn the front wheels towards the curb.

Brakes

▶ Make it a habit to check the operation of your brakes before driving.

Keep in mind that the braking distance increases very rapidly as the speed increases. At 60 mph (100 km/h), for example, it is not twice but four times longer than 30 mph (50 km/h). Tire traction is also less effective when the roads are wet or slippery.

▶ Therefore, always maintain a safe distance from the car in front of you.

Note

Even though the brake discs consist of alloved grev cast iron, they will unavoidably start to corrode if your car is parked for an extended period. The brakes will tend to "rub" as a result. The nature, extent and effects of corrosion depend on the amount of time the vehicle was parked, whether road salt or grit was spread and whether grease-dissolving agents were used in car washes.

If the braking comfort is noticeably impaired, we recommend having the brake system checked by experts at an authorized Porsche dealer.

Brake system function

Your Porsche is equipped with a power assisted hydraulic dual circuit brake system with disc brakes at the front and rear.

Both circuits function independently. One brake circuit operates the front left and rear right wheel and the other operates the front right and rear left wheel.

If one brake circuit has failed, the other will still operate. However, you will notice an increased pedal travel when you apply the brakes. Failure of one brake circuit will cause the stopping distance to increase.



Risk of an accident. In the unlikely event of hydraulic failure of one brake circuit:

- Push the brake pedal down firmly and hold it in that position. A mechanical linkage activates the second circuit, and you will be able to bring the vehicle to a stop.
- ▶ After bringing your vehicle to a complete stop, avoid driving the vehicle and instead have it towed to the nearest authorized Porsche dealer for repair.



Brake warning light USA



Brake warning light Canada

The warning light in the instrument panel lights up. A message will be displayed on the multi-purpose display of the instrument panel if the brake fluid level is too low, or (if the brake pedal travel has increased) one of the two brake circuits has failed.

A greater braking pressure will be required, stopping distances will be longer and the braking behavior will change, particularly in curves.

With correctly adjusted brakes and a correctly working brake system, the pedal travel to the point of brake application should be 1-3/16 in. to 1-9/16 in. (30 to 40 mm). Whenever the brake pedal travel exceeds this value, have the brake system checked.

Brake pedal



! Warning!

ing possibility.

Risk of an accident. Any obstruction of the brake pedal could increase the stopping distance.

- ▶ Always check the movement of the brake pedal before driving and make sure that it is not obstructed by a floor mat or any other object.
- ▷ Secure the floor mat to prevent it from sliding into positions that could interfere with the safe operation of your vehicle. Your Porsche dealer will be glad to offer you floor mats of the correct size including a secur-

Note

In case one of the two brake circuits fails, increased pedal travel is required to bring your vehicle to a full stop.



To avoid overheating and premature wear of the brakes:

- ▶ Before descending a steep grade, reduce speed and shift the transmission into a lower driving position to control speed.
- ▷ Do not "ride the brakes" by resting your foot on the pedal when not intending to apply brake pressure.
- ▷ Do not hold the pedal down too long or too often. This could cause the brakes to get hot and not function properly.

Brake booster

The brake booster assists braking only when the engine is running.

When the car is moving while the engine is not running, or if the brake booster is defective, more pressure on the brake pedal is required to bring the car to a stop.

Moisture, road salt or grit on brakes affects braking. When the vehicle is driven on salted or gritted roads for extended periods, the brakes should be washed down thoroughly about every 2 weeks. An automatic carwash facility cannot do this job properly. Brakes will dry after a few cautious brake applications.



Driving through water may reduce the traction. Moisture on brakes from road water, car wash, or a coating of road salt or grit may affect braking efficiency.

Cautiously apply brakes to test brakes after being exposed.

Brake wear

Your car has excellent brakes, but they are still subject to wear. The rate at which they wear depends on how the brakes are used.

▶ Have the brake system inspected at the intervals recommended in your Maintenance Booklet.

(\bigcirc)

Brake wear warning message

A warning message will be displayed on the multipurpose display of the instrument panel if the brake pads are worn, excessively.

- ▷ Do not continue to operate the vehicle. Have your authorized Porsche dealer inspect or replace the brake pads.
- ▶ Please observe the chapter "OVERVIEW OF WARNING MESSAGES" on Page 172.

Brake pads and brake discs

Wear on the brake pads and brake discs depends to a great extent on the driving style and the conditions of use and therefore cannot be expressed in actual miles on the road.

The high-performance brake system is designed for optimal braking effect at all speeds and temperatures.

Certain speeds, braking forces and ambient conditions (such as temperature and humidity) therefore might cause the brakes to squeal.

New brake pads or linings

New brake pads have to be "broken in", and therefore only attain optimal friction when the car has covered several hundred miles or km.

The slightly reduced braking ability must be compensated for by pressing the brake pedal harder. This also applies whenever the brake pads and brake discs are replaced.

! Warning!

▷ Do not obstruct the pedal travel with floor mats or other objects.

The brake booster is ready for operation only while the engine is running.

If the engine is switched off or there is a defect in the brake booster, much greater force has to be applied to the pedal when braking.

▶ Please observe the chapter "TOWING" on Page 394.

In heavy rain, while driving through water or after leaving a car wash, the braking action may be delayed and increased pressure may be required.

▶ For this reason, keep further back from the vehicle in front and "dry" the brakes by applying them at intervals. Make sure that following traffic is not affected.

After a long drive over salted or gritted roads, a coating may form on the brake discs and pads that significantly reduces friction and thus braking action.

 ▶ Therefore, clean the brake discs and pads approx. every 2 weeks with a strong jet of water. The cleaning effect of automatic car washes is insufficient.

To prevent corrosion of the brake discs, "brake them dry" before parking the car.

▶ Even though the brake discs consist of alloyed grey cast iron, they will unavoidably start to corrode if your car is parked for an extended period. The brakes will tend to "rub" as a result.

The nature, extent and effects of corrosion depend on the amount of time the vehicle was parked, whether road salt or grit was spread and whether grease-dissolving agents were used in car washes.

If the braking comfort is noticeably impaired, we recommend having the brake system checked by experts at an authorized Porsche dealer.

- ▶ To relieve the braking system on downhill stretches, change down to a lower gear in good time to obtain engine braking. If engine braking is insufficient on steep stretches, operate the footbrake at intervals. Continuous braking overheats the brakes and reduces the braking effect.
- ▶ Please observe the chapter "BRAKE-FLUID LE-VEL" on Page 291.

Brief overview – cruise control

The cruise control maintains any selected speed between approx. 20 and 150 mph (30 and 240 km/h) without you having to use the accelerator.

This brief overview does not replace the information provided in the chapter "Cruise control". In particular, warnings are not replaced by this brief overview.



Cruise-control lever

What do I want to do?	What do I have to do?
Storing and maintaining speed	Pull the lever to detent position 1. Bring the vehicle to the desired speed. Press button A.
Changing stored speed	Acceleration: Press and hold lever in position 3 . Deceleration: Press and hold lever in position 4 .
Switching off cruise control	Move the lever to detent position 2 or operate the footbrake.



A - SET (Store speed)

1 - RESUME - Switch on/resume cruise control readiness (pull toward driver)

2 - OFF - Interrupt (push away from driver)

3 - + SPEED - Accelerate (raise clockwise)

4 - - SPEED - Decelerate (lower counter-clockwise)

Cruise Control

Cruise control maintains any selected speed between 20 and 150 mph (30 and 240 km/h) without you having to use the accelerator.

The cruise control is operated with the operating lever on the steering wheel.

! Warning!

Risk of accident while using cruise control in heavy traffic and consequent personal injury or death, on twisting roads or under unfavorable road conditions (e.g. wintry or wet conditions, varying road surfaces).

- ▷ Do not use the cruise control under such conditions.
- ▷ Observe all local and national speed limits.

Risk of an accident, personal injury and loss of control.

▷ Do not reach through the steering-wheel spokes while driving.

Switching cruise control readiness on

▶ Pull back the operating lever to position **1** until it clicks audibly into place.



Cruise control readiness

The green indicator light on the tachometer now indicates readiness.

Maintaining and storing speed

- ▶ Bring the car to the desired speed with the accelerator.
- ▶ Press button A. The desired speed has now been stored.

Accelerating (e.g. to overtake)

Option 1

▷ Increase the speed as usual with the accelera-

When you ease off the accelerator, the previously stored value is set again.

Option 2

▶ Push operating lever upwards into position 3 until the desired speed is reached. The speed reached is maintained and stored when the operating lever is released.

Option 3

▶ Push operating lever slightly upwards into position 3 (a maximum of 10 times). The speed is increased by 1 mph (2 km/h).

Note on operation

Cruise control operation is automatically interrupted if the speed is increased by more than approx. 16 mph (25 km/h) for longer than 20 seconds.

Decelerating

Option 1

▶ Push operating lever down into position 4 until the desired speed is reached. The speed reached is maintained and stored when the operating lever is released.

Option 2

Push operating lever slightly downwards into position 4 (a maximum of 10 times). The speed is reduced by 1 mph (2 km/h).

Interrupting cruise control operation

The speed driven before the interruption remains stored in the memory and can be reactivated by operating the operating lever. Please observe the chapter "RESUMING THE STORED SPEED" on Page 193.

- Push the operating lever forward to position 2 (it doesn't engage) or
- ▷ Operate brake or clutch pedal or, on vehicles with Tiptronic S, select position N.
- ▶ Please observe the chapter "TIPTRONIC S" on Page 195.

Cruise control operation is interrupted automatically:

- If the set vehicle speed is exceeded by more than approx. 16 mph (25 km/h) for longer than 20 seconds.
- If the actual vehicle speed falls by approx. 6 mph (10 km/h) below the set vehicle speed for longer than 5 seconds (e.g. upward slopes).
- If Porsche Stability Management (PSM) intervenes for longer than 0.2 seconds.
- If Low Range is switched on.



A - SET (Store speed)

1 - RESUME - Switch on/resume cruise control readiness (pull toward driver)

2 - OFF - Interrupt (push away from driver)

3 - + SPEED - Accelerate (raise clockwise)

4 - - SPEED - Decelerate (lower counter-clockwise)

Resuming the stored speed

▶ Pull back the operating lever to position **1**.

Note on operation

The stored speed should only be recalled when traffic conditions and the road surface so permit.

Switching cruise control readiness off

▶ Push forward the operating lever to position **2** until it clicks audibly into place. The memory is cleared and the green readiness light goes out.

When the vehicle is parked and the ignition switched off, the memory is cleared.

Tip on driving

On upward or downward slopes, the set speed cannot always be maintained by cruise control.

▶ To obtain sufficient engine braking or a better engine-speed range, therefore, you have to change down to a lower gear.



Manual transmission, clutch



Risk of accident, resulting in serious personal injury or death.

▶ Do not obstruct the pedal travel with floor mats or other objects.

To avoid damage to the clutch and transmission:

- ▷ Always depress the clutch pedal fully when changing gears. Make sure that the gearshift lever is completely engaged.
- ▷ Only shift into revers when the car has come to a complete stop

Floor mats of the correct size and with the appropriate fasteners are available from your authorized Porsche dealer.

The positions of the gears are shown on the shift diagram on the gearshift lever.

- ▶ When shifting gears, always ensure that the clutch pedal is fully depressed and the gear has fully engaged.
- ▷ Select reverse only when vehicle is stationary.
- ▷ Select an appropriately low gear on upward and downward slopes.

This will ensure optimum use of engine power and engine braking.

When reverse gear is selected and the ignition is on, the reversing lights are lit.

Permitted engine speed

▶ You should change into a higher gear before the needle reaches the red mark on the tachometer, or ease off the accelerator.

If the red zone is reached during acceleration, fuel feed is interrupted.



Risk of engine damage (overrevving) when shifting down to a lower gear.

Take care not to exceed the maximum permitted engine speed when down-shifting.

Tiptronic S

The Porsche Tiptronic is a six-speed transmission and features an "automatic" and a "manual" gearshift mode.

In automatic selection mode (selector lever position **D**), gear changing is automatic. Depending on the driving program, you can change temporarily from automatic to manual mode using the rocker switches on the steering wheel.

In manual selection mode (selector lever position **M**), you change gear using the rocker switches on the steering wheel or by pushing the selector lever forward or back.

You can change between selector lever positions **D** and **M** as you wish while driving.

Note on operation

Take care not to operate the rocker switches on the steering wheel inadvertently, thereby triggering undesired gear changes.



Changing the selector lever position

The selector lever is locked with the ignition key withdrawn.

The selector lever can be moved from position **P** or **N** only with:

- The ignition switched on
- The brake pedal pressed and
- The release button pressed

Release button

The release button (arrow) on the front side of the selector lever prevents unintentional gear chan-

The release button must be pressed when shifting to position R or P.

The selector lever cannot be operated in the event of an electrical fault.

▶ Please observe the chapter "SELECTOR LE-VER EMERGENCY RELEASE" on Page 202.

Starting

The engine can be started only in selector lever position **P** or **N** with the brake pedal pressed.

Moving off

- ▷ Select the desired position for moving off (**D**, **M** or **R**) only when the engine is idling and when depressing the brake pedal.
- ▷ Since the car creeps when in gear, do not release the brake until you want to move off.
- ▶ After selecting a gear, do not accelerate until you can feel that the gear is engaged.



Selector lever position

Indicator for selector lever position and engaged gear

When the engine is running, the selector lever position and engaged gear are indicated.

If there is a fault in the transmission:

- An X appears instead of the current gear indication on the multi-purpose display of the instrument panel.
 - The transmission no longer shifts.
- To remedy the fault, immediately consult an authorized Porsche dealer.

Selector Lever Positions

P - Parking lock

In selector lever position **P**, the driven wheels are mechanically locked.

- ▶ Engage parking lock only when vehicle is stationary.
- ▶ Engage parking lock **after** applying the parking brake and release it **before** releasing the parking brake.
- ▷ Always apply the parking brake before leaving the vehicle.

The ignition key can be withdrawn only in selector lever position **P**.

R - Reverse

▷ Select reverse only if car is stationary and the brake is applied.

N - Neutral

Selector lever position N must be selected for towing or in car washes, for example.

▷ Select the desired position for moving off (D, M or R) only when the engine is idling and when depressing the brake pedal.

D - Automatic selection mode (in the road driving program)

The functions of selector lever positions **D** and **M** differ in the on-road program, High Range, and in the off-road program. Low Range.

▶ Use selector lever position **D** for "normal" dri-

The gears are shifted automatically according to the accelerator position and speed.

Depending on the way the vehicle is driven and on the resistance (e.g. uphill), the gear-changing points are shifted towards higher or lower enginespeed ranges. Movement of the accelerator, driving speed, longitudinal and lateral acceleration and the road profile all have an influence on the gear-changing characteristic.

When PSM is switched off, transmission gear changes are done at higher engine speeds.

Unwanted upward shifts, e.g. before corners, are prevented by swiftly releasing the accelerator pe-

Depending on lateral acceleration, upward changes on corners are not made until the enginespeed limit is reached.

During braking, and depending on the amount of deceleration, the Tiptronic changes down earlier. For subsequent cornering, the right gear is engaged when pressure is applied to the brakes before the corner.

The corner is taken in the right gear, and when you accelerate out of the corner you do not have to change down.

Moving off

In 2nd gear, the vehicle moves off with the throttle only slightly open. Move off in 1st gear with the throttle open wider or when the engine is cold (Cavenne S only).

When PSM is switched off or when Sport mode is switched on, the car generally moves off in 1st gear.

Shifting gear on the steering wheel

By shifting gear with the rocker switches on the steering wheel, you can temporarily change from automatic selection mode **D** to manual selection mode M.

Advantages

- Shifting down before corners and on entering built-up areas.
- Shifting down on downward slopes (engine bra-
- Shifting down for brief spurts of acceleration.
- Selecting 1st or 2nd gear for moving off.

The manual selection mode remains engaged:

- For cornering (depending on the lateral acceleration) and overrunning.
- When the vehicle is stationary (e.g. at a junction).

The system leaves manual selection mode:

- automatically after around 8 seconds (unless car is cornering, overrunning or stationary).
- if you depress the accelerator to kickdown.

Temporary change-down

Precondition

- Speed is higher than approx. 33 mph (54 km/h).
- ▶ Depress accelerator quickly. The Tiptronic changes temporarily to the sportiest gear-changing map, i.e. to the highest possible gear-changing points. Correspondingly, the transmission shifts down immediately by one, two or three gears.

Ending the function

▶ Release the accelerator markedly (by approx. 25%).

Kickdown

The kickdown function is active in selector lever position **D**.

▶ For optimum acceleration, e.g. when overtaking, depress the accelerator pedal beyond the full-throttle point (kickdown).

The transmission shifts down depending on the speed of travel and engine speed.

Upward shifts occur at the highest possible engine

These gear-changing speeds remain active until the accelerator is released to approx. 80% of the full-throttle position.

D - Automatic selection mode (in the offroad driving program)

The functions of selector lever positions **D** and **M** differ in the on-road program, High Range, and in the off-road program, Low Range.

▶ Use selector lever position **D** for "normal" dri-

The gears are shifted automatically according to the accelerator position and speed.

The gears are shifted automatically according to the accelerator position and speed. The gearchanging points have been adjusted to achieve the best possible vehicle control on difficult terrain.

Depending on the route profile, the gear-changing points are shifted towards higher or lower enginespeed ranges. On steep downhill stretches, upward shifts are prevented until medium engine speeds are reached (at least 2.500 rpm).

When the car is overrunning, an automatic upshift does not occur when the engine speed limit is reached.

Moving off

The car moves off in 1st gear.

Shifting gear on the steering wheel

By shifting gear with the rocker switches on the steering wheel, you can temporarily change from automatic selection mode **D** to manual selection mode M.

Advantages

- Shifting down on downward slopes (engine bra-
- Shifting down for brief spurts of acceleration.
- Selecting 1st/2nd or 3rd gear for moving off.

The manual selection mode remains engaged:

- For overrunning
- Depending on lateral acceleration
- When the vehicle is stationary (e.g. at a junction).

The system leaves manual selection mode:

- Automatically after around 8 seconds (unless car is subject to high lateral acceleration, is overrunning or stationary),
- if you depress the accelerator to kickdown.

Kickdown

The kickdown function is active in selector lever position **D**.

▶ For optimum acceleration, e.g. when overtaking, depress the accelerator pedal beyond the full-throttle point (kickdown).

The transmission shifts down depending on the speed of travel and engine speed.

Upward shifts occur at the highest possible engine speeds.

These gear-changing speeds remain active until the accelerator is released to approx. 80% of the full-throttle position.

Tip on driving

Unlike in the on-road driving program, an automatic upshift is **not** performed in manual selection mode **M** when the engine-speed limit is reached.



M - Manual selection mode (in the onroad driving program)

The functions of selector lever positions **D** and **M** differ in the on-road program. High Range, and in the off-road program, Low Range.

The currently selected gear is retained if you change from **D** to **M**.

If you change from **M** to **D**, the gear-changing map suitable for your current driving style is selected and the appropriate gear is selected.

∕!\ Warning!

The kickdown function is not active in manual selection mode "M".

The kickdown function cannot be used to downshift in manual selection mode "M".

ting (e.g. to overtake).

Shifting up

- Press upper part (+) of a rocker switch A or
- ▶ Push selector lever **B** forward in the M gate.

Shifting down

- ▶ Press lower part (–) of a rocker switch A or
- ▶ Push selector lever **B** back in the M gate.

Depending on driving speed and engine speed. you can shift up or down at any time. Gear changes which would exceed the upper or lower engine-speed limit are not executed by the control unit.

You can change down two gears by quickly pressing rocker switches A or selector lever B twice.

If PSM is active and the engine-speed limit is reached, an automatic upward shift is performed or, just before idling speed is reached, a downward shift is performed.

▷ Select an appropriately low gear on upward and downward slopes. This will ensure optimum use of engine power and engine braking.

If manual mode fails, the control electronics switch to automatic mode.

In this event, the instrument panel will display selector lever position **D**.

▶ To remedy the fault, please consult an authorized Porsche dealer.

M - Manual selection mode (in the offroad driving program)

The functions of selector lever positions **D** and **M** differ in the on-road program, High Range, and in the off-road program. Low Range.

The currently selected gear is retained if you change from **D** to **M**.

If you change from **M** to **D**, the gear-changing map suitable for your current driving style is selected and the appropriate gear is selected.



The kickdown function is not active in manual selection mode "M".

The kickdown function cannot be used to downshift in manual selection mode "M".

 ▶ Therefore shift down manually when accelerating (e.g. to overtake).

Tip on driving

The kickdown function is **not** active in selector lever position M.

Unlike in the road driving program, an automatic upshift is **not** performed when the engine-speed limit is reached.

Shifting up

- ▶ Press upper part (+) of a rocker switch A or
- ▶ Push selector lever **B** forward in the M gate.

Shifting down

- ▶ Press lower part (–) of a rocker switch A or
- ▶ Push selector lever **B** back in the M gate.

Depending on driving speed and engine speed. you can shift up or down at any time. Gear changes which would exceed the upper or lower engine-speed limit are not executed by the control unit.

You can change down two gears by quickly pressing rocker switches A or selector lever B twice.

The gear is changed down automatically just before idle speed is reached.

- ▷ Select an appropriately low gear on upward and downward slopes. This will ensure optimum use of engine power
 - and engine braking.

If manual mode fails, the control electronics switch to automatic mode. In this event, the instrument panel will display selector lever position **D**.

 ▶ To remedy the fault, please consult an authorized Porsche dealer.

Stopping

- ▶ For a brief stop (e.g. at a traffic light), leave the selector lever in drive position and hold the vehicle with the brake pedal.
- ▷ Do not hold the car on a slope using the accelerator. Use the brake pedal or the parking brake instead.
- ▶ Before leaving the vehicle, always apply the handbrake and move the selector lever to position **P**.

Tip on driving

In selector lever positions **D** and **M**, the hillholder function makes it easier to move off from a standstill on an upward slope when the engine is running. The driver does not have to apply the brake.

▶ Please observe the chapter "HILLHOLDER -MOVING-OFF ASSISTANT ON VEHICLES WITH TIPTRONIC S" on Page 217.

Parking

- ▶ Go easy on the accelerator.
- ▶ When parking or maneuvring in a small space, control the speed by careful use of the footbra-

Driving in winter

In wintry road conditions it is advisable to take steep inclines in manual mode M. This prevents the occurrence of gear changes that could cause wheelspin.

Reduced driving program

If there is a fault in the transmission:

- An X appears instead of the current gear indicator on the multi-purpose display of the instrument panel.
 - The transmission no longer shifts.
- ▶ To remedy the fault, immediately consult an authorized Porsche dealer.




Reverse gear lock monitoring is disabled in the emergency running program. Damage to the vehicle may result as well as loss of control, if the vehicle is moving forward fast enough to cause rear wheel lockup.

▷ Do not shift into **R** while the vehicle is moving forward.

Tip on driving

3rd or 5th gear in selector position **D** and reverse gear R are now available and will allow you to reach the nearest authorized Porsche dealer.

▶ Please go to your authorized Porsche dealer as soon as possible.




Selector lever emergency release

In the event of an electrical fault, the selector lever lock in position **P** can be manually released (for towing the vehicle, for example).


- 1. Raise center armrest.
- 2. Remove key **B** from the lower oddments tray (underneath the rubber mat) in the center console.



- 3. Undo screws **A** with key **B**.
- 4. Remove trim mounting **F**.
- 5. Lift trim **C** at rear and carefully pull it off.



6. Unplug plug connection **D**.



- 7. Press foam aside.
- 8. Press locking lever **E** aside (to the left) using a suitable object.
- 9. Move selector lever to position **N**.
- 10.Reassemble in reverse order.



Risk of loss of control, resulting in serious personal injury or death.

▶ Ensure that the parking brake of the vehicle is set and that vehicle does not move on its own.



Driving Programs for On-Road and Off-Road Driving

Two different driving programs with special powertransmission and running-gear control systems (such as ABS, off-road ABS and PSM, etc.) are provided in your Porsche, with the aim of realising the best possible driving dynamics combined with maximum safety.

All control systems meet these requirements for both off-road and normal driving.

With rocker switch A, you can easily select the appropriate driving program to suit the special reguirements for the respective terrain.

Off-road program Low Range (with reduction)

When Low Range is active, the power transmission and running-gear control systems are automatically adapted to the requirements for off-road driving.

On-road driving program High Range (without reduction)

When High Range is active, the power-transmission and running-gear control systems are automatically adapted to the requirements for on-road driving.

Use

Rocker switch **A** is located in the center console of the vehicle. It features a multi-step function and can be operated in both directions.

Fach time the rocker switch is pushed forward. the vehicle becomes one step more suitable for off-road driving. This is realized by changing from the on-road to the off-road driving program or by engaging the differential locks in stages. The number of differential locks that can be enga-

ged in Low Range depends on the equipment of vour vehicle.

Each time the rocker switch is pushed back, the vehicle becomes one step more suitable for onroad driving.

Once the driving program has been selected, the rocker switch springs back to home position.

Notes on operation

If the Low Range indicator light beside the rocker switch flashes rapidly after the ignition is swit**ched on**, there is a fault in the shifting system.

▶ Please have the vehicle checked immediately at an authorized Porsche dealer.

Low Range indicator light

If the Low Range indicator light beside the rocker switch flashes when you attempt to operate rocker switch, the conditions for a shift have not been met:

Vehicles with manual transmission

- Vehicle is not stationary.
- Brake is not pressed.
- Gear-shift lever is not in neutral.

Vehicles with Tiptronic S

- Vehicle has exceeded or gone below the limit speed.
- Selector lever is not in position **N**.



A - Rocker switch **B** - Low Range is engaged

Changing from on-road driving program to off-road driving program

Vehicles with manual transmission

- ▷ Stop the vehicle.
- ▶ Apply the brake.
- ▶ Put the gearshift lever in neutral.

Push rocker switch A forward until activation of the off-road driving program is indicated on the multi-purpose display of the instrument panel and by illumination of light-emitting diode B. The Low Range indicator lights in the instrument panel and beside the rocker switch **flash several times** during the shifting process. Low Range is now engaged.

/!\ Caution!

Risk of engine damage (overrevving). In the Low Range program, the gear-changing points are shifted towards lower enginespeed ranges.

▷ Shift early to prevent overrevving the engine.

Tip on driving

When Low Range is active, the power transmission and running-gear control systems are automatically adapted to the requirements for off-road driving.

Vehicles with Tiptronic S

- Reduce speed to below 9.3 mph (15 km/h) or stop vehicle.
- ▶ Move Tiptronic selector lever to position **N**.
- ▶ Push rocker switch **A** forward until activation of the off-road driving program is indicated on the multi-purpose display of the instrument panel and by illumination of light-emitting diode **B**. The Low Range indicator light on the instrument panel and light-emitting diode B beside the rocker switch flash several times during the shifting process.

Low Range is now engaged.

/! \ Danger!

Risk of accident, resulting in serious personal injury or death due to uncontrolled vehicle movement. The Tiptronic selector lever is blocked during the shifting procedure. Shifting when driving uphill can cause the vehicle to stand still or even roll backwards, if the shifting procedure has not yet been completed. When driving downhill, the vehicle can accelerate unintentionally while shifting.

Increased brake readiness is required.



A - Rocker switch

B - Low Range is engaged

C - Center differential lock is fully engaged

Fully engaging the center differential lock in Low Range

Tip on driving

When the center differential lock is fully engaged. there is no longer any speed difference between the front and rear axles. If, for example, both wheels at the front axle lose traction on an icy road or soft surface, the rigidly linked drive wheels will permit the vehicle to continue moving nevertheless.

Push rocker switch A forwards in stages until engagement of the center differential lock is indicated on the multi-purpose display of the instrument panel and by the illumination of the two light-emitting diodes B and C. The center differential lock is changed over to fully engaged state by the automatic control system.



- A Rocker switch
- **B** Low Range is engaged
- C Center differential lock is fully engaged
- D Rear differential lock is fully engaged

Fully engaging the rear differential lock in **Low Range**

Tip on driving

When the rear differential lock is fully engaged, there is no longer any speed difference between the two rear wheels. If, for example, one drive wheel at the rear axle loses traction on an icy road or soft surface, the stiff through-drive function will permit the car to continue moving nevertheless.

Push rocker switch A forwards in stages until engagement of the rear differential lock (transverse lock) is indicated on the multi-purpose display of the instrument panel and by the illumination of the three light-emitting diodes B. C and D.

The center and rear differential locks are changed over to fully engaged state by the automatic control system.

Note on operation

The rear differential lock can only be engaged while the engine is running.

Changing from off-road driving program to on-road driving program

Vehicles with manual transmission

- ▷ Stop the vehicle.
- Apply the brake.
- ▶ Put the gearshift lever in neutral.
- Pull rocker switch A back in stages until lightemitting diodes B, C and if necessary, D are out.

The Low Range indicator light on the instrument panel and light-emitting diode **B** beside the rocker switch flash several times during the shifting process.

High Range is active.

Vehicles with Tiptronic S

- Reduce speed to below 19 mph (30 km/h) or stop vehicle.
- ▶ Move Tiptronic selector lever to position **N**.
- ▶ Pull rocker switch **A** back in stages until lightemitting diodes B, C and if necessary, D are

The Low Range indicator light on the instrument panel and light-emitting diode **B** beside the rocker switch flash several times during the shifting process.

High Range is active.

Danger!

Risk of accident, resulting in serious personal injury or death due to uncontrolled vehicle movement. The Tiptronic selector lever is blocked during the shifting procedure. Shifting when driving uphill can cause the vehicle to stand still or even roll backwards, if the shifting procedure has not vet been completed. When driving downhill, the vehicle can accelerate unintentionally while shifting.

▶ Increased brake readiness is required.



Sport Mode

Function

The sports exhaust system is switched on and a sportier car set-up is obtained when Sport mode is switched on.

Interventions by the Porsche control systems are intentionally shifted towards greater agility and driving performance.

- PASM (Porsche Active Suspension Management) is automatically changed to Sport mode. resulting in a stiffer suspension setup.

- PDCC (Porsche Dynamic Chassis Control) is automatically set to Sport mode, and this further reduces the roll tendency of the vehicle.
- The air suspension automatically changes to the low level setting.
- The Tiptronic S transmission changes to a sportier shift strategy. The gear-changing points are shifted to higher speed ranges. Upward shifts are initiated later, and deceleration shifts are performed earlier. The vehicle moves off in 1st gear.
- The electronic accelerator pedal reacts sooner, and the engine is more responsive to throttle inputs.
- Sporty engine tuning is activated.
- ▶ For further information: Please observe the chapter "PORSCHE ACTIVE SUSPENSION MANAGEMENT (PASM)" on Page 224.
- ▶ Please observe the chapter "PORSCHE DYNA-MIC CHASSIS CONTROL (PDCC)" on Page 225.

Switching Sport mode on and off

Sport mode can be activated when the ignition is switched on and when the on-road driving program High Range (without reduction) is selected.

▶ Press SPORT button **E** in the center console. When Sport mode is switched on, the lightemitting diode **F** in the SPORT button is lit.

When Sport mode is switched on, the logo SPORT appears on the multi-purpose display.

After the ignition is switched off, Sport mode is automatically reset to Normal mode.

Warning messages

A warning appears on the multi-purpose display of the instrument panel in the event of a fault.

▶ For information on warning messages on the multi-purpose display: Please observe the chapter "OVERVIEW OF WARNING MESSAGES" on Page 172.

Vehicles with air suspension

If you wish to use the characteristics of Sport mode and the sports exhaust system, but would like a more comfortable running-gear setup, you can:

- switch PASM and PDCC separately to Normal or Comfort mode and/or
- raise the ride height of the vehicle.
- Press the corresponding PASM button in the center console. The light-emitting diode in the button of the selected running-gear setup lights up.

In addition, the selected running-gear setup is shown on the multi-purpose display of the instrument panel for approx. 12 seconds. Please observe the chapter "PORSCHE ACTIVE SUSPENSION MANAGEMENT (PASM)" on Page 224.

Please observe the chapter "PORSCHE DYNA-MIC CHASSIS CONTROL (PDCC)" on Page 225.

Press the rocker switch in the center console forward. The corresponding light-emitting diode next to the rocker switch lights up continuously after the adjustment process. The level change is also indicated on the multi-purpose display of the instrument panel.

Please observe the chapter "AIR SUSPENSION WITH LEVEL CONTROL AND HEIGHT ADJUST-MENT" on Page 220.

Power-Transmission and Running-Gear Control Systems

A complex interconnection of all control systems acting in power transmission and in the running gear has been realised in your Porsche. All control systems have been linked with the aim of combining the best possible driving performance with maximum safety. The following systems are involved:

System/designation	Scope
PTM Porsche Traction Management	 Full-time all-wheel drive Electronically controlled center differential lock Automatic brake differential (ABD) Traction control system (TCS) Reduction gear/Low Range
PTM Plus Porsche Traction Management	In addition to the PTM features, PTM Plus also includes: - Electronically controlled rear differential lock
PSM Porsche Stability Management	 Stability management system Anti-lock brake system (ABS) Brake system prefilling Brake booster Traction control system (TCS) Automatic brake differential (ABD) Engine drag torque control (MSR)
Air suspension with level control and height adjustment	Fully load bearing air spring struts with integral shock absorbersAir supply system with pressure accumulator
PASM Porsche Active Suspension Management	 Shock absorber system with adaptive, continuous shock absorber control
PDCC Porsche Dynamic Chassis Control	Active chassis control system to stabilise roll tendency of vehicle body when driving

Porsche Traction Management (PTM)

Porsche Traction Management is a full-time allwheel control system designed to influence the longitudinal and lateral dynamics. It is closely linked with the Porsche Stability Management (PSM) system:

PTM ensures the best possible power distribution to the four driven wheels at the front and rear axles. The system realises this optimal traction by intervening in the lock control function of the transfer case and rear differential. PTM is active at all times and, unlike the PSM, cannot be switched off.

Advantages of PTM

- Obvious improvement in traction, driving stability and steering ability of the car.
- Vehicle is more manageable when driven at its performance limits.
- Improved straight-ahead tracking and stability.
- The aforementioned features allow for a sportier setup of the running gear.
- The TCS and ABD provide even better traction for all wheels.

/!∖ Warning!

In spite of the advantages of PTM, it is still the driver's responsibility to adapt her/his driving style and maneuvers in line with road and weather conditions, as well as the traffic situation.

The increased safety that is provided should not induce you to take greater risks with your safety. The limits set by the physics of driving cannot be overcome, even with PTM.

Risks of accident due to inappropriate speed cannot be reduced by PTM.

Full-time all-wheel drive

With the four-wheel drive, the drive power is variably distributed to the front and rear wheels. Power distribution and wheel speed compensation between the front and rear axles is realised with a transfer box.

Distribution of the drive power depends on the wheel speed difference between the two axles. The transfer box always controls power distribution in such a way that optimal propulsion is achieved, even on an unfavorable road surface.

Full-time four-wheel drive ensures optimal handling and great stability.

!\ Warning!

In spite of the advantages of four-wheel drive, it is still the driver's responsibility to adapt her/his driving style and maneuvers in line with road and weather conditions, as well as the traffic situation.

The increased safety that is provided should not induce you to take greater risks with your safety. The limits set by the physics of driving cannot be overcome, even with four-wheel drive.

Risks of accident due to inappropriate speed cannot be reduced by four-wheel drive.

Automatic brake differential (ABD)

The ABD system controls the front and rear axles separately. If one wheel of an axle starts to spin, it is braked so that the other wheel on the same axle can be driven.

The ABD recognizes different driving states, and it features control strategies adapted to these states. In situations in which little propulsive power is required, such as when the car moves off on a level gravel surface, traction control already becomes active at low engine speeds. If great propulsive power is required, e.g. when moving off on an uphill slope or for rapid acceleration, the ABD is adapted accordingly.

A special off-road program is used in Low Range mode.

Traction control system (TCS)

The traction control system prevents the wheels from spinning by adjusting the engine power. thereby ensuring good lane-holding ability and a stable driving behavior.

Porsche Stability Management (PSM)

PSM is an active control system for stabilization of the vehicle during extreme driving maneuvers. It operates together with the Porsche Traction Management (PTM) system.

PSM makes use of both the ABD and TCS systems, as well as the known functions of the antilock brake system (ABS) and engine drag torque control system (MSR).

! Warning!

In spite of the advantages of PSM, it is still the driver's responsibility to adapt her/his driving style and maneuvers in line with road and weather conditions, as well as the traffic situation.

The increased safety that is provided should not induce you to take greater risks with your safety. The limits set by the physics of driving cannot be overcome, even with PSM.

Risks of accident due to inappropriate speed cannot be reduced by PSM.

Advantages of PSM

- Best possible traction and lane-holding ability in all driving situations – even on road surfaces with varying friction.
- The system compensates for undesired vehicle reactions (Ferraria effect) when the driver releases the accelerator pedal or brakes on bends. This compensation functions up to the maximum lateral acceleration.
- PSM actively stabilizes the vehicle as required during dynamic driving maneuvers (e.g. rapid steering movements, during lane changes or on alternating bends).
- Improved braking stability on corners and on different or varying road surfaces.
- Improved brake functioning and reduced stopping distance in the event of emergency braking.

Readiness for operation

PSM is switched on automatically every time you start the engine.

Function

Sensors at the wheels, brakes, steering system and engine continuously measure:

- Driving speed
- Direction of travel (steering angle)
- Lateral acceleration
- Longitudinal acceleration
- Rate of turn about the vertical axis

PSM uses these values to determine the direction of travel desired by the driver.

PSM intervenes and corrects the course if the actual direction of motion deviates from the desired course (steering-wheel position):

It brakes individual wheels as needed. If necessary, PSM additionally influences the engine power or the gear-changing characteristic of the Tiptronic in order to stabilize the vehicle.

The events below inform the driver of PSM control operations and warn him to adapt her/his driving style to the road conditions:

- The multi-functional information light in the instrument panel lights up.
- Light in the PSM Off button flashes.
- Hydraulic noises can be heard.
- The vehicle decelerates and steering-wheel forces are altered as the PSM controls the brakes.
- Reduced engine power.
- The brake pedal pulsates and its position is changed during braking. In order to achieve full vehicle deceleration, foot pressure must be increased after beginning of the brake pedal pulsing.

Examples of PSM control operations

- If the front wheels of the vehicle drift on a corner, engine power is reduced and the rear wheel on the inside of the corner is braked if necessary.
- If the rear of the vehicle swings out on a corner, the front wheel on the outside of the corner is braked.

- Brake system prefilling: The brake system is prepared for possible subsequent emergency braking if the accelerator pedal is released suddenly and quickly.
 - The brake system is prefilled and the brake pads are already applied gently to the brake discs.
- Brake booster:

In the event of an emergency braking operation where the pedal force is insufficient, a brake booster provides the braking pressure necessarv for maximum deceleration at all 4 wheels.

Combined use of PSM and PTM/PTM Plus

In order to ensure optimal stabilization of the vehicle, the center differential lock (PTM) and possibly the rear differential lock (PTM Plus) are also opened when PSM interventions occur.

Tip on driving

When PSM is switched off, wheel-specific brake interventions and the traction control system (TCS) are also inactive.

The automatic brake differential (ABD) remains on.

Off-road PSM (PSM in Low Range program)

When Low Range is active, an off-road PSM specially matched to off-road driving is activated to enhance traction.

In order to improve driveability on difficult terrain, the response of the off-road PSM is less sensitive in the low speed range when the vehicle is operated in the Low Range off-road driving program.

If the brakes are highly stressed, the automatic brake differential (ABD) switches itself off to protect the brakes. It remains deactivated until the brake system has cooled sufficiently.

Engine drag torque control

In conditions of excessive slip, the engine drag torque control system prevents all driven wheels from locking up when the car is overrunning. This is also the case for downshifts on a slippery road.



Switching off PSM

Press PSM OFF button A. PSM is switched off after a short delay. The light-emitting diode in the button is lit up. When the PSM is switched off, the multifunctional PSM light on the instrument panel is lit and a message appears in the multi-purpose display of the instrument panel.

During braking, the vehicle is stabilized even when PSM is switched off.

One-sided spinning of the wheels is prevented. even with PSM switched off.

PSM should always be switched on during "normal" driving.

However, it can be of advantage to switch off PSM temporarily in exceptional situations:

- On a loose surface or in deep snow
- When "rocking the vehicle free"
- When using snow chains.

Vehicles with Tiptronic: When the PSM is switched off the slip monitoring function is also deactivated.

Multifunctional PSM light

- The multifunctional light on the instrument panel lights up for a lamp check when the ignition is switched on.
- The light indicates a control operation, including when PSM is switched off (brake control in the event of one-sided wheel spin).
- In conjunction with the multi-purpose display on the instrument panel, the light indicates that PSM is switched off.
- Faults are displayed by the light in conjunction with the multi-purpose display of the instrument panel. PSM is out of order. Consult your authorized Porsche dealer.

Collapsible spare wheel

▶ Never switch the PSM off when driving with a collapsible spare wheel.

Towing

▶ For information on towing: Please observe the chapter "TOWING" on Page 394.

Tip on driving

When PSM is switched off, wheel-specific brake interventions and the traction control system (TCS) are also inactive.

The automatic brake differential (ABD) remains on.

Switching PSM back on

▶ Press PSM OFF button A. PSM is switched on after a short delay. The light-emitting diode in the button and the multi-functional PSM light on the instrument panel go out. A message is shown on the multipurpose display of the instrument panel.

ABS (Anti-lock Brake System)



In spite of the advantages of ABS, it is still the driver's responsibility to adapt her/his driving style and maneuvers in line with road and weather conditions, as well as the traffic situation.

The increased safety that is provided should not induce you to take greater risks with your safety. The limits set by the physics of driving cannot be overcome, even with ABS.

Risks of accident due to inappropriate speed cannot be reduced by ABS.

ABS ensures:

- Full steering control The vehicle remains steerable
- Good driving stability No skidding due to locked wheels
- Optimum braking distance Shorter stopping distances in most cases
- Lock prevention No flat spots on the tires

Function

The decisive advantage of ABS is in the driving stability and maneuvrability of the vehicle in hazardous situations.

ABS prevents locking of the wheels during full braking, on almost all road surfaces, until shortly before the vehicle stops.

The ABS begins to control the braking process as soon as a wheel shows a tendency to lock. This controlled braking process is comparable to extremely rapid cadence braking.

The pulsating brake pedal and a "rattling noise" warn the driver to adapt her/his driving speed to the road conditions.

▶ If full braking should be necessary, press the brake pedal all the way down throughout the entire braking procedure, regardless of the pulsating pedal. Do not ease up on pressure applied to the pedal.

Warning light

If the ABS warning lights light up in the instrument panel and on the multi-purpose display of the instrument panel while the engine is running, the ABS has switched off because of a fault. In this event, the braking system will operate without lock prevention, as in cars without ABS.

- Adapt your driving style to the changed braking behavior.
- The ABS must be checked immediately at an authorized Porsche dealer. This is necessary in order to prevent the occurrence of further faults whose effects cannot be defined.

The ABS control unit is adjusted for the approved tire dimensions.

The use of tires with non-approved dimensions can lead to different wheel speeds, causing the ABS to switch off.

Off-road ABS (ABS in Low Range program)

When Low Range is active, an ABS specially matched to off-road driving is activated automatically.

In the event of braking on loose ground, the permissible slip values for ABS braking are increased so that the off-road braking distance is reduced (wheels dig into the surface).

If the driver needs to steer, this off-road driving program is automatically switched off to maintain steerability.

Hillholder moving-off assistant on vehicles with **Tiptronic S**

In Tiptronic selector lever positions **D** and **M**, the hillholder function makes it easier to move off from a standstill on an upward slope when the engine is running. The driver does not have to apply the brake.

The hillholder thus makes moving off on slopes easier.



Risk of accident, resulting in serious personal injury or death.

The vehicle can roll backwards if the Hillholder is switched off.

▷ Always apply the footbrake on slopes.

Hillholder is not active:

- In Tiptronic selector lever positions N and R
- In the reduced driving program and
- If not all of the wheels are touching the ground (on difficult terrain, for example).
- ▶ For further information on moving off with the hillholder function on vehicles with Tiptronic S: Please observe the chapter "STOPPING" on Page 201.



In spite of the advantages of the hillholder function, it is still the driver's responsibility to adapt her/his driving style and maneuvers in line with situational conditions.

The increased safety that is provided should not induce you to take greater risks with your safety. The limits set by the physics of driving cannot be overcome, even with the hillholder function. Driving at the limits should be avoided, e.g., on icy slopes or on slippery surfaces. In this and similar cases, the support of the hillholder function is not ensured.

Porsche Drive-Off Assistant -Moving-off assistant on vehicles with manual transmission

The Porsche Drive-Off Assistant enables the driver to move off on upward slopes. The vehicle must have sufficient road contact to use this feature.

The Porsche Drive-Off Assistant is available for slopes starting at approximately 5 %.

▶ Please observe the chapter "TRAILER COUP-LING" on Page 262.



Risk of accident, resulting in serious personal injury or death.

When moving off on a slippery surface (e.g., on icy or loose surfaces), assistance by the Porsche Drive-Off Assistant is no longer assured. In this case, the vehicle could slip. The limits set by the physics of driving cannot be overcome, even with the Porsche Drive-Off Assistant. The responsibility for moving off on upward slopes is still the driver's, despite the Porsche Drive-Off Assistant.

▶ Always adjust your driving style to the driving conditions and vehicle load, use the footbrake if necessary.

Moving off with Porsche Drive-Off Assistant

- 1. Hold the vehicle securely with footbrake or parking brake on the slope. The engine must be running.
- 2. Fully depress the clutch pedal.
- 3. Engage one of the gears used to ascend in the direction of travel (1st gear or reverse).
- 4. While keeping the clutch pedal depressed, release the footbrake or foot-operated parking brake.

The vehicle is held on the slope.

5. Move off as usual.

Note on operation

The Porsche Drive-Off Assistant ceases to func-

- By shifting to neutral.
- When changing gears.
- If the engine is not running.



Risk of accident, resulting in serious personal injury or death.

If the Porsche Drive-Off Assistant ceases to function, the vehicle will no longer be held on a slope.

▶ Hold the vehicle with the footbrake.

Engine Braking Support (Assistance when heading downhill)

The Porsche Down-Hill Assistant is an assistance system which helps the driver at slower downhill driving up to approx. 12 mph (20 km/h), e.g., on steep slopes or on wintry mountain roads.

As long as the gas pedal is not used when traveling downhill, the Porsche Down-Hill Assistant is active and brakes the vehicle.

If road grip is lost on one or more wheels, the system brakes the wheels which have good road contact.

The braking ability of the Engine Braking Support is affected by slippery surfaces (e.g., on icy or loose surfaces), like all brakes.

/!∖ Warning!

Risk of accident, resulting in serious personal injury or death. Reduced braking ability on a slippery surface.

▷ Always adjust your driving style to the driving situation.

Conditions:

- The gas pedal must not be used when travelling downhill.
- The speed must not exceed 12 mph (20 km/h).

Vehicles with Tiptronic S:

The Tiptronic selector lever position **D**, **M** or **R** must be engaged.

- Vehicles with manual transmission:

The reverse gear or any other gear (1. - 6.)must be engaged. The clutch pedal must not be used when travelling downhill.

Tip on driving

The Porsche Down-Hill Assistant is active when driving downhill either forwards or backwards.

Checks on test stands

Power measurement

Power measurements on roller test stands are not approved by Porsche.

Brake tests

Brake tests must be carried out only in High Range and on plate-type test stands or roller test stands.

The following limit values must not be exceeded on roller test stands:

- Testing speed 4.7 mph (7.5 km/h)
- Test duration 20 seconds

Parking brake test

Parking brake tests on the brake tester must be performed only with the ignition switched off and the Tiptronic selector lever in position **N** or the gearshift lever in neutral.

Balancing wheels on the vehicle

During finish balancing of the wheels, the entire vehicle must be lifted and the wheels must be free to

Dynamometer testing procedure

Some U.S. states and Canadian provinces conduct emissions inspection/maintenance testing involving the use of two-wheel dynamometer. A two-wheeled dynamometer is a treadmill type device upon which a single axle of the car, the driving axle of the vehicle, rotates to simulate vehicle operation on the road while the vehicle remains stationary.

Your Porsche Cayenne has a full-time four-wheel drive system which cannot be disabled. Severe damage to the powertrain can result if tested on a two-wheel dynamometer.

Warning!

To avoid severe powertrain damage and a possible unexpected movement of the vehicle.

- ▶ Your Porsche Cayenne vehicle must never be tested on a two-wheel dynamometer.
- ▷ Advise the emission station of this warning before testing the vehicle.



Air Suspension with Level Control and Height Adjustment

On vehicles with air suspension, the driver can set five different level steps manually.

The preselected level is automatically adjusted to suit the vehicle speed.

The height of the car is automatically kept constant when the car is loaded.

Tip on driving

It is not permissible to drive on public roads with the car in the terrain or special terrain setting.

Note on operation

Frequent level changes can cause the compressor to overheat. In this case, the compressor must cool for several minutes before the level adjustment is fully functional again.

Normal level

The ground clearance at normal level is around 8.5 in. (215 mm).

Terrain level

This setting is intended for off-road driving, field paths and forest paths, etc.

The vehicle is raised by around 1 in. (26 mm) compared to normal level.

Terrain level can be selected only manually at speeds below around 50 mph (80 km/h). The car is automatically lowered to normal level at speeds exceeding around 50 mph (80 km/h). The car is automatically raised to terrain level when Low Range is activated.



Special terrain level

This setting is intended only for extremely challenging terrain requiring maximum ground clearance. The vehicle is raised by 2.2 in. (56 mm) compared to normal level.

The warning light in the instrument panel comes on when the special terrain level has been reached.

Special terrain level can be selected only at speeds below around 19 mph (30 km/h).

The car is automatically lowered to terrain level at speeds exceeding around 19 mph (30 km/h).

Low level

This level is intended for high-speed driving. Above speeds of around 78 mph (125 km/h), the car is lowered by around 1 in. (27 mm) compared to normal level.

When the speed drops to below around 25 mph (40 km/h), the car is automatically raised to normal level.

Note

If low level was set with the rocker switch in the center console, low level also remains active at speeds below approx. 25 mph (40 km/h).

Loading level



Risk of damage to running-gear parts, units and the vehicle underbody.

If the car is driven off a curb when at loading level, for example, insufficent ground clearance can cause it to bottom out.

▷ Always switch to normal level before moving off.

This setting makes it easier for you to load the luggage compartment.

The vehicle is lowered by around 2.4 in. (60 mm) compared to normal level.

The car is automatically raised to normal level at speeds exceeding around 3 mph (5 km/h).

Setting level manually

Preconditions

- Ignition on.
- Doors are closed.

Setting

▶ Move rocker switch in the appropriate direc-

This sets the next possible height.

Indication of selected level

The corresponding light-emitting diode beside the rocker switch flashes during the control process. The light-emitting diode is continuously lit after the control process.

The level change is also indicated on the multi-purpose display of the instrument panel.

Exceptions

Automatic changes from normal level to low level and back are not indicated on the multi-purpose display of the instrument panel.

Note on operation

The level selected last is stored in memory after the ignition is switched off.



1st actuation: Off-road level

Raising the vehicle

▶ Press rocker switch A forward once. A message appears on the multi-purpose display on the instrument panel and the yellow light-emitting diode lights up when off-road level is reached.



2nd actuation: Special terrain level

▶ Press rocker switch **A** forward a second time. A message appears on the multi-purpose display on the instrument panel and the yellow and red light-emitting diodes light up when special terrain level is reached.



1st actuation: Low level

Lowering the vehicle

▶ Pull rocker switch A back once. A message appears on the multi-purpose display on the instrument panel and the yellow light-emitting diode lights up when low level is reached.



2nd actuation: Loading level

▶ Pull rocker switch A back a second time. A message appears on the multi-purpose display on the instrument panel and the yellow and red light-emitting diodes light up when loading level is reached.

Warning message

Various messages are indicated on the multi-purpose display of the instrument panel if there is a system fault or if the compressor switches off due to overload.

- ▶ For further information on warning messages on the multi-purpose display: Please observe the chapter "OVERVIEW OF WARNING MESSAGES" on Page 172.
- ▶ Adapt your driving style to the changed conditions.
- Consult an authorized Porsche dealer in order to remedy a system fault.
- ▶ If the overload-protection function causes the compressor to switch off, wait for a time until it has cooled down. The system will function again as soon as it has cooled sufficiently.

The warning message appears when the control system is switched off and when the collapsible spare wheel is being filled. This does not indicate a fault.

The warning message will go out once these procedures have been completed.

Raising vehicle with the iack

Whenever it is necessary to jack up the vehicle:

▶ Manually set normal level and then switch off level control.

Switching off level control

- 1. Switch ignition on.
- 2. Push rocker switch forward for 5 to 10 seconds.

A message is shown on the multi-purpose display of the instrument panel. The vehicle can now be raised.

Switching level control back on

- 1. Switch ignition on.
- 2. Push rocker switch forward for 5 to 10 seconds or
- 3. Drive forward with the vehicle. Level control switches on automatically.

Transporting the vehicles on car trains, ferries and car transporters

▶ Tie the vehicle down only at its wheels.

Porsche Active Suspension Management (PASM)

Various messages are shown on the multi-purpose display of the instrument panel.

▶ For further information on warning messages on the multi-purpose display: Please observe the chapter "OVERVIEW OF WARNING MESSAGES" on Page 172.

Three different running-gear setups can be selected with the push of a button:

- comfort
- normal
- sport

If the running-gear setups "comfort" or "normal" have been selected, the system automatically changes the setup to "sport" when the car is driven in a sporty manner.

Indication of the selected running-gear setup

The light-emitting diode in the button of the selected running-gear setup is lit.

In addition, the selected running-gear setup is indicated on the multi-purpose display of the instrument panel for around 12 seconds.

Warning lights and warning messages

The warning light in the instrument panel comes on if there is a system fault. A warning message is shown on the multi-purpose display of the instrument panel.

- ▶ Adapt your driving style to the changed condi-
- ▶ To remedy the fault, consult an authorized Porsche dealer.



Selecting the running-gear setup

- 1. Switch ignition on.
- 2. Press the appropriate button.

Note on operation

The running-gear setup selected last is stored in memory after the ignition is switched off.

Porsche Dynamic Chassis Control (PDCC)

Function

Porsche Dynamic Chassis Control (PDCC) is a system for roll stabilization of the vehicle body when driving. Driving comfort and driving safety are improved by active intervention of the anti-roll bars on the front and rear axles.

No separate controls are available for the PDCC

After selection of a running-gear setup in Porsche Active Suspension Management (PASM):

- comfort
- normal
- sport

PDCC automatically activates the corresponding on-road driving program.

▶ For information on selecting a running-gear setup:

Please observe the chapter "PORSCHE ACTIVE SUSPENSION MANAGEMENT (PASM)" on Page 224.

PDCC automatically activates the off-road driving program if Low Range reduction is switched on.

▶ For information on switching Low Range reduction on and off: Please observe the chapter "DRIVING PRO-GRAMS FOR ON-ROAD AND OFF-ROAD DRI-

Warning message

VING" on Page 204.

A warning message appears on the multi-purpose display of the instrument panel if there is a system fault.

- ▶ For further information on warning messages on the multi-purpose display: Please observe the chapter "OVERVIEW OF WARNING MESSAGES" on Page 172.
- ▶ Adapt your driving style to the changed conditions.
- Consult an authorized Porsche dealer in order to remedy the fault.

Checking hydraulic fluid

Regular checking and changing of the hydraulic fluid takes place as part of servicing.

Further important information on "Maintenance" can be found in a separate chapter.

▶ Please observe the chapter "CAR CARE IN-STRUCTIONS" on Page 306.

Off-Road Driving

Please read this chapter carefully before driving off road with your Porsche.

The information provided will familiarise you with the special advantages of your vehicle, allowing you to arrive at your destination safely every time.

We recommend practicing on less rugged terrain.

Vehicles with SportDesign package



Risk of damage. On vehicles with Sport-Design package, front, rear, and side member trim are painted. Off-road driving can seriously damage these trim parts.

- ▶ When driving off-road, make sure these parts are not damaged.
- ▶ Make sure there is sufficient clearance between obstacles and the underside of the vehicle.
- Avoid driving through water.
- ▷ Do not use side member trims or rear wheel spoilers as a running board.

Maintenance Note

Please bear in mind that off-road driving subjects all vehicle components to considerably more wear than normal use, making professional inspection and maintenance after each use a vital precondition for functioning and safety.

Grains of sand, dirt particles and other abrasive materials entering the brakes can cause excessive wear or unpredictable braking action.

Rules for off-road driving

- ▶ Ensure vehicle is equipped with approved allterrain tires.
- ▶ Pay attention to the ground clearance of the vehicle.
 - Please observe the chapter "GROUND CLEA-RANCE" on Page 409.
- ▶ Activate Low Range.
- Stow or fasten luggage and loads securely. Please observe the chapter "LOADING INFOR-MATION" on Page 263.
- ▷ If unknown terrain is obscured from view, examine it on foot first and traverse it with extreme caution.
 - This way, obstacles are easier to recognise and damage to the vehicle is avoided.
- ▷ Always drive with the engine running. Steering assistance is provided only with the engine running.
- Drive slowly and uniformly.

- ▷ Always make sure that the wheels touch the ground.
- Before driving through water, check the water depth, the condition of the surface beneath it and the speed of the water.
- ▶ Look out for obstacles such as boulders. holes, tree stumps or ruts.
- ▷ Always keep the sliding/lifting roof or Panorama roof system and the side windows closed while driving.
- ▶ Do not depart from marked routes or paths.
- Respect Nature. Always obey off-limits signs.

Driving systems for off-road driving

Specially adapted driving programs or powertransmission and running-gear control systems are available for off-road driving:

- Off-road program Low Range
- Off-road PSM
- Off-road ABS
- Center differential lock
- Rear differential lock
- ▶ Please observe the chapter "POWER-TRANS-MISSION AND RUNNING-GEAR CONTROL SYS-TEMS" on Page 210.

Before driving off

Tires

- ▶ Check tread depth and tire pressure.
- ▷ Check for damage and remove any foreign objects (e.g. stones) from the tread.
- ▶ Replace missing valve caps.

Rims

▶ Replace dented or damaged rims before driving off road.

After driving off road

Off-road driving places a greater burden on the vehicle than does normal driving on roads.

We recommend inspecting the vehicle after offroad driving. Potential damage poses an accident risk and impairs driving comfort. Damage on the car is recognised in good time if the car is checked.

Vehicles with SportDesign package



Risk of damage. On vehicles with Sport-Design package, front, rear, and side member trim are painted. Off-road driving can seriously damage these trim parts.

- ▶ When driving off-road, make sure these parts are not damaged.
- ▶ Make sure there is sufficient clearance between obstacles and the underside of the vehicle.
- Avoid driving through water.
- ▷ Do not use side member trims or rear wheel spoilers as a running board.



Car damage poses an accident risk for the vehicle occupants and other road users.

- ▷ In cases of doubt, have your vehicle checked by your authorized Porsche dealer.
- ▶ Examine tires for signs of damage such as cuts, tears, bulges or foreign objects stuck in the tread. Replace a damaged tire if neces-
- an authorized Porsche dealer without delay.

Recommended procedure

- ▷ Deactivate the Low Range off-road driving pro-
- ▷ Clean headlights and tail lights and check them for signs of damage.
- ▷ Clean the front and rear lincense plates.
- ▷ Clean the tire tread with a jet of water and remove any foreign objects.
- ▷ Clean wheels, wheel housings and the underbody with a jet of water.
- ▷ Check whether the car has picked up plant parts or branches. These materials increase the risk of fire and can damage fuel lines, brake hoses, boots of the axle joints and drive shafts.
- ▶ After off-road driving, always check the entire floor assembly, tires, body structure, steering system, running gear and exhaust system for signs of damage.

- ▶ After driving for an extended period through mud, sand, water or substances with a similar soiling effect, check the brake discs, brake pads, wheels and axle joints and have them cleaned.
- ▷ If you experience severe vibrations after driving off road, check the wheels for foreign substances.

These substances can produce an imbalance which might be responsible for the vibrations. Removing these deposits may remedy the problem.

Uphill driving



Danger of serious personal injury or death and risk of damage if the vehicle should overturn.

- ▷ Do not turn around when driving uphill.
- ▶ If it is not possible to climb a gradient, the car must be backed down in reverse gear.
- ▷ Do not drive over embankments or slopes at steep diagonal angles.
- ▷ If the vehicle starts to tilt, immediately steer in the direction of the tilt (line of slope).
- ▶ When driving uphill, never let the vehicle roll backward when in idle or not in gear. Exclusive use of the footbrake is too risky in such situations.

Note on operation

▶ Activate the Low Range program before taking extreme upward or downward gradients.

Tips on driving

- ▷ Do not perform manual gear changes when driving, and try to avoid stopping.
- ▷ Avoid high engine speeds (max. 2.500 rpm).

Traction on uphill slopes

Note on operation

▶ Activate the Low Range program and engage differential locks if necessary.

Tips on driving

- ▶ When driving uphill, go easy on the accelerator and make sure that wheels have sufficient traction (don't spin).
- ▷ Avoid high engine speeds (max. 2,500 rpm).
- Drive slowly.

Driving downhill



There is a danger of serious personal injury or death and risk of damage if the vehicle should overturn.

- ▷ Do not drive over embankments or slopes at steep diagonal angles.
- Drive downhill slowly, with the wheels pointing straight ahead.
- ▶ If the vehicle starts to tilt, immediately steer in the direction of the tilt (line of slope).
- ▶ When driving downhill, never let the vehicle roll when in idle.
- ▶ Use engine braking effect. If the engine braking effect is not adequate, gently apply the foot brake.

Note on operation

▶ Activate the Low Range off-road driving program. The off-road ABS is switched on automatically.

Tips on driving

The same general principle as for uphill driving applies to downhill driving.

- ▷ Do not perform manual gear changes when driving, and try to avoid stopping.
- ▶ Avoid high engine speeds (max. 2,500 rpm).

A special circuit in the off-road ABS permits controlled brief lock-up of the front wheels so that they can dig into the loose surface more effectively. Locked wheels slip and can no longer be steered.

When driving down steep hills on unpaved surfaces, brake carefully so that vehicle does not start to slide.

Obstacles

Pay attention to the ground clearance of the

Please observe the chapter "GROUND CLEA-RANCE" on Page 409.

Note on operation

▶ Activatethe Low Range program and engage differential locks if necessary.

Tips on driving

- ▶ Just before reaching the obstacle, ease off the accelerator slightly and use the car's momentum to cross the obstacle. This will prevent the car from jumping over the obstacle and landing on the following downward slope at an excessive speed.
- ▷ Avoid high engine speeds (max. 2.500 rpm).



Water crossing

Pay attention to the ground clearance of the

Please observe the chapter "GROUND CLEA-RANCE" on Page 409.

! \ Danger!

Danger of drowning if water enters the vehicle. Risk of damage to the engine and accessories if water penetrates.

▷ Before driving through water, check the water depth A, water speed and the condition of the surface beneath it.

The water must not be deeper than 20 in. (50 cm).

The water must not be deeper than 22 in. (55.5 cm) for vehicles with level control and height adjustment.

- ▷ Check the door sills and rubber seals before starting to drive.
- ▷ Do not drive through deep or rapidly flowing

Deep or rapidly flowing water, e.g. mountain streams, can cause the car to deviate from the desired path.

- ▷ Avoid a "bow wave" by driving at an appropriate
- ▶ Never open the doors when driving through water.

Soiling can impair the braking action.

▷ Check and clean the brakes if they have been soiled.

Danger of steering assistance failing during a long journey in the water if the drive belt slips.

▶ If the steering assistance fails, more effort will be required to steer.

Danger of damaging electrical systems

▷ Avoid driving through salt water.

Notes on operation

- ▶ Activate the Low Range program.
- ▷ Switch the air conditioner off.
- Switch the headlights off.

Tips on driving

- ▷ Avoid high engine speeds (max. 2.500 rpm).
- ▷ Do not perform manual gear changes when driving, and try to avoid stopping. Moving off in the water can be difficult due to the high resistance and the loose surface involved.
- ▷ Start the water crossing at a shallow place at walking speed.
- ▷ After checking the body of water, take the shortest path through it.
- ▶ Never drive into the water at high speed. The resulting "bow wave" could damage the engine and its accessories.
- ▷ Adjust your driving style to the unfamiliar surroundings.
- ▷ Cross the body of water slowly and at a constant speed.
- ▶ Never turn around when crossing a body of water.
- ▶ If it is not possible to cross the body of water, the car must be backed out of it in reverse gear.

The servo pump and alternator can fail if the car is driven through water for an extended period.

▷ If the servo pump fails, substantially more force will have to be exerted in order to steer.

Maintenance Note

The car requires a special check after the water crossing.

- ▶ Remove mud from the tire tread.
- ▷ Briefly apply the brakes in order to dry them after driving through the water.

Crossing obstacles



Risk of damage to the underbody and chassis components if obstacles are traversed improperly.

- ▷ Always bear in mind the ground clearance of your vehicle.
- ▷ Slowly drive over the middle of tree trunks, boulders or other obstacles with one of the front wheels.
- ▷ Cross the obstacle with the rear wheel in the same way.

Note on operation

▶ Activate Low Range and engage differential locks if necessary.



Tips on driving

- ▶ Avoid high engine speeds (max. 2,500 rpm).
- ▷ Drive slowly.

Driving on sand

Note on operation

▶ Activate Low Range and engage differential locks if necessary.

Tips on driving

Loose sand is an especially tricky surface for offroad driving.

You can often become stuck in sand within minutes if you do not drive correctly in such situations.

- ▶ Drive at brisk pace and do not stop under any circumstances. This will reduce the chance of the car becoming bogged down.
- have not been covered by blown sand, are not too deep and the car's ground clearance is sufficient.
 - Pay attention to the ground clearance of the
 - Please observe the chapter "GROUND CLEA-RANCE" on Page 409.
- ▷ Avoid high engine speeds (max. 2,500 rpm).

When driving on slopes with soft sand on vehicles with Tiptronic S:

▶ Use the manual select mode **M** in addition to the Low Range program.

If your vehicle becomes stuck nevertheless:

▷ Do not spin the wheels. Instead, use branches, mats or similar items to provide adequate traction so that you can drive out of the critical area.

Track ruts

Other vehicles leave ruts in many off-road courses or gravel roads.

- ▶ Pay attention to the ground clearance of the
 - Please observe the chapter "GROUND CLEA-RANCE" on Page 409.



Risk of damage to the vehicle floor when driving through ruts that are too deep.

- ▷ Always bear in mind the car's ground clearance.
- ▷ Do not drive over ruts that are too deep.

Note on operation

▶ Activate the Low Range program and engage differential locks if necessary.

Tips on driving

- ▷ In cases of doubt, drive with one wheel on the strip of grass between the ruts.
- ▷ Avoid high engine speeds (max. 2,500 rpm).
- Drive slowly.

Luggage Compartment, Loadspace and Storage

Rear Seats	236
Loadspace	239
Cargo management system	240
Luggage Compartment Cover	
Luggage safety net	
Ski Bag	
Roof Transport System	
Car Audio Operation/Tips	
Porsche Communication	
Management (PCM)	251
Fire Extinguisher	
Storage	
Cupholder	
Ashtray, front	
Cigarette Lighter	


Rear Seats

The rear seats are divided and can be folded forward individually to make the loadspace bigger.



Risk of damage to seat cushions, backrest, and seat belt if only the backrest is folded forward.

▷ Always fold seat cushions and backrest forward.



Folding rear seats forward

If the luggage safety net is installed, first set up the left seat cushion in a vertical position and fold the left rear seat backrest forward.

On vehicles with automatically controlled four-zone air conditioning:



Safety button

▶ Press the safety button in the driver's door armrest before folding the rear seats forward. The rear control panel for the air conditioning ceases to function.

This prevents unintentional adjustment of the air conditioning.

The symbol in the switch lights up.

1. Remove the headrests of the backrest to be folded forward.


Therefore:

Please observe the chapter "HEADRESTS" on Page 46.

- 2. Move front seats forward.
- 3. Pull seat cushion up at loop A.
- 4. Pull seat cushion forward (arrow **B**).



5. Raise seat cushion vertically.




6. Pull release lever **A** and fold the backrest forward.



7. Insert mounting hook on the seat cushion in the eyelet of the backrest (**arrow**).



8. Insert headrest into the receiver in the seat cushion.



Positioning rear seats

- 1. Remove the headrests from the seat cushion.
- 2. Make sure that the safety belts are not trapped.

Raise the backrest until it locks with an audible

The red "verification flag" A must be lowered completely.



- 3. Fold seat cushion forward.
- 4. Push seat cushion under the backrest.
- 5. Press seat cushion downward at the front. Make sure that the buckles are accessible.
- 6. Insert the headrests into the backrest.

Therefore:

Please observe the chapter "HEADRESTS" on Page 46.



Loadspace

The maximum permissible load on the loadspace floor is 400 kg or 880 lbs. The weight must be distributed evenly over the entire loadspace.

▶ Please observe the chapter "LOADING INFOR-MATION" on Page 263.

Opening loadspace floor

1. Pull handle **A** and lift the loadspace floor.



2. Unclip prop **B** and insert it into receiver **C** in the loadspace floor.

Closing loadspace floor

- 1. Lift the loadspace floor slightly and clip prop **B** into its holder in the vehicle floor.
- 2. Close the loadspace floor.



Tie-down rings

You can secure the load in the luggage compartment against slipping. Tie-down straps or the luggage net can be fastened to tie-down rings **D**.

▶ Make sure that all rings are equally loaded when securing a load.

Note on operation

The tie-down rings are not designed to restrain a heavy load in an accident.

Cargo management system

The cargo management system is a variable system for securing objects in the luggage compartment.

It comprises two telescopic rails integrated in the loadspace, a telescopic bar, four tie-down rings as well as a strap reel and a reversible mat. The reversible mat is provided with an anti-slip structure on the underside.

▶ For information on stowing loads and luggage: Please observe the chapter "LOADING INFOR-MATION" on Page 263.





Inserting and adjusting the telescopic bar


- 1. Insert the two end elements of the telescopic bar in the openings **A** of the mounting rails.
- 2. Press the end elements down and push against the load. When the bar is correctly positioned, the load should no longer be able to move.
- 3. Release the end elements.
- 4. Check that the elements are locked in position by pushing against them.

Inserting and adjusting the strap reel


The strap reel is stored in the supplied bag together with the tie-down rings in the luggage compartment or in the spare-wheel well.

- 1. Take the strap reel out of the bag.
- 2. Press the button **B** on the end element of the strap reel and pull both elements out to the width of the two mounting rails.





- 4. Press both end elements down and push against the load.
- 5. Release the end elements.
- 6. Check that the elements are locked in position by pushing against them.
- 7. Press button **B** and tension the strap so that the load cannot move.
- 8. Release button B.



Inserting strap reel on one rail

1. Press button **B** on the end element and pull both elements apart slightly.



- 2. Insert one end element of the strap reel in the opening A of a mounting rail, press down and slide into position.
- 3. Insert the second element in the same opening A, press down and slide in the opposite direction.
- 4. Check that the elements are locked in position by pushing against them.
- 5. Press button **B** and place the strap around the item of luggage. Tension the belt so that the item of luggage cannot move.
- 6. Release button B.

Inserting and adjusting tie-down rings


Tie-down straps or the luggage net can be fastened to the tie-down rings.

Make sure that all rings are equally loaded when securing a load.

The tie-down rings are not designed to restrain loads in serious accidents.



- 1. Insert the tie-down ring in the opening **A** of the mounting rail.
- 2. Press button **C** nach down and slide the tie-down ring in the correspondig direction.
- 3. Release button C.
- 4. Check that the tie-down ring is locked in position by pushing it.



5. Insert the remaining tie-down rings.

Note on operation

The opposing tie-down rings must always be inserted in the opposite direction.

Luggage Compartment Cover

The luggage can be protected against prving eves with the luggage compartment cover.

- ▶ Always pull out the luggage compartment cover when transporting objects in the luggage compartment.
 - The luggage compartment cover is not designed to carry objects.
- ▷ Do not hang bags or objects on the support brackets A. The support brackets could break off.
- ▶ Please observe the chapter "LOADING INFOR-MATION" on Page 263.

∕!\ Warning!

Danger of injury. During braking, direction changes or in an accident, objects can slide into the passenger compartment and endanger the occupants.

▷ Do not place objects on top of the luggage compartment cover.




Pulling out luggage compartment cover

▶ Pull out the cover by the handle and insert it into the guides on the left and right side walls of the luggage compartment.

Retracting luggage compartment cover

▷ Disengage the luggage compartment cover from the guides on the side walls and carefully guide it back into the retractor roller.



Remove luggage compartment cover

- ▶ Pull the release **B** back.
- ▶ Lift the cover at the right and remove.



Installing luggage compartment cover

- ▷ Insert the cover into the receiver on the left
- Press the cover down into the receiver on the right side until it can be heard and felt to en-

Release **B** must point forwards.

Luggage safety net

The luggage safety net can hold back only lightweight items in the event of braking, changes in direction or in an accident.

▶ For information on stowing loads and luggage: Please observe the chapter "STOWING LOAD IN THE VEHICLE" on Page 265.

/!\ Warning!

Danger of injury. During braking, direction changes or in an accident, an unsecured load can slip and endanger the occupants.

- ▶ Always secure the passenger compartment with the luggage safety net.
- ▷ Always fasten the load at the tie-down rings.
- ▶ The load must never project over the top edge of the seat backrest.
- ▷ If the safety net was heavily stressed or damaged during braking or an accident, etc., have the luggage safety net and its bracket checked by an authorized Porsche dealer.



Maintenance Note

▶ If the luggage safety net was heavily stressed or damaged during braking or in an accident etc., have the safety net and its retaining bracket checked by a qualified specialist workshop.

Wir empfehlen Ihnen für die Durchführung dieser Arbeiten einen Porsche Partner, da dieser über geschultes Werkstattpersonal und die erforderlichen Teile und Werkzeuge verfügt.

Permitted uses

A - Variant 1



B - Variant 2

In the case of variant, 2, it is necessary to first fold forward the rear seats and open the covers of the luggage safety net fixing points.

For information on folding the rear seats forward:

▶ Please observe the chapter "FOLDING REAR SEATS FORWARD" on Page 236.

Securing passenger compartment with luggage safety net

Pulling out luggage safety net

- ▶ Pull the luggage safety net out and engage the fastening hooks into the fixing rings on the
 - The luggage safety net fastening hooks can be pulled out at the sides.
- ▶ Make sure that the luggage safety net fastening hooks are properly engaged in the fixing rings.



Removing luggage safety net assembly from the rear seat backrest

- 1. Open both rear doors.
- 2. Fold down the left rear seat backrest first, followed by the right rear seat backrest. The seat cushions need not be folded over for this purpose.
- ▶ For information on folding the rear seats forward: Please observe the chapter "FOLDING REAR SEATS FORWARD" on Page 236.
- 3. Push the luggage safety net assembly in the direction of arrow 1.
- 4. Lift the luggage safety net assembly up and off (direction of arrow 2).




Ski Bag

Long objects such as skis can be transported in the passenger compartment, where they can be kept clean and protected against damage.

Loading ski bag

1. Press release button **A** on the lid of the through-load facility. Open the lid downward



- 2. Fold down the armrest of the rear seat backrest.
- 3. Pull protective cover **B** off the Velcro strap at the top and lower it.
- 4. Press release button **C** on the lid of the through-load facility downwards and fold down the lid.



- 5. Pull out and unfold the ski bag.
- 6. Insert objects into the ski bag from the luggage compartment.



Securing load

- ▷ Secure the stowed objects with tightening
- ▷ Insert belt tongue into the buckle.

Stowing ski bag

- 1. Empty ski bag.
- 2. Pull ski bag into the passenger compartment.
- 3. Close lid in the luggage compartment.
- 4. Carefully fold the ski bag and close the lid.
- 5. Put in the protective cover and secure it with the Velcro strap.

Note on operation

Roof Transport System

- ▶ Please follow the separate instructions for fitting the Roof Transport System.
- ▶ Please observe the chapter "LOADING INFOR-MATION" on Page 263.

Fitting normal commercially available luggage racks is **not** possible.

The **Porsche Roof Transport System** allows the transport of various sports and hobby equipment. Your authorized Porsche dealer will be pleased to tell you about the manifold uses of the Roof Transport System.



Risk of an accident, loss of control and damage to the vehicle.

- ▷ Completely remove the Roof Transport System before using an automatic car wash - risk of damage to the vehicle.
- ▷ Do not exceed the permissible roof load, the permissible gross weight and the permissible axle loads.
 - Please observe the chapter "WEIGHTS" on Page 408.
- Distribute load evenly, with heavy items as low as possible. Items of luggage must not project beyond the side of the load area.
- ▶ Fix and secure every item to the basic carrier with a rope or lashing strap (do not use elastic rubber tensioners).
- ▶ Before every trip, and at regular intervals during long trips, check that Roof Transport System and load are secure. Re-tighten if necessary and secure additionally by locking.

When the Roof Transport System is loaded, the maximum speed depends on the nature, size and weight of the load being carried.

▶ Adapt your driving style and speed to the changed conditions.

Nevertheless, Porsche recommends that you do not exceed the posted speed limit.

Driving, braking and steering behavior change due to the higher center of gravity and the greater wind-resistant area. You should adapt your driving style appropriately.

▷ Since fuel consumption and noise are increased with the Roof Transport System fitted, it should not remain on the car if not in use.

Car Audio Operation/Tips

For radio operation see your radio manual which is included with your on-board literature.

FM reception

A vehicle is not an ideal place to listen to a radio. Because the vehicle moves, reception conditions are constantly changing.

Buildings, terrain, signal distance and noise from other vehicles are all working against good recep-

Some conditions affecting FM may appear to be problems when they are not.

The following characteristics are completely normal for a given reception area, and they do not indicate any problem with the radio itself.

Note

Electronic accessories should only be installed by vour authorized Porsche dealer.

Equipment which has not been tested and approved by Porsche may impair radio reception.

Fading and drifting

FM range is limited to about 25 miles (40 km), except for some high power stations.

If a vehicle is moving away from the desired station's transmitter, the signal will tend to fade and/ or drift. This condition is more prevalent with FM than AM, and is often accompanied by distortion. Fading and drifting can be minimized to a certain degree by careful attention to fine tuning or selection of a stronger signal.

Static and fluttering

When the line-of-sight link between a transmitter and vehicle is blocked by large buildings or mountains, the radio sound may be accompanied with static or fluttering because of the characteristic of FM.

In a similar effect, a fluttering noise is sometimes heard when driving along a tree-lined road.

This static and fluttering can be reduced by adjusting the tone control for greater bass response until the disturbance has passed.

Multipath

Because of the reflecting characteristics of FM, direct and reflected signals may reach the antenna at the same time (multipath) and cancel each other out.

As a vehicle moves through these electronic dead spots, the listener may hear a momentary flutter or loss of reception.

Station swapping

When two FM stations are close to each other, and an electronic dead spot, such as static or multipath area, interrupts the original signal, sometimes the stronger second signal will be selected automatically until the original one returns.

This swapping can also occur as you drive away from the selected station and approach another station of a stronger signal.



Compact disc player



!\ Caution!

To avoid damage to compact disc player and discs.

- ▶ Use only compact discs labeled as shown, having no dirt, damage or warpage.
- ▶ Never attempt to disassemble or oil any part of the player unit. Do not insert any object other than a disc into the slot.Remember there are no user-serviceable parts inside the compact disc player.
- ▷ Do not allow the disc to sustain any fingerprints, scrapes or stickers on the surfaces. This may cause poor sound quality. Hold the disc only on the edge or center hole.
- ▶ When not in use, take the disc out of the player, put the disc back into its case and store it away from dust, heat, damp and direct sun-
 - Leaving the disc on the dashboard in the sun can damage the disc.

▶ If the disc gets dirty, clean the disc by wiping the surfaces from the center to the outside in a radial direction with a soft cloth. Do not use a conventional record cleaner or

anti-static record preservative.

Disc cleaners are available in audio stores.

Car Telephone and Aftermarket Alarms

Important legal and safety information regarding the use of cellular telephones

Some states may prohibit the use of cellular telephones while driving a vehicle. Check the laws and regulations on the use of cellular telephones in the areas where you drive.



/!\ Danger!

Risk of an accident.

Severe personal injury or death can result in the event of an accident.

Looking away from the road or turning your attention away from your driving can cause an accident and lead to serious personal iniury or death.

When using your cellular telephone, you should al-

▷ Give full attention to your driving - pull off the road and park before making or answering a call if traffic conditions so require; and

▶ Keep both hands on the steering wheel - use hands-free operation (if available) - pull off the road and park before using a hand-held telephone.

It is essential to observe the instructions of the telephone manufacturer before putting the telephone into operation.

Any portable telephone or radio transmitter which is used in a Porsche must be properly installed in accordance with the technical requirements of Porsche.

The transmission power must not exceed 10 W.

The devices must possess a type approval for your vehicle and have an "e" symbol.

If you should require equipment with transmission power values greater than 10 W, please consult your authorized Porsche dealer for this purpose. He is familiar with the technical requirements for installing devices of this kind.

The antennas for all radios and telephones with a transmitting antenna must be externally mounted.

The improper installation of radios or telephones or use of a radio or telephone with a transmitting antenna inside the car may cause **the warning** lights to come on.

Improper installation of such equipment can create a discharged battery or excessive current draw from added equipment.

If aftermarket systems are installed by non-dealership technicians or outside the selling dealer, problems may result. Installation of aftermarket equipment is not covered under the New Car Warrantv.

Consult your authorized Porsche dealer about the installation of non Porsche approved equipment.

Reception quality

The reception quality of your car telephone will change constantly when you are driving. Interference caused by buildings, landscape and weather is unavoidable. It may become particularly difficult to hear when using the hands-free function due to external noise such as engine and wind noise.

Automatic car-wash

Unscrew external antennas before using an automatic car-wash.

Porsche Communication Management (PCM)

/!\ Warning!

There is danger of accident if you set or operate the on-board computer, radio, navigation system, telephone or other equipment when driving.

This could distract you from traffic and cause you to lose control of the vehicle resulting in serious personal injury or death.

- Operate the components while driving only if the traffic situation allows you to do so safely.
- ▷ Carry out any complicated operating or setting procedures only with the vehicle stationary.
- ▶ If it is necessary to operate these components while the vehicle is in motion, use the function keys on the multi-functional steering wheel.
- ▶ Refer to the separate operating instructions before putting the PCM into operation.

When put into operation for the first time, a distance of approx. 3 miles (5 km) must be driven in order for the navigation system to complete the process of fine calibration. The same applies when the tires are changed (e.g. summer/winter tires) or new tires fitted. Full location accuracy is not yet achieved during the fine-calibration process.

If the vehicle has been transported (e.g. ferry, car train), the system may take a few minutes after being switched on before it determines the current location.

Serious tire slip (e.g. spinning wheels on snow) may result in temporarily inaccurate navigation.

When the battery has been disconnected, it may take up to 15 minutes before the navigation system is operational once more.

Satellite radio

You must have the satellite radio activated before you can put it into operation. You will need a contract with a provider in order to use this radio.

▶ Refer to the separate radio operating instructions before putting into operation.



Fire Extinguisher

If the vehicle is equipped with a fire extinguisher, it is mounted underneath the left or right front seat, depending on equipment level.

Fire extinguisher under the left front seat

▶ To remove the fire extinguisher in case of an emergency, hold the fire extinguisher with one hand, and press the PRESS button on the fire extinguisher holder with the other hand (arrow).

Fire extinguisher under the right front seat

▶ Take the fire extinguisher out of the drawer under the seat.

Note

- Pay attention to the final control date on the fire extinguisher. If the fire extinguisher is used after its testing interval has elapsed, it may not function properly.
- ▶ Follow the operating instructions on the fire extinguisher.
- ▶ The functional ability of the fire extinguisher should be checked by a specialist workshop every 1 to 2 years.
- ▶ After use, have the fire extinguisher refilled.

Storage

/ Warning!

Unsecured luggage and heavy objects may come loose during braking, rapid directional changes or in an accident and cause serious personal injury or death.

- ▷ Do not carry items of luggage or objects in the passenger compartment unsecured.
- ▷ Do not transport any heavy objects in open storage trays.
- ▷ Always keep the storage trays closed while driving.
- ▷ Always protect the passenger compartment with a safety net and a luggage compartment cover.

Note on operation

An unsecured or incorrectly positioned load can slip out of place or endanger the vehicle occupants during braking, direction changes or in accidents:

▶ Please observe the chapter "LOADING INFOR-MATION" on Page 263.

Storage options

- In the glasses case in the roof console
- In the glove compartment, pen holder
- In the front and rear armrests
- In the drawer underneath the passenger's seat
- In the storage compartments at the sides of the luggage compartment
- In the door trim panel
- In the center console, front and rear
- On the back of the front seats
- Coat hook on the rear grab handles
- Under the load compartment floor
- In the front and rear cupholders



Glasses case in the roof console

Sunglasses (for example) can be stored in this storage compartment.

Opening

▶ Press button (arrow).

Closing

▷ Close the lid until it clicks audibly into place.



Glove compartment



Risk of injury by the glove compartment lid in case of an accident.

▶ Keep the glove compartment closed while driving.

A drawer, designed to hold the vehicle folder, is located in the glove compartment.

Opening

▶ Press button **A** and open cover.

Locking

▶ Always lock button **A** with the car key to secure the contents from unauthorized access.



B - Thumb wheel for cooling the glove compartment **C** - Holder for pens

Cooling the glove compartment

- ▶ Rotate thumb wheel **B** leftwards.
- Switch cooling off
- ▶ Rotate thumb wheel **B** rightwards.



Storage trays in the armrest between the front seats

Two storages trays are located in the armrest.

Opening the top tray

▶ Press button **A** and lift the cover.



Opening the lower tray

Press button **B** and lift top tray with the cover



Storage tray in the rear armrest

One storage tray is located in the armrest.

Opening the storage tray in the armrest

- 1. Fold down the armrest completely.
- 2. Press button **C** and lift the cover.



Drawer underneath the right front seat

There is room for the fire extinguisher in the drawer underneath the right front seat. On vehicles with DVD navigation, the DVD player is under the right front seat.

▶ Please observe the chapter "DVD PLAYER UN-DER THE RIGHT FRONT SEAT" on Page 258.

Opening

▶ Lift the unlocking handle and pull out the drawer.

Closing

▷ Close the drawer until it clicks audibly into place.



Side storage compartments in the luggage compartment

Space is provided for the warning triangle in the right-hand storage compartment.

Depending on how the vehicle is equipped, there is an additional storage option in the left-hand storage compartment.

The intermediate base can be removed to increase the size of the drawer.

Opening the storage compartment

▶ Pull off the cover on the handle recess.

Closing the storage compartment

▶ First, insert the cover at the bottom and then close it until it clicks audibly into place.



/!\ Caution!

Risk of damage.

▶ Because of the heat, the right-hand storage compartment cannot be used as such in vehicles that have air suspension with level control and height adjustment.

256 Luggage Compartment, Loadspace and Storage

Cupholder

You can place drinks cans and cups in the cupholder.

▶ Keep the cupholder closed while driving.



Risk of accident, scalding or damage due to spilling drinks.

- ▷ Only use cupholder when safe to do so it is.
- ▷ Only use containers which fit.
- ▶ Never put overfull containers in the cupholder.
- ▶ Never use hot drinks.



Opening front cupholder

▷ Open shutter A (arrow).



Removing cupholder insert

The cupholder insert can be removed for cleaning. Removing the insert makes an additional storage tray available.

- ▷ Open shutter A.
- ▶ Press together the cupholder insert at the two engagement recesses **B**.
- ▶ Remove the cupholder insert.



Opening rear cupholder

▶ Press on the cover of the cupholder (arrow).

Closing rear cupholder

▷ Close and engage the cupholder.




DVD player under the right front seat

On vehicles with DVD navigation, the DVD player is under the right front seat behind a cover.

Opening the cover

- ▶ Pull cover upwards on the handle (direction of the arrow 1).
- ▶ Pull out cover towards the front (direction of the arrow 2).



Closing the cover

- ▷ Insert the four guide lugs of the cover into their openings (arrow).
- ▶ Press the cover into place.
- ▶ Push down the cover until it can be felt clicking into place.



Ashtray, front



Danger of fire.

▶ Never use ashtray for waste paper disposal, as it could pose a fire hazard.

Opening

▶ Press ashtray lid briefly.

Emptying

- ▶ Move unlocking button **A** to the right; the ashtray insert pops out.
- ▷ Once you have emptied the ashtray, replace the insert and push it down until it clicks audibly into place.



Ashtray, rear

Depending on how the vehicle is equipped, an ashtray can be installed in the rear door panels.

Opening

▶ Press ashtray lid briefly.

Emptying

- ▷ Open ashtray cover and press carefully to the door trim panel. The insert is raised slightly.
- ▶ Remove and empty insert.

Cigarette Lighter



Danger of fire and burning. The cigarette lighter is ready for use, regardless of the ignition lock position.

- ▷ Do not leave children in the car unattended.
- ▶ Never touch the heating element or sides of the lighter.
- ▶ Hold the lighter by the knob only.

The cigarette lighter is ready for use regardless of the ignition lock position.

Lighter, front

- ▶ Press ashtray lid briefly. Ashtray opens independently.
- ▶ Press lighter into the receptacle (arrow). When the element is red hot the lighter jumps back to its initial position.



Lighter, rear

- ▶ Press cover in the center console briefly. Cover opens independently.
- ▶ Press lighter into the receptacle (arrow). When the element is red hot the lighter jumps back to its initial position.

Trailer Hitch

Trailer Coupling	262
Loading Information	263



Trailer Coupling



Risk of accident.

- ▶ Follow the operating instructions for the trailer recommended by the trailer manufacturer.
- ▷ Do not modify or repair the trailer coupling.
- ▷ Before having new ADAPTER fitted, find out from your authorized Porsche dealer about the current authorization status.
- ▶ Use only ADAPTER makes tested and approved by Porsche.

- ▷ Ensure that all trailer equipment conforms to the appropriate classification for total gross trailer weight and tongue weight.
- ▶ Please observe the chapter "WEIGHTS" on Page 408.
- ▶ Please observe the chapter "LOADING INFOR-MATION" on Page 263.

Retrofitting

Have a trailer coupling retrofitted only by an authorized Porsche dealer. The dealer is familiar with the manufacturer's specifications and any necessary conversion measures.

Electrical connection

Your Porsche is equipped with a 7-pin connector A for the electrical connection to the trailer.



Risk of accident. Failure to keep an electrical adapter clean may result in corrosion and affect operation of electrical lines, resulting in possible trailer brake system failure.

▶ Periodically inspect and clean adapter as needed.

Hitching trailer

- ▷ Always turn off the alarm system before you attach a trailer. The inclination sensor could trigger the alarm unintentionally.
- ▶ Follow the operating instructions for the trailer recommended by the trailer manufacturer.
- ▶ Please observe the chapter "WEIGHTS" on Page 408.

Unhitching trailer

If the trailer is equipped with an overrun brake, do not unhitch the trailer when its brake is still applied.

Loading Information

Definitions

The towing capacity (gross weight of the trailer) is the sum of the trailer's empty weight and the weight of the load.

The vertical coupling load is the weight that the trailer drawbar exerts on the trailer coupling of the vehicle.

The rear-axle load is the vehicle weight on the rear axle plus the weight of the transported load and the vertical coupling load of the trailer.

The gross weight of the vehicle and trailer is the sum of the weight of the towing vehicle and the weight of the trailer.

The Curb weight - actual weight of your vehicle vehicle weight including standard and optional equipment, fluids, emergency tools, and spare tire assembly. This weight does not include passengers and cargo.

The Gross Vehicle Weight is sum of the curb weight and the weight of passengers and cargo combined.

The Gross Vehicle Weight Rating is the maximum total weight of vehicle, passengers, luggage, hitch, trailer tongue load and optional equipment.

The Gross Axle Weight Rating is the maximum load limit for the front or the rear axle. This information is located on the safety comliance sticker located in the driver's side door jamb.

For determining the compatibility of the tire and vehicle load capabilities:

▶ Please observe the chapter "TIRES, RIMS, TRACKS" on Page 403.

The load capacity coefficient (e.g. "106") is a minimum requirement. For more information:

▶ Please observe the chapter "INSCRIPTION ON RADIAL TIRE" on Page 327.

The Gross Combined Weight Rating is the maximum total weight rating of vehicle, passengers, cargo and trailer.

The Vehicle Capacity Weight - Load Limit - is the maximum total weight limit specified of the load (passengers and cargo) for the vehicle. This is the maximum weight of passengers and cargo that can be loaded into the vehicle. This information can be found on the tire pressure plate. If a trailer is being towed, the trailer tongue weight must be included as part of the cargo load.

The maximum loaded vehicle weight is the sum of curb weight, accessory weight, vehicle capacity weight and production options weight.

The load rating is the maximum load that a tire is rated to carry for a given inflation pressure.

The maximum load rating is the load rating for a tire at the maximum permissible inflation pres-

The cargo capacity is the permissible weight of cargo, the subtracted weight of passengers from the load limit.

▶ Never exceed the permissible limits.




Risk of personal injury or death. Injuries are much more likely in an accident if persons ride in the cargo area.

- Persons must ride only on the seats provided for this purpose.
- ▶ Make sure that everybody fastens their safety

Risk of loss of control, damage to the vehicle and serious personal injury or death.

▶ Never exceed the specified axle loads. Overloading can shorten the service life of the tires and car, as well as lead to dangerous vehicle reactions and long braking distances. Damage due to overloading is not covered by the vehicle warranty.



Example for determining the combined weight of occupants and cargo

Vehicle Load Capacity

- ▶ The combined weight of occupants and cargo should never exceed the weight shown on the tire plate in the vehicle. Please observe the chapter "TIRE PRESSURE PLATE" on Page 400.
- ▶ Never exceed the number of passengers shown on the tire pressure plate in the vehicle.

Determining the combined weight of occupants and cargo:

▶ Add the weight of all occupants and then add the total luggage weight (**figure**).

Steps for determining correct load limit

- 1. Locate the statement "The combined weight of occupants and cargo should never exceed XXX pounds" on your vehicle's placard (depending on the date of manufacture)
- 2. Determine the combined weight of the driver and passengers that will be riding in your vehicle.

- 3. Subtract the combined weight of the driver and passengers from XXX kilograms or XXX pounds.
- 4. The resulting figure equals the available amount of cargo and luggage load capacity. For example, if the "XXX" amount equals 1400 lbs. and there will be five - 150 lb passengers in your vehicle, the amount of available cargo and luggage load capacity is 650 lbs. [1400 - $750 (5 \times 150) = 650 \text{ lbs.l.}$
- 5. Determine the combined weight of luggage and cargo being loaded on the vehicle. That weight may not safely exceed the available cargo and luggage load capacity calculated in Step 4.
- 6. If your vehicle will be towing a trailer, load from your trailer will be transferred to your vehicle. Consult this manual to determine how this reduces the available cargo and luggage load capacity of your vehicle.

Stowing load in the vehicle



Danger of injury.

An unsecured or incorrectly positioned cargo can slip out of place or endanger the vehicle occupants during braking, direction changes or in accidents.

Never transport objects which are not secured.

- Always transport cargo in the cargo area, never in the passenger compartment (e.g. on or in front of the seats).
- Support the cargo on the seat backrests whenever possible. Always lock the backrests into place.
- ▶ Place the cargo behind unoccupied seats whenever possible.
- ▷ Stow heavy objects as close to the front of the cargo area as possible, with lightweight objects behind them.
- ▶ The cargo must never project over the top edge of the seat backrest.
- ▷ Always protect the passenger compartment with a luggage safety net and a luggage compartment cover. Do not drive with objects on top of the luggage compartment cover.

- ▶ If the rear seats are not occupied, the backrests can be additionally secured with the safety belts. Simply cross the outer safety belts and insert each into the opposite buckle.
- ▶ Make sure that the cargo cannot damage the heating filaments of the rear window and the TV antenna of the side window.

Luggage net

▶ Luggage must be stowed completely covered by the luggage net. The luggage net can prevent only lightweight objects from slipping.

Tie-down belts

- ▷ Do not use elastic belts or straps to tie down cargo.
- ▷ Do not place belts and straps over sharp edg-
- ▷ Observe the directions for use and information for the tie-down equipment.
- ▶ Use only belts with a tear strength of at least 1543 lbs. (700 kg) and a maximum width of 1 in. (25 mm).
- ▷ Cross the belts over the load.

Driving

- ▶ The car's handling changes depending on the vehicle loading. Adapt your driving style to the changed driving behavior.
- ▷ Do not exceed the maximum gross weight and the axle load.
- ▶ Please observe the chapter "WEIGHTS" on Page 408.
- ▶ Never drive with the rear window or rear lid Exhaust gases can enter the passenger compartment.
- ▶ Adapt the tire pressure to the load.
- ▶ Please observe the chapter "SETTING VEHIC-LE LOADING AND ADJUSTING TIRE PRESSU-RE" on Page 158.
- ▶ Please observe the chapter "TIRE PRESSU-RES, COLD" on Page 406.

Towing a trailer



Driving with a trailer

- ▷ Always observe the permissible towing capacity, vertical coupling load and rear-axle load. Please observe the chapter "WEIGHTS" on Page 408.
- ▶ When connected, the trailer must always be horizontal behind the towing vehicle. If necessary, use a trailer with an adjustable drawbar.
- ▶ When the vehicle is driven in the mountains, the engine output decreases as altitude increases. The maximum weights stated are the values at sea level. The total permissable weight of the car-trailer combination must therefore be reduced by 10% for each increment of 3,280 ft. (1,000 meters) altitude. A fractional increment counts as the full 3,280 ft. (1,000 meters). Please take this into consideration when planning your route.

Distributing the load

- ▷ Distribute the load in the trailer so that heavy objects are as close to the axle as possible. Always safeguard all objects against slipping and tie them down securely.
- You should make the best possible use of the trailer coupling's rated vertical coupling load when loading the trailer, but never exceed it.

Tire pressure

- ▷ Select the vehicle tire pressure for full load when towing a trailer.
- ▶ Please observe the chapter "TIRE PRESSU-RES, COLD" on Page 406.
- ▷ Check the tire pressure of the trailer's wheels according to the manufacturer's instructions.

Door mirrors

▷ If the width of the trailer obstructs your view of the traffic behind the trailer, you must have additional door mirrors fitted.

Headlights, lights

- Always check the headlight adjustment before driving with a trailer. If necessary, correct with the headlight beam adjustment function.
- ▷ Check whether the plug of the trailer is plugged into the towing vehicle and whether all lights function.

Driving with a trailer

When towing a trailer you must under all circumstances adapt your speed to prevailing road and driving conditions. Never exeed a speed of **50 mph (80 km/h)**. Towing at excessive speed can result in loss of control.

- Carefully and gradually familiarize yourself with the handling and braking behavior of the cartrailer combination.
- Do not drive with the towing vehicle empty and the trailer loaded.
 If this unfavorable combination is unavoidable, please drive especially slowly.
- Bear in mind the different vehicle handling and size in situations such as braking, parking, cornering and overtaking, etc.
- The driving stability of the car-trailer combination worsens as the speed increases. Therefore, drive especially slowly on downhill stretches and in the case of unfavorable road and weather conditions (such as wind).
- Drive in an appropriately low gear on downhill stretches in order to make use of the engine braking effect.

- Slow down immediately if the trailer starts to sway. Do not countersteer; brake if necessary. Never attempt to straighten out the car-trailer combination by accelerating.
- Activate Low Range when moving off on steep slopes.
- Under no circumstances may people, animals or objects be in the space between the trailer and the towing vehicle when the vehicle is moving.
- When reversing, bear in mind that ParkAssist is not active.

Maintenance note

Please take into consideration that driving with a trailer places markedly greater stress on all vehicle components. Expert inspection and maintenance after every use are indispensable prerequisites for proper functioning and safety.

Parking

Parking Aids	269
Swivelling down mirror glass as parking aid	273
Garage Door Opener	274

Parking Aids

ParkAssist provides a visual and acoustic indication to the driver of the distance between the vehicle and a large obstacle.

ParkAssist is switched on automatically when the ignition is switched on and remains active up to a speed of approx. 9 mph (14 km/h).

ParkAssist is switched off automatically at high speed. ParkAssist is switched on again automatically when the speed drops below approx. 9 mph (14 km/h).

The selector lever position determines activation levels for ParkAssist and the corresponding area that is monitored.

Selector lever position:

- P ParkAssist is **not** activated.
- R, N ParkAssist is activated for the front and rear areas.
- D, M ParkAssist is activated for the front area.

Gearshift lever position:

- R ParkAssist is activated for the front and rear areas.
- In all other gearshift positions ParkAssist is activated for the front area.

Note

On vehicles with manual transmission, the parking assistant is not switched on in the rear area if the vehicle rolls backward without reverse gear engaged.

Warning!

Risk of serious personal injury or death. ParkAssist cannot detect small objects such as children and pets.

Even when using ParkAssist, the driver is still responsible for taking due care when parking and when assessing obstacles.

Make sure that no persons especially small children, animals or obstacles are within the maneuvering area.



Switching ParkAssist on and off

- Switch ParkAssist on and off using button **A** in the roof console.
 - When ParkAssist is switched off, the indicator light in the button lights up.

Note on operation

It is a good idea to switch off ParkAssist when driving off-road and on unpaved surfaces.



Front ultrasound sensors

Sensors

Six ultrasound sensors in the front and rear bumpers measure the distance to the closest obstacle.

- Range of outer sensors (front and rear): approx. 24 in. (60 cm)
- Range of front middle sensors (arrow): approx. 48 in. (120 cm)



Rear ultrasound sensors

- Range of rear middle sensors (arrow) (only in vehicles without spare wheel bracket): approx. 59 in. (150 cm)
- Range of rear middle sensors (only in vehicles **with** spare wheel bracket): approx. 48 in. (120 cm)

Obstacles cannot be detected in the "blind" sensor area (above and below the sensors).

Maintenance Notes

- ▶ The sensors must always be kept free of dust, ice and snow in order to ensure that they are fully functional.
- ▷ Do not damage sensors by abrasion or scratching.
- ▶ Maintain sufficient distance when cleaning with steam-jet units. The sensors will be damaged if the pressure is too high.

Note on operation

The rear ultrasound sensors may not function correctly if tires that have not been recommended by Porsche are fitted on the spare wheel bracket.

If the spare wheel bracket is open, this may impair the function of the rear ultrasound sensors.

In vehicles that have air suspension with level control and height adjustment, the system may not recognise obstacles near the ground at terrain level or special terrain level.



A - Front display – left monitoring area **B** - Front display – right monitoring area

Warning indicators, signal tones, distances

The warning indicator for the front area is located on the dashboard.

The warning indicator for the rear area is located in the rooflining at the rear of the loadspace.

The warning indicators for the various monitoring areas (left and right) are subdivided respectively into one green, 4 yellow and 2 red light segments



C - Rear display – right monitoring area **D** - Rear display – left monitoring area

If ParkAssist is activated, the **green light segments** of the active warning indicators are lit up continuously.

If the vehicle approaches an obstacle that has been detected by the sensors, one or more of the yellow or red light segments lights up, depending on the distance to the obstacle. If the **first yellow light segment** lights up, the obstacle is still 48 in. (120 cm) (to the front) or 48 in. to 59 in. (120 to 150 cm) (to the rear) away. A brief signal tone sounds when reversing.

An **intermittent tone** sounds when the distance becomes less than approx. 24 in. (60 cm). The **fourth yellow light segment** lights up.

A **continuous tone** sounds when the distance becomes less than approx. 10 in. (25 cm) (on vehicles with trailer coupling: approx. 14 in. (35 cm)). The **second red light segment** lights up.

If the obstacle is approached even closer, the system may not be able to recognize the obstacle any longer.

▷ Set the radio volume so that the signal tones are not drowned out.

You can have the volume of the signal tones adjusted to your own requirements at your authorized Porsche dealer.

Note on operation

If the obstacle is approached even closer after the continuous tone sounds and the second red light segment lights up, the system may not be able to recognize the obstacle any longer.

Limits of ultrasonic measurement

- ParkAssist cannot detect sound-absorbing obstacles (e.g. winter operation, powder snow),
- Sound-reflecting obstacles (e.g. glass surfaces, flat painted surfaces),
- And very thin obstacles.

Other ultrasound sources (e.g. pneumatic brakes of other vehicles, jackhammers) can interfere with detection of obstacles.

Fault indication without warning tone

All red light segments of the active warning indicators light up when there is a **temporary fault** in ParkAssist.

Note

Correct operation is no longer ensured if there is a temporary fault (e.g. caused by ice formation or heavy soiling on the sensors).

The system detects the temporary fault.
All light segments light up until a speed of 9 mph (14 km/h) is reached.
ParkAssist is ready for operation again when the interference has been eliminated.

Fault indication with warning tone

In the event of a **long-lasting fault** in ParkAssist, the red light segments of the active warning indicators light up **and** a continuous tone sounds for three seconds after a transmission range has been selected.

Possible causes

- Defect or system fault.
- Switch ParkAssist off.
 When ParkAssist is switched off, the indicator light in the button lights up.
- ▶ Please have the fault remedied at an authorized Porsche dealer.

Driving with a trailer

The ParkAssist rear monitoring area is switched off when the trailer's power supply is plugged in.



A - Control switch for door mirror adjustment **C** - Passenger mirror setting

Swivelling down mirror glass as parking aid

When reverse gear is engaged, the mirror glass on the passenger's side swivels down slightly to show the curb area.

Preconditions

- Vehicle must be equipped with seat memory.
- Control switch A must be turned to position C (passenger mirror's setting).
- Reverse gear must be engaged.

Moving mirror to its initial position

The mirror glass swivels to its initial position when:

- The car is shifted out of reverse gear **or**
- The position of the control switch for the door mirror setting is changed.



- A Programable keypad
- **B** Light-emitting diode for status identification

Garage Door Opener

The programable garage door opener in your Porsche replaces up to three original hand-held transmitters used to operate a variety of devices (e.g. garage door, gate to the property, alarm system).

You have the option of programming each individual key in key pad A with an original hand-held transmitter frequency.

∕!\ Warning!

Risk of accident when using the garage door opener if persons, animals or objects are within the range of movement of the equipment that is being operated.

- ▶ When using the garage door opener, ensure that no persons, animals or objects are within the range of movement of the equipment that is being operated.
- Observe the safety notes for the original handheld transmitter.

To operate the device in question (e.g. garage door, gate to the property, alarm system):

▶ Press the relevant button in keypad A. Light-emitting diode **B** lights up during the signal transfer.

Notes on operation

- ▷ Always use the garage door opener in the direction of travel.
 - Otherwise, range restrictions cannot be ruled
- ▶ Before selling the vehicle, delete the programed signals in keypad **A** of the garage door
- ▶ Please read the instructions for the original hand-held transmitter to find out whether the original transmitter is equipped with fixed or changeable code.



Deleting programed signals (e.g., when selling the vehicle)

This process deletes the standard codes set at the factory. Do not repeat the process if you program further buttons

▶ Keep the two outer buttons of key pad A pressed for approx. 20 seconds until lightemitting diode **B** begins to flash. All programed signals are deleted.



Assigning garage door opener signal to key with fixed code system

- 1. Please follow the operating instructions for the original hand-held transmitter.
- 2. The standard codes set at the factory must be deleted before programming for the **first** time.
- 3. Point the original transmitter at the marked position.
- Press the button of the original hand-held transmitter and the button to be allocated on the keypad simultaneously (see illustration).

- 5. Keep both buttons depressed until lightemitting diode **B** starts to flash (first slowly and then quickly).
 - Only release both buttons when light-emitting diode **B** flashes quickly.
 - The rapidly flashing light-emitting diode **B** confirms that the new signal has been programmed successfully.
- 6. Repeat steps 1 to 3 to assign signals to the other buttons

Assigning garage door opener signal to key with changeable code system

- 1. Please follow the operating instructions for the original hand-held transmitter.
- 2. The standard codes set at the factory must be deleted before programming for the **first** time.
- 3. Point the original transmitter at the marked position.
- Press the button of the original hand-held transmitter and the button to be allocated on the keypad simultaneously.
- Keep both buttons depressed until lightemitting diode **B** starts to flash (first slowly and then quickly).
 - Only release both buttons when light-emitting diode **B** flashes quickly.
- The rapidly flashing light-emitting diode **B** confirms that the new signal has been programmed successfully.

- To synchronise the system:
 Press the programming button on the receiver for the garage door drive.
 Afterwards, you usually have approx.
 30 seconds to initiate step 5.
- Press the button to be assigned on the keypad twice (for some devices you must press the key on the keypad a third time to complete the setting process).
- 8. Repeat steps 1 to 5 to assign signals to the other buttons.

Note

Please consult your authorized Porsche dealer if you have not been able to successfully assign signals to the buttons even though you have carefully followed the instructions in this chapter and the operating instructions for the original hand-held transmitter. Your authorized Porsche dealer has a list of all garage door opener signals that can be taught.

Operating the garage door opener

 Press the corresponding button on keypad A. Light-emitting diode B lights up during signal transfer.

Alarm System and Theft Protection

Alarm System. **Passenger Compartment Monitoring, Inclination Sensor**

USA: KR55WK45032

Canada: CAN 267 104 187

This device complies with: Part 15 of the FCC Rules RSS-210 of Industry Canada.

Operation of this device is subject to the following two conditions:

- It may not cause harmful interference, and
- it must accept any interference received including interference that may cause undesired operation.

Note

▶ The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modification could void the user's authority to operate the equipment.

! Warning!

Any changes or modifications not expressly approved by Porsche could void the user's authority to operate this equipment.

Avoiding false alarms

- ▷ If people or animals are remaining in the locked vehicle or the vehicle is being transported on a train or ship, for example, the passenger compartment monitoring system and inclination sensor must temporarily be switched off.
- ▷ Always close the sliding/lifting roof or the Panorama roof system, and all door windows.
- ▷ Do not leave a mobile phone switched on in the glasses case of the roof console.
- ▶ Always turn off the alarm system before you attach or uncouple a trailer. The alarm system could trigger an alarm unintentionally.

Switching off the alarm system if it is triggered

- ▷ Unlock vehicle doors or
- ▷ Switch ignition on.

The following alarm contacts are monitored

- Doors
- Engine compartment lid
- Rear lid
- Rear window
- Passenger compartment
- Vehicle inclination
- ▶ If one of these alarm contacts is interrupted. the alarm horn sounds for approx. 30 seconds and the emergency flashers flash. After 5 seconds of interruption the alarm is triggered again. This cycle is repeated ten times.

Switching on

- ▶ Lock the vehicle. The alarm system, passenger compartment monitoring system and inclination sensor are switched on.
- ▶ Please observe the chapter "UNLOCKING AND LOCKING FROM OUTSIDE" on Page 26.

Switching off

▶ Unlock the vehicle. The alarm system, passenger compartment monitoring system and inclination sensor are switched off automatically.

Note on operation

If you unlock the vehicle with the key at the door lock, you must switch the ignition on (ignition lock position 1) within 15 seconds of opening the door in order to prevent the alarm system from being triggered.



Temporarily deactivating passenger compartment monitoring system and inclination sensor

If people or animals are remaining in the locked vehicle or the vehicle is being transported on a passenger train or ship, for example, the passenger compartment monitoring system and inclination sensor must be deactivated.

When locked again, the passenger compartment monitoring and inclination sensor are activated again.

The rocker switch to switch off the inclination sensor and the passenger compartment monitoring system is located next to the driver's seat under the seat belt height adjustment.

Note on operation

You can also temporarily deactivate the passenger compartment monitoring system and inclination sensor separately on the multi-purpose display in the instrument panel:

▶ Please observe the chapter "SWITCHING OFF PASSENGER COMPARTMENT MONITORING AND INCLINATION SENSOR ON THE MULTI-PURPOSE DISPLAY" on Page 165.



Deactivating passenger compartment monitoring system and inclination sensor

- 1. Apply the parking brake.
- 2. Remove ignition key. On vehicles with Porsche Entry & Drive: Switch off the ignition.
- 3. Open the driver's door.
- 4. Press the rocker switch. The rocker switch symbol lights permanently.
- 5. Lock the vehicle.

Emergency flasher flashes twice and an acoustic signal will sound twice.

The vehicle doors, the rear lid and the rear window are locked but the doors can be opened from the inside by pulling the inner door handle twice.

▶ Inform any persons remaining in the vehicle that the alarm system will be triggered if the door is opened.

Note on operation:

If the ignition is switched on after pressing the rocker switch, the passenger compartment monitoring system and the inclination sensor are activadet again. The symbol on the rocker switch will flash.

Activating the alarm system, the passenger compartment monitoring system and inclination sensor


▶ Unlock the vehicle and lock it again.

Fault indication

If the monitoring system and the inclination sensor could not be deactivated the symbol on the rocker switch will flash (e.g. the rocker switch is pressed with the ignition on).

For deactivating the passenger compartment monitoring and inclination sensor:

- ▷ Switch off ignition.
- Press the rocker switch.
- Lock the vehicle.



A - Light-emitting diode for alarm system

Function indication

The locking condition of the vehicle is indicated by a rapid flashing of the light-emitting diodes **A** in the front doors.

The light-emitting diodes go out when the vehicle is unlocked.

The passenger compartment monitoring and inclination sensor are switched on

The light-emitting diodes flash for 2 seconds, rapidly, then slowly.

The passenger compartment monitoring and inclination sensor are switched off

- The light-emitting diodes flash for 2 seconds, rapidly, then slowly.

The passenger compartment monitoring and inclination sensor are switched off in the multi-purpose display in the instrument panel

- The light-emitting diodes flash rapidly for 2 seconds, go out for 28 seconds and then flash slowly.

Faults of the central locking system and the alarm system

- The light-emitting diodes flash rapidly for 2 seconds, shine for 28 seconds and then flash slowly.

Immobilizer

There is a transponder (an electronic component). containing a stored code, in each key. Before the ignition is switched on, the ignition lock checks the code.

The immobilizer can be switched off and the engine started only using an authorized ignition key.

Switching off the immobilizer

▶ Insert the ignition key into the ignition lock.

Switching on the immobilizer

▶ Withdraw the ignition key.

Maintenance and Car Care

Exercise Extreme Caution when	
Working on your Vehicle	282
Engine Oil Level	284
Engine Oil Recommendation	287
Coolant Level	289
Brake-Fluid Level	
Power Steering	
Changing Air Cleaner	
Changing Particle Filter	
Automatic Transmission Fluid	
Manual Transmission Oil	
Wiper Blades	
Emission Control System	
Fuel Economy	
Operating Your Porsche in other Countries	
Fuel	
Portable Fuel Containers	
Fuel Recommendations	
Fuel Evaporation Control	
Car Care Instructions	
Hipunica zur Magannflaga	

Exercise Extreme Caution when Working on your Vehicle

Power measurements

Power measurements on dynamometers are not approved by Porsche.



Ignoring the following instructions may cause serious personal injury or death.

- ▶ The engine compartment of any motor vehicle is a potentially hazardous area. If you are not fully familiar with proper repair procedures, do not attempt the adjustments described on the following pages.
 - This caution applies to the entire vehicle.
- ▷ Only work on your vehicle outdoors or in a well ventilated area.
- ▶ Ensure that there are no open flames in the area of your vehicle at any time when fuel fumes might be present. Be especially cautious of such devices such as hot water heaters which ignite a flame intermittently.
- ▶ Before working on any part in the engine compartment, turn the engine off and let it cool down sufficiently. Hot engine compartment components can burn skin on contact.
- ▶ Be alert and cautious around engine at all times while the engine is running.

- If you have to work on the engine while it is running, always put the parking brake on **and** put the gearshift lever in neutral or the selector lever in position P or N.
- ▷ In particular, be very careful to ensure that items of clothing (ties, shirt, sleeves etc.), jewelry, long hair, hand or fingers cannot get caught in the fan, belts or other moving parts. The radiator and radiator fans are in the front of the car.
 - The fans can start or continue running as a function of temperature, even with the engine switched off.
 - Carry out work in these areas only with the engine off and exercise extreme caution.
- Your Porsche is equipped with an electronic ignition system. When the ignition is on, high voltage is present in all wires connected with the ignition system; therefore, exercise extreme caution when working on any part of the engine while the ignition is on or the engine is running.
- ▶ Always support your car with safety stands if it is necessary to work under the car. The jack supplied with the car is not adequate for this purpose.

For vehicles with air suspension with level control and height adjustment switch off level control. Therefore:

Please observe the chapter "RAISING VEHICLE WITH THE JACK" on Page 223.

- When working under the car without safety stands but with the wheels on the ground, make sure the car is on level ground, the wheels are blocked, and that the engine cannot be started.
- Withdraw ignition keys (switch ignition off in vehicles that have Porsche Entry & Drive).
- Do not smoke or allow an open flame around the battery or fuel. Keep a fire extinguisher close at hand.
- ▷ Incomplete or improper servicing may cause problems in the operation of the car. If in doubt about any servicing, have it done by your authorized Porsche dealer.
 - Improper maintenance during the warranty period may affect your Porsche warranty coverage.
- Supplies of fluids, e.g. engine oil, washer fluid, brake fluid or coolant, are hazardous to your health.
 - Keep these fluids out of children's reach and dispose of them in accordance with the appropriate regulations.
- ▷ Some countries require additional tools and special spare parts to be carried in your vehicle. Please make enquiries before driving abroad.

Radiator fans

The radiator and radiator fans are in the front of the car.



Danger of injury. The fans can start running as a function of temperature, even with the engine switched off.

► Exercise extreme caution when working in the area of the radiator fans.

Engine Oil

Engine oil consumption

It is normal for your engine to consume oil. The rate of oil consumption depends on the quality and viscosity of oil, the speed at which the engine is operated, the climate, road conditions as well as the amount of dilution and oxidation of the lubricant.

If the vehicle is used for repeated short trips, and consumes a normal amount of oil, the engine oil measurement may not show any drop in the oil level at all, even after 600 miles (1000 km) or more. This is because the oil is gradually becoming diluted with fuel or moisture, making it appear that the oil level has not changed.

The diluting ingredients evaporate out when the vehicle is driven at high speeds, as on an expressway, making it then appear that oil is excessively consumed after driving at high speeds.

If the conditions you drive your vehicle in are dusty, humid, or hot, the frequency of the oil change intervals should be greater.

If the vehicle is driven at a high rate of speed, climatic conditions are warm, and the load is high, the oil should be checked more frequently, as driving conditions will determine the rate of oil consumption.

- The engine in your vehicle depends on oil to lubricate and cool all of its moving parts. Therefore, the engine oil should be checked regularly and kept at the required level.
- Make it a habit to have the engine oil level checked with every refueling.
- The oil pressure warning light is not an oil level

The oil pressure warning light indicates serious engine damage may be occuring when lit, if engine rpm is above idle speed.

Engine Oil Level

▷ Check the oil level regularly. It is best to do this when refuelling and before extended journeys.

Further important information concerning "maintenance" can be found in a separate chapter.

- ▶ Please observe the chapter "EXERCISE **FXTREME CAUTION WHEN WORKING ON YOUR** VEHICLE" on Page 282.
- ▶ Please observe the chapter "OVERVIEW OF WARNING MESSAGES" on Page 172.



Engine oil is hazardous to your health and may be fatal if swallowed.

▶ Keep engine oil out of children's reach.

Used engine oil contains chemicals that have caused cancer in laboratory animals.

▶ Always protect your skin by washing thoroughly with soap and water.



If the oil level is too low, this is indicated by the oillevel warning light lighting up on the multi-purpose display.

▷ Check the oil level using the oil dipstick as soon as possible and add engine oil if necessarv.

Note on operation

▶ If the engine compartment lid is opened and oil is not added, the warning message appears again after approximately 100 km.

Checking the oil level



Danger of injury. The radiator fans can start running as a function of temperature, even with the engine switched off.

Risk of burning from hot parts in engine compartment.

▶ Exercise extreme caution when working on the engine compartment.

Conditions for measuring the oil level correctly

- Vehicle must be level.
- Engine must be switched off and at operating temperature.
- Before the oil-level measurement, allow the engine oil to flow back into the oil pan for around 3 minutes.

Checking oil level with the oil dipstick

- 1. Withdraw oil dipstick and wipe it with a clean, lint-free cloth.
- 2. Push oil dipstick fully home, withdraw again and read off the oil level.

The oil level must never fall below or exceed the "Min." and "Max." marks on the dipstick.

The difference between the marks is approx. 1.6 qt. (1.5 liters).

3. Push oil dipstick in as far as the stop.



Cayenne S oil dipstick

MAX - marking

▷ Do not top up engine oil.

MIN - marking

▶ Top up engine oil immediately.



Cayenne oil dipstick

MAX - marking

▷ Do not top up engine oil.

A - Normal marking

▷ Engine oil can be topped up.

MIN - marking

Top up engine oil immediately.





Cayenne S

Topping off engine oil



Fire hazard if engine oil comes into contact with hot engine parts.

Risk of damage if engine oil comes into contact with the drive belt.

▷ Exercise great care when adding engine oil.

Cayenne

- 1. Unscrew cap of the oil filler opening.
- 2. Add engine oil carefully.
- 3. Measure oil level again after a few minutes. Never exceed the MAX mark on the oil dipstick.
- 4. Push oil dipstick in as far as the stop.
- 5. Carefully close cap of the oil filler opening.

Engine Oil Recommendation

Recommended oil viscosity ranges dependent on ambient temperatures:

Ambient temperature (seasonal)	SAE Viscosity Range
Cayenne (V6)	
For all temperature ranges	0W - 30 0W - 40
Cayenne S	
higher than -13 °F (-25 °C)	OW - 40 5W - 40 5W - 50

Suitable oils are:

lower than -13 °F (-25 °C)

- ▶ Use only engine oils tested and approved by Porsche (Porsche approval list). Your authorized Porsche dealer will be pleased to advise you.
- ▶ You will find a sticker in the engine compartment which provides information (manufactrer) about the initial factory filling of your engine.
- ▶ Generally you can find the manufacturer suggestions on the oil containers or as a bulletin on the market.

0W - 40

Oil change

The engine oil has to be changed at the intervals listed in your Maintenance Schedule.

▶ Please observe the chapter "CAPACITIES" on Page 411.

We recommend that you have the engine oil changed at your Porsche dealer, who has the reguired oils and the necessary filling equipment.

If you suspect an oil leak in the engine have your dealer check it out immediately.

All current engine oils are compatible with each other, i.e. when making an oil change it is not necessary to flush the engine if you wish to use a different brand or grade of oil.

Since, however, each brand of oil has a special composition, you should, if possible, use the same oil brand if it becomes necessary to top up between oil changes.

Porsche engines have long intervals between oil changes. Only by using oils approved by Porsche the needed engine oil performance is guaranteed. If your vehicle is used frequently in stop-and-go traffic in cold weather, the engine will not always be completely warmed up.

Condensation from products of combustion may accumulate in the oil. In this case, it is advisable to change the oil more frequently so that your engine once again has 100% efficient engine oil.

Engine oil performance class

Engine oil is not only a lubricant, but also serves to keep the engine clean, to neutralize the dirt which penetrates into the engine through combustion and to protect the engine against corrosion. To perform these functions, the oil is provided with additives which have been specially developed for these functions.

The efficiency of an oil is expressed, for example. by the API, ILSAC or ACEA classifications.

Viscosity

Like all liquids, engine oil is viscous when cold, and thin-bodied when warm. The viscosity of an oil is expressed by its SAE class. For cold viscosity the SAE class is given as a number and the letter "W" (as in winter), for hot viscosity the SAE class is given only as a number.

The viscosity of an oil is, therefore, always the same if it has the same number of an SAE class.

E.g.: A 5 W-40 oil and a 5 W-50 oil have the same viscosity when cold: when hot the oil with the number 40 is thinner than the oil with the number 50.

Oils with two viscosities are called multigrade oils; oils with only one viscosity are termed singlegrade oils.

Single-grade oils cannot be used in your engine.

The viscosity of the engine oil for your Porsche has to be selected according to the ambient temperature given in the engine oil recommendation table.

Coolant Level

The coolant provides year-round protection from corrosion and freezing down to -31 °F (-35 °C) (Nordic countries -40 °F (-40 °C).

- ▶ Use only anti-freeze authorized by Porsche.
- ▷ Check the coolant level regularly.

Further important information concerning "maintenance" can be found in a separate chapter.

▶ Please observe the chapter "EXERCISE EXTREME CAUTION WHEN WORKING ON YOUR VEHICLE" on Page 282.

Checking coolant level/adding coolant

The expansion tank for the coolant is located under the engine-compartment cover in the engine compartment.

When the **engine** is **cold** and the car is level, the coolant level must lie between the min- and maxmarks.



Checking when engine is cold

1. Remove cover.



- 2. Open cap of the expansion tank carefully and allow any overpressure to escape. Then unscrew cap completely.
- 3. Read the coolant level.
- 4. Top up with coolant if necessary. Do not exceed the max- mark. Only add a mixture of anti-freeze and water in equal parts.

Antifreeze in coolant:

50% provides anti-freeze protection down to -31 °F (-35 °C).

5. Screw the cap closed firmly and put on the cover.

Checking the coolant level when a warning messages is shown on the multi-purpose display of the instrument panel

! Warning!

Danger of serious personal injury or death from scalding. Coolant is hazardous to your health, and may be fatal if swallowed.

- ▶ Do not open the cap of the expansion tank while the engine is hot.
- Allow the engine to cool down before opening the cap and protect your hands, arms and face from any possible escape of hot coolant.
- ▶ Keep coolant out of children's reach.
- Also, keep coolant away from your pets. They can be attracted to it should there be a spill, or to used coolant left in an open container. Coolant can be deadly to pets if consumed.

- Remove cover.
- 2. If the engine is hot, cover the the expansion tank cap with a cloth.

Open cap carefully and allow any overpressure to escape.

Then unscrew cap completely.

Read the coolant level.
 Top up with coolant if necessary.
 Only add a mixture of anti-freeze and water in equal parts.

Antifreeze in coolant:

50% provides anti-freeze protection down to -31 °F (-35 °C).

Do not exceed the max-mark.

Note on operation

- If the coolant level exceeds the max-mark when the engine is hot, check the coolant level again when the engine is cold.
- 4. Screw the cap closed firmly and put on the cover.
- Have the cooling system checked by an authorized Porsche dealer.

Maintenance Notes

If in an emergency pure water has been added, the mixture ratio must be corrected at an authorized Porsche dealer.

Marked loss of coolant indicates leakage in the cooling system.

The cause should be remedied at an authoized Porsche dealer immediately.

Radiator fans

The radiator and radiator fans are in the front of the car.



Danger of injury. The fans can start running as a function of temperature, even with the engine switched off.

Exercise extreme caution when working in the area of the radiator fans.

Brake-Fluid Level

▶ Use only new (unused) Original Porsche brake fluid.

Further important information concerning "maintenance" can be found in a separate chapter.

▶ Please observe the chapter "EXERCISE EXTREME CAUTION WHEN WORKING ON YOUR VEHICLE" on Page 282.



Brake fluid is hazardous to your health, and may be fatal if swallowed. Brake fluid also attacks paintwork.

- ▶ Keep brake fluid out of children's reach.
- ▶ Immediately rinse off spilled brake fluid with clean water.
- ▶ If brake fluid gets into your eye, immediately rinse with clean water for a few minutes. Then see a doctor immediately.
- ▶ Please note all the information on the refill container of the brake fluid.



Checking the brake-fluid level

The reservoir for the hydraulic braking system is located in the engine compartment.

- 1. Rotate the turn-locks 90° anti-clockwise (arrow) with a screwdriver and remove the cover.
- 2. Check brake-fluid level at the transparent

The fluid level should always lie between the MIN and MAX marks.



A slight decrease in the fluid level due to wear and automatic readjustment of the disc brakes is

If, however, the fluid level falls markedly or below the MIN mark, the braking system may have developed a leak.

▶ Please have the braking system checked immediately at an authorized Porsche dealer.

Changing the brake fluid

Brake fluid absorbs moisture from the air over time. This accumulation of water lowers the boiling point and, under certain operating conditions, can affect the braking performance.

▶ Therefore, have the brake fluid changed in accordance with the change intervals stated in the booklet "Guarantee and Maintenance".



Brake fluid warning light





Brake fluid warning light Canada

The warning light in the instrument panel and the warning message on the multi-purpose display of the instrument panel indicate

- indicate the brake level fluid is too low or.
- in conjunction with large pedal travel could indicate a braking-circuit failure.

Note on operation

If the warning lights should light up while driving:

- ▷ Stop immediately in a suitable place.
- ▷ Do not continue driving. Please have the fault remedied at your nearest authorized Porsche dealer.



Washer Fluid

Warning message on the multi-purpose display

A message is shown on the multi-purpose display of the instrument panel if the washer-fluid level is too low.

In this case, the residual quantity is only around 0.85 quarts (0.8 liter).

▶ Add washer fluid at the next opportunity.

The capacity is approx. 7.9 quarts (7.5 liters).

The washer-fluid reservoir for windshield, rear window and headlights is located in the engine compartment.

Summer filling with water + window cleaner concentrate in the mixture ratio specified on the container.

Winter filling with water + antifreeze + window cleaner concentrate in the mixture ratio specified on the container.

Always follow all the instructions on the containers of the additives used.

Only use window cleaner concentrate which meets the following requirements:

Dilutability 1:100, phosphate-free, suitable for plastic headlights.

We recommend window cleaner concentrates approved by Porsche, Your Porsche partner will be pleased to advise you.

The washer fluid reservoir for windscreen, rear window and headlights is located in the engine compartment.

- 1. Open cap of washer fluid reservoir.
- 2. Add washer fluid.
- 3. Close cap carefully.

Power Steering



Risk of accident resulting in serious personal injury or death. When the engine is stationary (e.g. when on tow) or the hydraulic system fails, there is no assistance for steering. Therefore, substantially more force will have to be exerted.

- ▷ Exercise great care when on tow.
- ▶ Have the fault remedied at your nearest authorized Porsche dealer.

The flow noise heard at full steering lock is designrelated and does not indicate a defect in the steering system.

Further important information concerning "maintenance" can be found in a separate chapter.

▶ Please observe the chapter "EXERCISE EXTREME CAUTION WHEN WORKING ON YOUR VEHICLE" on Page 282.



Checking hydraulic fluid

- ▶ Use only hydraulic fluid authorized by Porsche.
- ▷ Check the fluid level with the engine stopped and cold (engine temperature approx. 68° F or 20°C).
- 1. Remove cover A.



- 2. Open the reservoir cap.
- 3. The fluid level should lie between the MIN and MAX marks on the dipstick. Add hydraulic fluid if necessary.
- 4. Close cap carefully.
- 5. Put on cover A.
- 6. Close engine compartment lid.
- ▷ If the fluid level drops significantly, please have the cause remedied immediately by an authorized Porsche dealer.

Changing Air Cleaner

Regular replacement of the filter element is part of servicing.

▷ In dusty conditions, clean the filter element more frequently and replace if necessary.

Further important information concerning "maintenance" can be found in a separate chapter.

▶ Please observe the chapter "EXERCISE EXTREME CAUTION WHEN WORKING ON YOUR VEHICLE" on Page 282.

Changing Particle Filter

The fresh air passing through the particle filter into the passenger compartment is virtually free of dust and pollen.

▶ If the outside air is polluted by exhaust fumes, press the recirculating-air button.

A dirty filter can be the cause of reduced air throughput.

- ▶ Have filter replaced by your authorized Porsche dealer.
- ▶ Regular replacement of the filter is part of servicing.

Automatic Transmission Fluid

The torque converter and the transmission are lubricated with Automatic Transmission Fluid (ATF).

▶ Please observe the chapter "CAPACITIES" on Page 411.

Do not tow the car or run the engine without ATF in the transmission. The automatic transmission may be damaged by even a tiny speck of dirt, only a clean funnel or spout must be used when adding ATF.

The ATF and transmission oil has to be checked and changed at the intervals listed in your Maintenance Schedule.

We recommend that you have the ATF and transmission oil changed at your Porsche dealer, who has the required lubricants and the necessary filling equipment.

If you suspect an oil leak in the transmission, have your authorized Porsche dealer check it out immediately.

Manual Transmission Oil

The transmission oil has to be checked and changed at the intervals listed in your Maintenance Schedule.

▶ Please observe the chapter "CAPACITIES" on Page 411.

We recommend that you have the transmission oil changed at your Porsche dealer, who has the required lubricants and the necessary filling equipment.

If you suspect an oil leak in the transmission, have vour authorized Porsche dealer check it out immediately.

Wiper Blades

Maintenance Notes

Wiper blades that are in perfect condition are vital for a clear view.

- ▶ Replace the wiper blades twice per year (before and after the cold season) or if wiper performance deteriorates or the blades are damaged.
- ▶ For important information on "service topics": Please observe the chapter "CAR CARF INSTRUCTIONS" on Page 306.



Risk of damage if wiper arm accidentally falls back onto the windshield.

▷ Always hold the wiper arm securely when replacing the wiper blade.

Risk of damage if wiper blades that are frozen in place are loosened improperly.

▶ Thaw the wiper blades before loosening them.

Risk of damage.

If the wiper blades are not changed properly, they can come loose when the car is moving.

Check whether the wiper blades are seated securely.

The wiper blade must be pushed onto the wiper arm up to the stop.

▶ Periodically clean the wiper blades with window cleaner, especially after the vehicle has been washed in a car wash. We recommend the Porsche window cleaner. If they are very dirty (e.g. with insect remains), they can be cleaned with a sponge or cloth.

If the wiper blades rub or squeak, this may be as a result of the following:


- If the vehicle is washed in an automatic car wash, wax residues may adhere to the windshield. These wax residues can be removed only by using window cleaner concen-

Please observe the chapter "WASHER FLUID" on Page 292.


Please contact your Porsche partner for further information.

▶ The wiper blades may be damaged.


Replace damaged wiper blades as soon as possible.



- 1. Apply the parking brake.
- 2. Switch the windshield wipers off (position 0).
- 3. Switch ignition off.
- 4. Fold windshield wiper arm away from the windshield.
- 5. Lift up wiper blades completely (arrow).








- 7. Turn wiper blade at right angles (arrow 1).
- 8. Pull off wiper blade towards the windshield (arrow 2).
- 9. Push on new wiper blade.

Note on operation

- ▶ Make sure that the wiper blade is pushed onto the wiper arm up to the stop.
- 10.Fit cap **A** again.
- 11. Fold wiper blade back to its original position.
- 12. Carefully fold wiper arm back on to the windshield.



Changing rear window wiper blade



Risk of damage if the rear wiper is frozen in place and is loosened improperly.

- ▶ Thaw the wiper blade before loosening them.
- ▶ Grasp the wiper arm with both hands and separate it from the window.

- 1. Apply the parking brake.
- 2. Switch ignition off.
- 3. Carefully fold the wiper arm away from the rear window until it reaches its locking position (approx. 60°).
- 4. Carefully unclip the wiper blade from the wiper arm (arrow). Hold the wiper arm with your other hand when doing this.
- 5. Push the new wiper blade onto the wiper arm and snap it into place.
- 6. Carefully fold wiper arm back on to the rear window.

Emission Control System

In the interest of clean air

Pollution of our environment has become a problem that is of increasing concern to all of us. We urge you to join us in our efforts for cleaner air in controlling the pollutants emitted from the automobile.

Porsche has developed an emission control system that controls or reduces those parts of the emission that can be harmful to our environment. Your Porsche is equipped with such a system.

Porsche warrants the Emission Control System in your new car under the terms and conditions set forth in the Warranty Booklet.

You, as the owner of the vehicle, have the responsibility to provide regular maintenance service for the vehicle and to keep a record of all maintenance work performed. To facilitate record keeping, have the service performed by authorized Porsche dealers. They have Porsche trained technicians and special tools to provide fast and efficient service.

To assure efficient operation of the Emission Control System:

- accordance with the recommendations described in your Maintenance Booklet, Lack of proper maintenance, as well as improper use of the vehicle, will impair the function of the emission control system and could lead to damage.
- ▷ Do not alter or remove any component of the emission control system.
- ▷ Do not alter or remove any device, such as heat shields, switches, ignition wires, valves, etc., which are designed to protect your vehicle's emission control system. In addition to serious engine damage, this can result in a fire if excess raw fuel reaches the exhaust system.
- ▷ Do not continue to operate your vehicle if you detect engine misfire or other unusual operating conditions.

Parking



Danger of fire resulting in serious personal iniury or death.

- ▶ Do not park or operate the vehicle in areas where the hot exhaust system may come in contact with dry grass, brush, fuel spill or other flammable material.
- ▶ If your car catches on fire for any reason, call the fire department. Do not endanger your life by attempting to put out the fire.

Undercoating



Danger of fire resulting in serious personal injury or death.

▶ Do not apply additional undercoating or rustproofing on or near the exhaust manifold, exhaust pipes, catalytic converters or heat shields. During driving the substance used for undercoating could overheat and ignite.

How Emission Control Works

When an automobile engine is running, it uses energy generated through the combustion of a mixture of air and fuel. Depending on whether a car is driven fast or slowly or whether the engine is cold or hot, some of the fuel (hydrocarbons) may not be burned completely, but may be discharged into the engine crankcase or exhaust system. Additonal hydrocarbons may enter the atmosphere through evaporation of fuel from the fuel tank. These hydrocarbons (HC), when released into the air, contribute to undesirable pollution.

In addition, carbon monoxide (CO) and oxides of nitrogen (NOx) contribute to engine emissions. They, too, are formed during the combustion process and discharged into the exhaust system.

To reduce these pollutants, your Porsche is equipped with a precisely calibrated fuel injection system to assure a finely balanced air/fuel mixture under all operating conditions.

Oxvgen sensor

The oxygen sensor, installed in the exhaust pipe continuously senses the oxygen content of the exhaust and signals the information to an electronic control unit. The control unit corrects the air/fuel ratio, so the engine always receives an accurately metered air/fuel mixture.

Crankcase ventilation

Through crankcase ventilation, undesirable emissions from the engine crankcase are not permitted to reach the outside atmosphere. These emissions are recirculated from the crankcase to the air intake system. From here the emissions mix with the intake air and are later burned in the engine.

Catalytic converters

The catalytic converters are efficient "clean-up" devices built into the exhaust system of the vehicle. The catalytic converters burn the undesirable pollutants in the exhaust gas before it is released into the atmosphere.

The exclusive use of unleaded fuel is critically important for the life of the catalytic converters. Therefore, only unleaded fuel must be used.

The catalytic converters will be damaged by:

- push or tow starting the vehicle
- misfiring of the engine
- turning off the ignition while the vehicle is mov-
- driving until the fuel tank is completely empty
- by other unusual operating conditions.
- ▶ Do not continue to operate your vehicle under these conditions, since raw fuel might reach the catalytic converters. This could result in overheating of the converters. Federal law prohibits use of leaded fuel in this car.

Fuel Economy

Fuel economy will vary depending on where, when and how you drive, optional equipment installed, and the general condition of your car

A car tuned to specifications and correctly maintained, will help you to achieve optimal fuel economy.

- Have your vehicle tuned to specifications. Air cleaner should be dirt free to allow proper engine "breathing".
 Battery should be fully charged.
 Wheels should be properly aligned.
 Tires should be inflated to the correct pressure.
- ▷ Always monitor your fuel consumption.
- Drive smoothly, avoid abrupt changes in speed as much as possible.
- Avoid jack rabbit starts and sudden stops.
- ▷ Do not drive longer than necessary in the lower gears. Shifting into a higher gear early without lugging the engine will help save fuel.
- Prolonged "warm up" idling wastes gas. Start the vehicle just before you are ready to drive.
 Accelerate slowly and smoothly.

- Switch off the engine if stationary for longer periods.
- Any additional weight carried in the vehicle reduces fuel economy. Always keep cargo to a minimum and remove all unnecessary items.
- Organize your trips to take in several errands in one trip.
- ▶ All electrical accessories contribute to increased fuel consumption.
- Only switch on the air conditioning when necessary.
- ▶ Do not drive with the Roof Transport System mounted unless you need it.

The EPA estimated miles per gallon (mpg) is to be used for comparison purposes, actual mileage may be different from the estimated mpg, depending on your driving speed, weather conditions and trip length. Your actual highway mileage will probably be less than the estimated mpg.

Please observe all local and national speed limits.

Operating Your Porsche in other Countries

Government regulations in the United States and Canada require that automobiles meet specific emission regulations and safety standards. Therefore, cars built for the U.S. and Canada differ from vehicles sold in other countries.

If you plan to take your Porsche outside the continental limits of the United States or Canada, there is the possibility that

- unleaded fuel may not be available;
- unleaded fuel may have a considerably lower octane rating. Excessive engine knock and serious damage to both engine and catalytic converters could result:
- service may be inadequate due to lack of proper service facilities, tools or diagnostic equipment;
- replacement parts may not be available or very difficult to get.

Porsche cannot be responsible for the mechanical damage that could result because of inadequate fuel, service or parts availability.

If you purchased your Porsche abroad and want to bring it back home, be sure to find out about shipping and forwarding requirements, as well as current import and customs regulations.

Fuel



Fuel is highly flammable and harmful to health.

- ▶ Fire, open flame and smoking are prohibited when handling fuel.
- ▶ Avoid contact with skin or clothing.
- ▷ Do not inhale fuel vapours.

To prevent damage to the emission control system and engine:

- ▶ Never drive the tank completely out of fuel.
- ▷ Avoid high cornering speeds after the warning lights have come on.

To avoid permanent damage to the functionality of the catalytic converters and oxygen sensors, use only unleaded fuel.

The engine is designed to provide optimum performance and fuel consumption if unleaded premium fuel with 98 RON/88 MON is used.

If unleaded premium fuels with octane numbers of at least 95 RON/85 MON are used, the engine's knock control automatically adapts the ignition timing.

The emission control system can be damaged in various ways (e.g. fuelling incorrectly, shortage of fuel, tow-starting).

- ▶ Please observe the chapter "HOW EMISSION CONTROL WORKS" on Page 299.
- ▶ Please observe the chapter "DISPLAYING STA-TUS OF LEVEL CONTROL" on Page 154.



Filler flap

The filler flap is located in the rear right wing.

Unlocking the filler flap

The filler flap is unlocked by activating the remote control or gripping the outer door handle (on vehicles with Porsche Entry & Drive).

Opening the filler flap

▶ With the vehicle unlocked, press on the rear part of the filler flap (arrow). The filler flap pops up and can be opened.



Fuel quality label

Closing the filler flap

▷ Close the filler flap and press on the rear of the filler flap (arrow) until it can be felt to engage.

Locking the filler flap

The filler flap is locked by activating the remote control or the button in the outer door handle (on vehicles with Porsche Entry & Drive).



Emergency unlocking

If the electrical release is faulty:

- 1. Open rear lid.
- 2. Remove lid of the right storage compartment.
- 3. Pull emergency release A in the direction of the arrow.

The filler flap pops open.

Refueling

▶ Total capacity approx. 26.4 gallons (100 liters), including approx. 3 gallons (12 liters) reserve

Danger!

The RF energy from a cellphone can cause a sparking on bare metal, much like aluminium foil in a microwave oven. The spark could ignite gasoline fumes present while refuling. Static discharge from your body can ignite gasoline fumes present when you get back out of the vehicle and touch the fuel nozzle. In either case, resulting fire can cause serious damage to the vehicle, serious injury or death to persons in immediate vicinity.

- ▷ Do not use a cellphone while pumping gas.
- ▷ Do not re-enter the vehicle while pumping gas.
- 1. Stop the engine and switch off the ignition.



- 2. Slowly unscrew the tank cap. Hang the tank cap on plastic strap A of the filler flap.
- 3. Insert pump nozzle fully into the filler neck with the handle of the pump nozzle facing down.
- 4. Do not add further fuel once the correctly operated automatic pump nozzle has switched Fuel could spray or could run over when heat-
- 5. Replace the tank cap immediately after refuelling and turn it until you hear it and feel it engage.

Maintenance Note

If you lose the tank filler cap, you must replace it only with an original part.

Portable Fuel Containers

Danger!

Portable fuel containers, full or partially empty, may leak causing an explosion, or result in fire in case of an accident.

▶ Never carry additional fuel in portable containers in your vehicle.

Fuel Recommendations

Your Porsche is equipped with catalytic converters and must use UNLEADED FUEL ONLY.

Your engine is designed to provide optimum performance and fuel economy using unleaded premium fuel with an octane rating of 98 RON (93 CLC or AKI). Porsche therefore recommends the use of these fuels in your vehicle.

Porsche also recognizes that these fuels may not always be available. Be assured that your vehicle will operate properly on unleaded premium fuels with octane numbers of at least 95 RON (90 CLC or AKI), since the engine's "Electronic Octane™ knock control" will adapt the ignition timing, if necessary,

The use of UNLEADED FUEL ONLY is critically important to the life of the catalytic converters. Deposits from leaded fuels will ruin the converters and make it ineffective as an emission control device.

Cars with catalytic converters have a smaller fuel tank opening, and gas station pumps have smaller nozzles. This will prevent accidental pumping of leaded fuel into cars with catalytic converters.

Unleaded fuels may not be available outside the continental U.S. and Canada. Therefore, we recommend you do not take your car to areas or countries where unleaded fuel may not be available.

Octane ratings

Octane rating indicates a fuel's ability to resist detonation. Therefore, buying the correct octane gas is important to prevent engine "damage".

The RON octane rating is based on the research method. The CLC (U.S. Cost of Living Council octane rating) or AKI (antiknock index) octane rating usually displayed on U.S. fuel pumps is calculated as research octane number plus motor octane number, divided by 2, that is written as:

$$\frac{RON + MON}{2}$$
 or $\frac{R + M}{2}$

The CLC or AKI octane rating is usually lower than the RON rating:

For example: 95 RON corresponds 90 CLC or "AKI"

▷ Do not use fuel additives without Porsche approval.

Fuels containing ethanol

▷ Do not use any fuels containing more than 10 percent ethanol by volume.

We recommend, however, to change to a different fuel or station if any of the following problems occur with your vehicle:

- Deterioration of driveability and performance.
- Substantially reduced fuel economy.
- Vapor lock and non-start problems, especially at high altitude or at high temperature.
- Engine malfunction or stalling.

Fuel Evaporation Control

Fuel tank venting

The evaporation chamber and the carbon canister prevent fuel from escaping to the atmosphere at extreme high outside temperatures, when driving abruptly around curves and when the car is parked at an incline or in any other nonlevel position.

Vapor control system and storage

When the fuel tank is filled, vapors are collected in the evaporation chamber by a vent line leading the vapors to the carbon canister where they are stored as long as the engine does not run.

Purge system

When the engine is running, the fuel vapors from the canister will be mixed with fresh air from the ambient air of the canister. This mixture will be directed to the intake air housing by the tank vent line, mixed with the intake air and burned during normal combustion.

Car Care Instructions

▶ Please observe the chapter "EXERCISE EXTREME CAUTION WHEN WORKING ON YOUR VEHICLE" on Page 282.

Regular and correct care helps to maintain the value of your car and is also a precondition for the New Vehicle Warranty and the Anti Corrosion Warranty.

Your authorized Porsche dealer has specially developed car-care products from the Porsche program available either singly or as complete car-care sets. They will be pleased to help you select suitable products.

Whether you use Porsche products or other commercially available cleaning agents first make sure of their correct application.

A Porsche that is well-cared for can look like new for years. It all depends on the amount of care the owner is willing to give the car.

!\ Warning!

Risk of serious personal injury or damage to the vehicle or property.

Cleaning agents may be hazardous to your health.

Most chemical cleaners are concentrates which require dilution. High concentrations might cause problems ranging from irritation to serious injury as well as damage to your vehicle.

- ▶ Keep cleaning agents out of reach from chil-
- Observe all caution labels.
- Always read directions on the container before using any product. These directions may contain information necessary to avoid personal injury.
- Do not use fuel, kerosene, naphtha, nail polish remover or other volatile cleaning fluids. They may be toxic, flammable or hazardous in other ways. Only use spot removing fluids in a well vented area.
- ▷ Do not clean the underside of chassis, fenders, wheel covers, etc., without protecting your hands and arms as you may cut yourself on sharp-edged metal parts.

Moisture and road salt on brakes may affect braking efficiency.

Test the brakes after each vehicle washing.

High-pressure cleaning units



High-pressure cleaning units can damage the following components:

- Tires
- Logos, emblems
- Painted surfaces
- Widened fenders
- Lock and latch of the removable towing attach-
- Seals of the electrically retractable ball hitch
- Alternator, valve covers
- ParkAssist sensors
- ▶ Please observe the operating instructions from the unit manufacturer.
- ▷ Always cover the lid over the brake fluid reservoir prior to cleaning. Never point the cleaning jet directly at the lid.
- ▶ When cleaning with a flat-jet nozzle or the like, maintain a minimum distance of 21 in. (50 cm).

- ▶ Never use high-pressure cleaning units with a round-jet nozzle.
 - A high-pressure cleaning unit with round nozzle will damage your vehicle. The tires are particularly susceptible to damage.
- ▷ Do not point the cleaning jet directly at any of the aforementioned components.

Door lock

▶ To prevent the door lock from freezing during the cold season, cover the lock barrel with a suitable adhesive tape during washing.

Should the locks freeze, use an ordinary de-icer. In many cases, a well warmed key can help. Never use excessive force.

Washing

The best protection for the car from the damaging effects of the environment is frequent washing and preservation. The underside of the car should also be thoroughly washed for cinders, salt or sanding at winter's end.

The longer salt, road dust, industrial dust, insect remains, bird excrement, and tree exudations (resin, pollen), etc. are allowed to remain on the bodywork, the more serious is their harmful effect.

New cars should be washed carefully with plenty of clear water to protect the new paint work. Dark paint finishes show up the smallest of surface damage (e.g. scratches) more readily than lighter colors.

Dark colors are also more susceptible to scratching because of the composition of their pigments and require particularly careful paint care.

- ▷ Do not wash your car in bright sunlight or while the bodywork is still hot.
- ▶ When washing by hand, use abundant water, a soft sponge or wash brush and Porsche car shampoo.
- ▶ Begin by spraying the body thoroughly with water to rinse away loose dirt.
- ▶ After washing, rinse the car with plenty of water and then dry with a chamois leather. Do not use the same chamois leather for drying as you use for cleaning the windshield and windows.

**** Warning‼

Moisture which gets on the brakes during a car wash can reduce braking efficiency or make the brake pull unevenly which could increase the danger of an accident, causing serious personal injuries or death.

▷ Always apply the brakes a few times after washing the car to test braking efficiency and dry the brake discs.

When doing this, take care not to hamper other road users behind you (traffic conditions permitting).

Automatic car washes

▶ Please observe the chapter "WIPFR BI ADFS" on Page 295.

Optional add-on parts or parts which project beyond the contours of the vehicle may be damaged by design features (e.g. brushes) of automatic car washes.

The following parts are particularly susceptible to damage:

- Windscreen wipers and rear wiper (always) switch them off – position 0 – to prevent them wiping unintentionally in intermittent or sensor operation).
- Door mirrors (always fold in).
- Roof Transport System (always remove completely).
- Spoiler.
- Wheels (the wider the rim and the lower the tire height, the greater the risk of damage).
- ▶ Please consult the operator before using automatic car washes.
- ▶ Wash and dry by hand all points not reached by a car wash, such as door and lid seams or door sills.

Note

Automatic car washes spray water at odd angles and high pressures, which are not seen in normal driving. Therefore, water can sometimes find its way into the passengers compartment during or shortly after the car wash.

Paint

▶ Never rub a dusty car with a dry cloth since dust particles are abrasive and could dull and damage the surface finish.

The paintwork of your car is exposed to all types of mechanical and chemical conditions, particularly climatic ones such as bright sunlight, rain, frost and snow. Ultraviolet light, rapid changes in temperature, rain, snow, industrial dust and chemical deposits constantly attack the paint which is only able to withstand such exposure in the long term if it is given regular care and attention.

- ▶ Do not apply silicone polishes to the windshield or window.
- ▶ Do not treat matt-painted components with preservatives or polishes, otherwise the matt effect will be lost.

Preservation

The paint surface becomes dull over time due to weathering. It is therefore necessary to preserve the paint regularly.

This keeps the paint shiny and elastic. Dirt is prevented from adhering to the paint surface and industrial dust is prevented from penetrating the paint.

Provided it is washed and treated with preservative regularly, the brand new finish of your car will be retained for years to come.

Simply apply paint preservative after washing the car and polish it smooth.

Polishing

Do not resort to using Porsche polish until it becomes evident that the normal preservatives no longer produce the desired finish.

Removing spots and stains

- ▶ Remove tar stains, grease, oil spots and dead insects etc. as soon as possible with Insect Remover. They can cause discoloration if allowed to remain on the paintwork.
- ▶ Wash the affected area immediately after treating it.

Minor paint damage

▶ Have minor paint damage, such as scratches, scores or chips caused by flying stones, repaired immediately by your authorized Porsche dealer **before** corrosion begins.

However, if there are already traces of corrosion, they must first be removed carefully and thoroughly. Coat the area with a rust-proofing primer and finish off with a top coat. The paint code and color number are found on the data bank in the Maintenance booklet and on the vehicle's data bank.

▶ Please observe the chapter "DATA BANK" on Page 399.

Cleaning the engine compartment



Risk of damage, e.g. to the alternator, painted surfaces, and the valve covers.

- ▶ Never use high-pressure cleaning units with a round-iet nozzle.
- ▶ Always maintain a minimum distance of 21 in. (50 cm).
- ▷ Always cover the lid over the brake fluid reservoir prior to cleaning with a high-pressure cleaner. Never point the cleaning jet directly at the lid.
- ▷ Do not point the cleaning jet directly at any of the aforementioned components.

Note on operation

If the car is driven off-road frequently and after driving on salted or gritted roads:

▷ Clean the engine compartment regularly.

Windows

The road dust which settles on the windshield and windows contains particles of tire rubber and oil residue. The interior trim and upholstery release particles, particularly in strong sunlight, which collect on the insides of the windows. These deposits are augmented by impurities in the air which enters the car through the fresh air vents.

- Clean all windows regularly, inside and outside. with Porsche window cleaner.
- ▶ Make sure not to damage the TV antenna in the side window when cleaning.
- ▶ If you use a chamois leather for the windows. do not use it for paintwork as it will otherwise pick up a certain amount of preservative or polish and could smear the windows and thus impair vision.
- Remove dead insects with insect remover.

Care of wiper blades

Wiper blades that are in perfect condition are vital for a clear view.

- ▶ Replace the wiper blades twice per year (before and after the cold season) or if wiper performance deteriorates or the blades are damaged.
- ▶ Please observe the chapter "WIPER BLADES" on Page 295.
- ▶ Periodically clean the wiper blades with window cleaner, especially after the vehicle has been washed in a car wash. We recommend the Porsche window cleaner. In the event of heavy soiling (e.g. insect residue), the blades can be cleaned with a sponge or a cloth. If the wiper blades rub or squeak, this may have the following causes:

If the vehicle is washed in an automatic car wash, wax residues may adhere to the windshield. These wax residues can be removed only by using window cleaner concentrate.

- ▶ Please observe the chapter "WASHER FLUID" on Page 292.
- ▶ Please contact your authorized Porsche dealer for further information.

Undercoating

The underside of your car is durably protected against chemical and mechanical influences.

As it is not possible to exclude the risk of damage to this protective coating in day to day driving, it is advisable to have the underside of the car inspected at certain intervals - preferably before the start of winter and again in spring - and the undercoating restored as necessary.

Your authorized Porsche dealer is familiar with the bodyseal treatment procedures and has the necessary equipment for applying factory approved materials. We recommend that you entrust them with such work and inspections.

Unlike conventional spray oils, undercoating and rust-proofing compounds based on bitumen or wax do not attack the sound-proofing materials applied at the factory.



Danger of fire resulting in serious personal iniury or death.

▷ Do not apply additional undercoating or rustproofing on or near the exhaust manifold, exhaust pipes, catalytic converters or heat shields. During driving the substance used for undercoating could overheat and ignite.

Effective rust-proofing is particularly important during the cold weather season. If your car is driven frequently in areas where salt has been spread on

the roads, the whole engine compartment should be cleaned thoroughly after the winter to prevent salt from causing any lasting damage. A full underbody wash should also be performed at the same time.

Cleaning headlights, lights, interior and exterior plastic parts, adhesive films

Observe the following points:

▶ Use only clean water and a little dishwashing detergent or interior window cleaner to clean headlights, lights, plastic parts and surfaces. Use a soft sponge or a soft, lint-free cloth.

Note

An interior window cleaner can also be used to clean plastic surfaces (observe cleaning instructions on the container!).

We recommend the Porsche interior window cleaner.

- ▶ Gently wipe the surface without applying too much pressure.
- ▷ Do not clean when dry.
- Never use other chemical cleaners or solvents.

Rinse cleaned surfaces with clear water.

Light alloy wheels

▶ Please observe the chapter "AUTOMATIC CAR WASHES" on Page 308.



Danger of accident resulting in serious personal injury or death if cleaning agents (e.g. wheel cleaning agents) come into contact with the brake discs. The resulting film on the brake discs can impair braking performance.

- ▶ Make sure that no cleaning agent comes into contact with the brake discs.
- ▶ If cleaning agent has come into contact with the brake discs, thoroughly clean the brake discs with a strong jet of water.
- Paving attention to any road users behind you. dry the brake discs by applying the brakes.

Pitting may occur if metallic particles which cause contact corrosion (e.g. brass or copper in brake dust) are allowed to remain on the aluminum too long.

▷ If possible, wash the wheels with a sponge or wash brush about every two weeks. In areas where road salt or grit is spread on winter roads or there is a lot of airborne industrial dust, it is best to clean the wheels weekly. The Porsche Light Alloy Wheel Cleaner (ph-value 9.5) can be used for this purpose.

If the ph-value of the detergent is incorect, the protective coating on the wheels will be destroyed.

Polishes which dissolve oxides, such as those frequently used for other metals, or abrasive tools or agents are unsuitable because they break down the oxide film of the protective coating and will cause discoloration of the wheel.

Every three months, after cleaning, coat the wheels with a car wax or non-corrosive grease (e.g. vaseline).

Using a clean cloth thoroughly rub the grease into the surface.

Stainless steel exhaust tailpipes

Stainless steel exhaust tailpipes can discolor due to soiling, strong heat, and combustion residues.

The original polish can be achieved again using commercially available metal polishing paste or metal polish.

Cleaning door, roof, lid and window seals Leather care



The lubricant coating on the inner door seals may be damaged by unsuitable cleaning and care agents.

- ▶ Do not use any chemical cleaning agents or solvents.
- ▷ Do not use any care agents.
- ▶ Wash dirt (e.g. abrasion, dust, road salt or grit) from all seals regularly using warm soapy water. Do not use any chemical cleaning agents or solvents.
- ▶ When there is a frost hazard, the outer door seals and the lid seals can be protected against freezing into place by a suitable care product.

The natural surface markings of leather. e.g. creases, healed scars, insect sting marks, structural differences and slight variations in shade and grain add to the attractiveness of the high-quality natural leather product.

Observe the following care instructions:



The leather will be damaged by the use of unsuitable cleaning and care agents and by inappropriate treatment.

- ▶ Do not use caustic cleaners or hard cleaning objects!
- Perforated leather must under no circumstances get wet on its reverse side.
- ▶ All types of leather should be cleaned regularly to remove fine dust using a soft, damp, white woollen cloth or a commercially available microfibre cloth.
- ▶ Remove heavy contamination with a leather
 - Please always follow the instructions for use given on the containers.
 - We recommend the Porsche leather care product.
- ▶ Treat cleaned leather only with a leather care
 - We recommend the Porsche leather care product.

Carpets and mats

- ▶ Use only a vacuum cleaner or a medium stiff brush.
- ▶ Remove stains and spots with Porsche stain

The Porsche range of accessories includes floormats to protect the carpets in summer and winter.



Risk of an accident resulting in serious personal injury or death.

- ▶ Always check the movement of the pedals before driving and make sure that they are not obstructed by a floor mat or any other object.
- Secure the floor mat to prevent it from sliding into positions that could interfere with the safe operation of your vehicle - do not lay them loosely in the vehicle.
 - Your Porsche dealer will be glad to offer you floor mats of correct size including a securing possibility.

Cleaning airbags covers



There is a danger of serious personal injury or death if the airbag system is impaired by improper cleaning work.

- ▶ Do not make any modifications whatsoever on individual components such as the padded covers of the steering wheel, the front seats, the roof pillars and the rooflinings.
- ▶ Let your authorized Porsche dealer clean these components.

Cleaning fabric linings

Fabric linings on pillars, headliner and sun visors, etc., must be treated only using suitable cleaning agents or a suitable dry foam and a soft brush.

Cleaning Alcantara

▶ Do not use a leather care product to clean Alcantara.

For regular care it is sufficient to clean the cover with a soft brush. Heavy abrasion or rubbing when cleaning causes a permanent change in the surface.

Cleaning when lightly soiled

▶ Wet a soft cloth with water or a neutral soap solution and wipe off the dirt.

Cleaning when heavily soiled

▶ Wet a soft cloth with lukewarm water or thinned white spirit and dab the dirt from the outside in.

Cleaning safety belts

- ▶ Use mild detergent to clean soiled belts.
- ▶ When drying, avoid direct sunlight.
- ▷ Only use suitable cleaning agents.
- Do not dye or bleach the belts. The belt fabric could be weakened, thus affecting safety.

Storing your Porsche

If you intend to store your Porsche for a prolonged period, please consult your authorized Porsche dealer. The staff will be glad to advise you on the most suitable and necessary methods.

- ▷ Clean your vehicle thoroughly inside and outside. Clean the engine compartment. The under carriage and chassis components should be free of dirt and salt deposits.
- ▶ Fill up the fuel tank.
- ▷ Change the oil and oil filter, and run the engine for several minutes.
- ▶ Increase the tire pressure to 58 psi (4 bar). It is not recommended to lift the vehicle, due to the possibility of corrosion on shock absorber piston shafts. The vehicle should be moved slightly, approximately every four weeks, to prevent flat spot on the tires.

Climate control

The air conditioning system should be in good working condition and fully charged.

Windshield/Headlight washer

▶ Check and correct antifreeze/cleaning solution level as necessary.

Electrical system

- ▶ Remove the battery from the vehicle and store it in a cool dry place, not on a cement floor. When the battery is disconnected, the alarm system is deactivated.
- ▶ Recharge the battery every 3 months. If the battery remains in the vehicle with the cables connected, it is necessary to check, remove and recharge the battery every 2-3 weeks. Do not fast charge the battery.
- ▶ Please observe the chapter "CHARGE STATE" on Page 364.

Vehicle interior

The interior must be dry, especially in the area of the floor carpets. The use of drying agents (Silica-Gel) is recommended in vehicles with leather interior and in areas with high humidity. The recommended amount is 3 fabric bags of 1.1 lbs. (500 grams) each placed on the floor carpets.

▶ Windows, doors, lids and roof must be closed. The air vents should be opened.

Minor Repairs

Exercise Extreme Caution when Working	
on your Vehicle	316
Fires/Wheels	
lack	
Tool Kit	
Spacers	
Vheel Bolts	
Changing Wheels	33
Flat Tire	
Lifting the Vehicle with a Lifting Platform	
or Garage lift	33
Electrical System	
Battery	
Replacing the remote control battery	37
Emergency Starting with Jumper Cables	
Replacing Bulbs	376
Headlights	
Tail light	38
icense Plate Lights	389
Headlight Adjustment	
Bulb Chart	
Fauring	20

Exercise Extreme Caution when Working on your Vehicle



Ignoring the following instructions may cause serious personal injury or death.

- The engine compartment of any motor vehicle is a potentially hazardous area. If you are not fully familiar with proper repair procedures, do not attempt the adjustments described on the following pages.
 - This caution applies to the entire vehicle.
- Only work on your vehicle outdoors or in a well ventilated area.
- Ensure that there are no open flames in the area of your vehicle at any time when fuel fumes might be present. Be especially cautious of such devices such as hot water heaters which ignite a flame intermittently.
- Before working on any part in the engine compartment, turn the engine off and let it cool down sufficiently. Hot engine compartment components can burn skin on contact.
- Be alert and cautious around engine at all times while the engine is running.
 If you have to work on the engine while it is running, always put the parking brake on and put the gearshift lever in neutral or the selector lever in position P or N.

- In particular, be very careful to ensure that items of clothing (ties, shirt, sleeves etc.), jewelry, long hair, hand or fingers cannot get caught in the engine-compartment blower, fan, belts or other moving parts.
 - The radiator and radiator fans are in the front of the car.
 - The fans can start or continue running as a function of temperature, even with the engine switched off.
 - Carry out work in these areas only with the engine off and exercise extreme caution.
- Your Porsche is equipped with an electronic ignition system. When the ignition is on, high voltage is present in all wires connected with the ignition system; therefore, exercise extreme caution when working on any part of the engine while the ignition is on or the engine is running.
- Always support your car with safety stands if it is necessary to work under the car. The jack supplied with the car is not adequate for this purpose.

For vehicles with air suspension with level control and height adjustment:

Please observe the chapter "RAISING VEHICLE WITH THE JACK" on Page 223.

- When working under the car without safety stands but with the wheels on the ground, make sure the car is on level ground, the wheels are blocked, and that the engine cannot be started.
 Remove the ignition key.
- Do not smoke or allow an open flame around the battery or fuel.
 Keep a fire extinguisher close at hand.
- Incomplete or improper servicing may cause problems in the operation of the car. If in doubt about any servicing, have it done by your authorized Porsche dealer.
 Improper maintenance during the warranty period may affect your Porsche warranty coverage
- Supplies of fluids, e.g. engine oil, brake fluid or coolant, are hazardous to your health. Keep these fluids out of children's reach and dispose of them in accordance with the appropriate regulations.
- Some countries require additional tools and special spare parts to be carried in your vehicle.
 - Please make enquiries before driving abroad.

Notes on minor repairs

Tool kit

The tool kit is accommodated in the spare-wheel well under the cover of the loadspace floor.

Tires/Wheels

The original equipment tires and wheel rims on your Porsche comply with all applicable Federal Motor Vehicle Safety Standards.

For your safety remember the following:

- Wheel rims and wheel bolts are matched to fit your Porsche.
- If you intend to use other than original equipment wheels, be sure that they conform to
 Porsche specifications for your model. Only
 tires with the same make and with the same
 specification code (e.g. "NO", "N1"...) can be
 mounted.
- The use of wheel rims and wheel bolts that do not meet specifications of the original factory installed equipment will affect the safe operation of your vehicle and affect warranty coverage.
- Before you plan on exchanging wheels, or snow tires already mounted on the wheel rims, consult your authorized Porsche dealer.
 Your dealer has the technical information necessary to advise you which wheel rims and wheel bolts are compatible with the original factory installations.

! Danger!

Risk of loss of control and serious personal injury or death.

- If while driving, your vehicle experiences a sudden vibration or ride disturbance, and/or you suspect that possible damage to your tires or vehicle has occurred, you should immediately reduce your speed without excessive use of the brakes.
- Stop the vehicle as soon as possible, and inspect the tires.
 If you cannot determine the cause for the disturbance, have your vehicle towed to the nearest Porsche or tire dealer to have your vehicle or tire(s) inspected.
- Continuing to operate the vehicle without correction could result in a loss of control and serious personal injury.

Uniform Tire Quality Grading

Quality grades can be found where applicable on the tire sidewall between tread shoulder and maximum section width.



Example

All passenger car tires must conform to Federal Safety Requirements in addition to these grades.

Treadwear

The treadwear grade is a comparative rating based on the wear rate of the tire when tested under controlled conditions on a specific government test course. For example, a tire graded 150 would wear one and a half (1-1/2) times as well on the government course as a tire graded 100. The relative performance of tires depends upon the actual conditions of their use, however, and may depart significantly from the norm due to variations in driving habits, service practices and differences in road characteristics and climate.

Traction AA. A. B. C

The traction grades, from highest to lowest, are AA, A, B, and C and they represent the tire's ability to stop on wet pavement as measured under controlled conditions on specified government test surfaces of asphalt and concrete. A tire marked C may have poor traction performance.



The traction grade assigned to this is based on braking (straight-ahead) traction tests and does not include cornering (turned) traction, acceleration, hydroplaning or peak traction characteristics.

Temperature A. B. C

The temperature grades are A (the highest), B and C, representing the tire's resistance to the generation of heat and its ability to dissipate heat when tested under controlled conditions on a specified indoor laboratory test wheel.

Sustained high temperatures can cause the material of the tire to degenerate and reduce tire life, and excessive temperature can lead to sudden tire failure.

The grade C corresponds to a level of performance which all passenger car tires must meet under the Federal Motor Vehicle Safety Standard No. 109.

Grades B and A represent higher levels of performance on the laboratory test wheel than the minimum required by law.

! Warning!

The temperature grade for this tire is established for a tire that is properly inflated and not overloaded. Excessive speed, underinflation, or excessive loading, either separately or in combination, can cause heat buildup and possible tire failure, resulting loss of control, leading to serious personal injury or death.

Tire pressures

∕!\ Danger!

Risk of accident.

Risk of serious personal injury or death. Driving the vehicle with low tire pressure increases risk of a tire failure and resulting loss of control. Furthermore, low tire pressure increases rate of wear of the affected tires and cause damage.

- ▷ Always use an accurate tire pressure gauge when checking inflation pressures.
- ▷ Do not exceed the maximum tire pressure listed on the tire sidewall. (Also refer to "Technical data").
- ▶ Please observe the chapter "TIRE PRESSURE PLATE" on Page 321.
- Cold tire inflation pressure means: all tires must be cold, ambient temperature maximum 68°F (20°C), when adjusting the inflation pressure. Avoid sunlight striking the tires before measuring cold pressures, since the pressures would rise from temperature influence.
- ▶ Valve caps protect the valve from dust and dirt, and thus from leakage. Always screw caps tightly down. Replace missing caps immediately.
- ▶ Use only plastic valve caps.
- ▶ For safety reasons, don't use tire inflating bottles.

▶ Please observe the chapter "TIRF PRESSU-RES, COLD" on Page 406.

Each tire, including the spare (if provided), should be checked every 2 weeks when cold (68°F/20°C) and inflated to the inflation pressure recommended in this Owner's Manual or on the tire-pressure plate.

If your vehicle has tires of a different size than the size indicated in this Owner's Manual or on the tirepressure plate, you should determine the proper tire inflation pressure for those tires.

As an added safety feature, your vehicle has been equipped with a tire pressure monitoring that illuminates a low tire pressure message when one or more of your tires is significantly under-inflated. Accordingly, when the low tire pressure message illuminates, you should stop and check your tires as soon as possible, and inflate them to the proper pressure. Driving on a significantly underinflated tire causes the tire to overheat and can lead to tire failure. Under-inflation also reduces fuel efficiency and tire tread life, and may affect the vehicle's handling and stopping ability.

Please note that the tire pressure monitoring is not a substitute for proper tire maintenance, and it is the driver's responsibility to maintain correct tire pressure, even if under-inflation has not reached the level to trigger illumination of the tire pressure monitoring low tire pressure message.

For further information on the tire pressure monitoring:

▶ Please observe the chapter "SETTING TIRE PRESSURE MONITORING" on Page 155.

When tires are warm, the tire pressure is increased.

▶ Never let air out of hot tires. This could cause the tire pressure to fall below the prescribed value.


Insufficient tire pressure can cause tires to overheat and thus be damaged – even invisibly. Hidden tire damage is not eliminated by subsequently correcting the tire pressure.

Overloading



Risk of damage to vehicle parts, loss of control and serious personal injury or death.

- ▷ Do not overload your vehicle. Be careful about the roof load.
- ▷ If loading the vehicle also correct the tire pressure. Tire pressure for loaded vehicle can be found on the tire pressure plate and in the chapter technical data.
- Never exceed the specified axle load. Overloading can shorten the service life of the tires and car, as well as lead to dangerous vehicle reactions and long braking distances. Damage due to overloading is not covered by the vehicle warranty.
- ▶ Please observe the chapter "LOADING INFOR-MATION" on Page 263.



Example of a tire pressure plate

Tire Pressure plate

Information on the tire pressure plate

A Seating capacity Maximum number of vehicle occupants, including the driver.

B Vehicle load limit

Is the maximum total weight limit specified of the load (passengers and cargo) for the vehicle. This is the maximum weight of passengers and cargo that can be loaded into the vehicle. If a trailer is being towed, the trailer tongue weight must be included as part of the cargo

Please observe the chapter "LOADING INFOR-MATION" on Page 263.

- C Original tire size Size of tires mounted at the factory.
- D Recommended cold tire inflation pressure These values are for cold tires (68°F/20 °C).
- E Approved tire sizes
- F Size and tire pressure for the collapsible spare wheel

Tire traction



When driving on wet or slushy roads, a wedge of water may build up between the tires and the road. This phenomenon is known as "hydroplane" and may cause partial or complete loss of traction, vehicle control or stopping ability.

▶ Reduce speed on wet surfaces to prevent this.

Tire life

Tire life depends on various factors, i.e., road surfaces, traffic and weather conditions, driving habits, type of tires and tire care.

▶ Inspect your tires for wear and damage before driving off. If you notice uneven or substantial wear, wheels might need alignment or tires should be balanced or replaced.

Tire wear

The original equipment tires on your Porsche have built-in tire wear indicators. They are molded into the bottom of the tread grooves and will appear as approximately 1/2 in. (12 mm) bands when the tire tread depth is down to 1/16 of an in (1.6 mm).

When the indicators appear in two or more adjacent grooves, it is time to replace the tires. We recommend, however, that you do not let the tires wear down to this extent.

Worn tires cannot grip the road surface properly and are even less effective on wet roads.

In the United States, state laws may govern the minimum tread depth permissible. Follow all such laws.



Driving on worn tires can result in loss of control of the vehicle and could cause serious personal injuries or death.

- ▶ Do not drive with worn tires or tires showing cuts or bruises as they may lead to sudden deflation and loss of control which could cause severe personal injury.
- Specialized high performance tires on high performance sport utility vehicles exhibit more wear than those on a family sedan, or even a high performance sedan.

Therefore, it is important to check your tire pressure and condition at least every two weeks.

▶ If you notice that tires are wearing unevenly, consult your Porsche dealer.

Uneven wear may not always be due to improper wheel alignment. It can be the result of individual driving habits such as cornering at high speeds. If the tire pressure is not checked and adjusted regularly, abnormal tire wear can also occur.

Tire care

- ▶ Avoid damaging tires and wheel rims.
- ▶ If you must drive over a curb or other obstacle, drive slowly and at an obtuse angle.
- ▷ Check tires for uneven wear and damage before driving off.
- ▶ Remove imbedded material.
- ▶ Replace worn or damaged tires immediately.
- ▶ Keep oil, fuel, brake fluid, etc. away from tires.
- ▶ Replace missing valve stem caps.
- Keep tires inflated correctly.
- ▶ Wash tires when washing the vehicle. Also clean inner side of wheels.
- ▷ Do not use abrasive cleaners when washing the wheels.
- Check wheel rims for corrosion.
- ▶ Remove road salt, if driving in winter.

Tire damage, puncture

▶ Please observe the chapter "HIGH-PRESSURE CI FANING UNITS" on Page 307.

∕!\ Danger!

Risk of serious personal injury or death. Driving the vehicle with low tire pressure increases increases risk of a tire failure and resulting loss of control. Furthermore, low tire pressure increases rate of wear of the affected tires.

- ▷ Check tires including sidewalls regularly for foreign bodies, nicks, cuts, cracks and bulges.
- ▶ After driving off road, examine tires for signs of damage such as cuts, tears, bulges or foreign objects stuck in the tread. Replace a damaged tire if necessary.
- Cross curb edges slowly and at right angles if Avoid driving over steep or sharp curbs.
- ▷ In cases of doubt, have the wheel (particularly the inner side) checked by an authorized Porsche dealer.

In case of tire damage, where it is uncertain whether there is a break in the ply with all its consequences or tire damage caused by thermal or mechanical overloading due to loss of pressure or any other prior damage, we recommend that the tire be replaced for safety reasons.

If one faulty tire is replaced it should be noted that the difference in tread depth on one axle must not exceed 30%. Handling inconsistencies may result.

▶ Perform a visual inspection if necessary.

Tire replacements

▶ Use only tire makes and types tested by Porsche.

If you do not use a Porsche recommended replacement tire, make sure that you purchase your new tires from a reputable tire dealer and that the dealer complies with all manufacturers warnings for those tires.

Only tires with the same manufacturer and with the same specification code (e.g. "NO", "N1"...) should be mounted on the vehicle.

Before mounting new tires, check with your Porsche dealer about the current release status.

Tires should be replaced no less than on one axle at the time. Only tires of the same make and type must be used. Mixed tires are not permissible and will affect vehicle performance, safety, and can affect vehicle warranty.

Porsche dealers can recommend the most current replacement tire options for your vehicle.

Initially, new tires do not have their full traction. You should therefore drive at moderate speeds during the first 60 - 120 miles (100 - 200 km).

Tires must always remain on the same side of the vehicle.

When wheels are removed, the direction of rotation and position of each wheel should be marked.

If new tires are installed only on one axle, a noticeable change in handling occurs due to the different tread depth of the other tires. This happens especially if only rear tires are replaced. However, this condition disappears as the new tires are broken in.

▶ Please adjust your driving style accordingly.

Installation of new tires should only be done by a qualified tire technician.

Valves

- ▶ Use only plastic valve caps.
- ▶ The rubber valves must be replaced whenever the tires are changed.
- ▶ The fitting and replacement specifications must be observed for metal valves.
- ▷ Only use Original Porsche metal valves.
- ▶ Protect the valve inserts against soiling with valve caps. Soiled valve inserts can cause a gradual loss

of air.

Parking at the curb



Hard impacts against curbs (or traffic islands) are dangerous and may cause hidden tire damage which is not noticeable until later. Such damage can result in accidents at high speeds causing serious personal injury or death. Depending on the force of impact. the edge of the rim can also be damaged.

- ▶ If you are in doubt, have the wheel checked by an expert, particularly if you suspect damage on the inside.
- ▶ If you must drive over a curb or other obstacle. drive slowly and at an obtuse angle. Exercise care when parking along curbs.

Maintenance Note

Tire repairs are not permissible under any circumstances.

Wheel alignment, wheel balancing

As a precaution, have wheels with summer tires balanced in the spring, and those with mud and snow tires before winter. Unbalanced wheels may affect car handling and tire life.

Only the specified weights may be used for wheel balancing.

Self-adhesive weights must not come into contact with cleaning agents, since they could drop off. Uneven tread wear indicates wheel imbalance. In this event, the vehicle should be checked at an authorized Porsche dealer.



If, during a trip, uneven running or vibrations occur that could be caused by damage to tires or the car, the speed must be reduced immediately, but without braking sharply. If you continue your trip without having the cause of the fault remedied, you might lose control of your vehicle which could cause serious personal injury or death.

- Stop the vehicle and check the tires.
- ▶ If no cause for the fault can be found, drive carefully to the nearest authorized Porsche dealer.

Removing and storing tires

- ▶ After changing, adjust tire pressure and torque wheel bolts diagonally. Please observe the chapter "CHANGING WHEELS" on Page 332.
- Store tires in a cool and dry place. Rotate periodically to avoid flat spots.
- ▷ Avoid contact with petrol, oil and grease.

The perception that tire durability and performance are not affected by storage and age is unfounded.

Chemical additives, which make the rubber elastic. lose their effectiveness over the course of time and the rubber becomes brittle and cracks.

Therefore, the tires, especially the spare tire, should be inspected from time to time.

The age of the tire can be obtained from the "DOT" code number. If, for example, the last three numbers read 1207, then the tire was produced in the 12th week of 2007.

Example

FR (front right), FL, RR and RL.

Wheels must always be fitted in accordance with their marking.

Snow tires

The installation of Porsche approved winter tires is recommended.

Use Porsche approved winter tires for grip on snow and ice. For optimum performance, studding can be considered.

Check with your local Motor Vehicle Bureau for possible restrictions.



Risk of loss of control and damage to the vehicle as well as serious personal injury or death.

The standard tires profile and rubber mixture are optimized for wet and dry driving conditions, and may not prove favorable for snow conditions.

▶ Install winter tires before driving in such conditions.

Before mounting winter tires, consult with your Porsche dealer. He has the technical information necessary to advise you on wheel and tire compatibility.

▷ Snow tires should have the same load capacity as original equipment tires and should be mounted on all four wheels. Winter tires with studs should be run at moderate speeds when new in order to give the studs time to settle.

!\ Danger!

Risk of serious personal injury or death. Driving the vehicle with low tire pressure increases increases risk of a tire failure and resulting loss of control. Furthermore, low tire pressure increases rate of wear of the affected tires and cause damage.

Tires with badly worn treads and studs are very dangerous and could cause accidents resulting in serious personal injuries or death.

- ▶ Make sure they are replaced immediately.
- Do not exceed the winter tire speed rating.

Snow tires do not have the same degree of traction on dry, wet or snowfree roads as normal tires. Furthermore, snow tires wear rapidly under these conditions.

Winter tires do not fulfill their purpose if the tread depth is less than 5/32 in. (4 mm).

Comply with all state and local laws governing snow tire and tread depth requirements.

/!\ Danger!

Risk of accident and serious personal injury or death due to excessive speed.

- ▷ Always check the maximum speed rating on the tire sidewall on any tire on the vehicle.
- ▶ Never exceed the maximum speed rating of the tires.

Wheel change

- ▶ When wheels are removed, mark the direction of rotation and position of each wheel. Example: FR (front right), FL, RR and RL.
- ▷ Always fit the wheels in accordance with the markings.

Snow chains



Risk of damage to body, axle or brake components.

- ▶ Use only the fine-link snow chains recommended and authorized by Porsche so that sufficient clearance between the wheel well and the chain is assured.
- ▶ Please observe the chapter "TIRES, RIMS. TRACKS" on Page 403.
- ▶ Follow instructions issued by the supplier of the chains.

The best possible handling characteristics are achieved when snow chains are fitted on all four wheels of the vehicle. However, it is also possible to fit snow chains on only one axle (preferably the rear axle).

▶ Remove spacers if 18 inch tires, snow chains or a collapsible spare wheel are mounted.



Risk of damage to wheel housings if the spacers on the rear axle are not removed before fitting the snow chains.

- ▶ 17 mm spacers must always be removed from the rear axle when snow chains are to be fitted.
- ▶ For information on the spacers: Please observe the chapter "SPACERS" on Page 330. Please observe the chapter "CHANGING A WHEEL WITH REMOVAL OF 17 MM SPACER" on Page 342.
- ▶ Before fitting chains, remove accumulated ice and snow from the wheel well.
- ▶ Vehicles with snow chains must not be driven faster than 30 mph (50 km/h).

Different states and countries have varying statutory requirements regarding maximum speed.

- ▷ Check with local authorities for possible restrictions.
- ▶ Remove chains as soon as the roads are free of ice and snow.



Example of Inscription

Inscription on radial tire

A Tire size

Example: P 255/55R18 109 Y

- **P** The tire is designed for Passenger vehicle. This information is not included on all tires.
- 255 Indication of tire width in mm
- **55** Indication of tire height to tire width ratio in percent
- **R** Belt type code letter for radial

- **18** Indication of rim diameter in inches
- 109 Load capacity coefficient
- Y Speed code letter
- XL (Extra Load) Tire with increased load

B TIN (Tire Identification Number)

Example: DOT xx xx xxxx xxxx

DOT

The DOT symbol indicates that the tires comply with the requirements of the US Department of Transportation and provides information about:

- first two-digit code means manufacture's identification mark.
- second two-digit code means tire size.
- third four-digit code means tire type code.
- fourth four-digit code means date of manufac-

If, for example, the last four numbers read 1204, the tire was produced in the 12th week of 2004.

C Tire ply composition and material

The number of layers in the tread and sidewalls and their material composition.

D Maximum permissible inflation pressure

The maximum permissible cold inflation pressure to which a tire can be inflated.

▷ Do not exceed the permissible inflation pressure.

E Maximum Load rating

The maximum load in kilograms and pounds can be carried by the tire. If you replace tires always use a tire that has the same maximum load rating as the factory installed tire.

F Term of tubeless or tube tire

Identification for tubeless tires.

G Radial

The identification indicates if the tire has radial structure.

Speed code letter

The speed code letter indicates the maximum permissible speed for the tire.

This code letter is shown on the tire sidewall.

T = up to 118 mph (190 km/h)

H = up to 131 mph (210 km/h)

V = up to 150 mph (240 km/h)

W = up to 167 mph (270 km/h)

Y = up to 186 mph (300 km/h)

Tip on driving

Tires with a maximum speed rating that is lower than the specified maximum vehicle speed may be mounted only if they bear an M+S identification on the tire sidewall.

Please note that in addition to the winter tires, all-season and all-terrain tires are also subject to speed limits and bear this identification.

Inscription on light alloy wheels

Note on operation

▶ The rim width in inches G and the rim offset L are visible from the outside. This information can be found near the tire valve.



- **G** Rim width in inches
- H Rim-flange contour code letter
- I Symbol for drop-center rim
- J Rim diameter in inches
- K Double hump
- L Rim offset in mm



A - Tool box

Jack

The jack is located in tool box A under the loadspace floor.


▶ Please observe the chapter "OPENING LOADS-PACE FLOOR" on Page 239.



The jack must be used only to raise the car for wheel changing.

The jack must never be used as a support to work underneath the vehicle. If the jack is accidentally dislodged, you or bystanders could suffer severe personal injury.

- ▶ Never jack up other vehicle or other loads with the jack.
- ▶ Always place the car on stable supports if you have to work under the car. When working under the vehicle, always use safety stands specifically designed for this purpose.



Tool Kit

Tool box **A** and compressor **B** with pressure tester on non-air suspension vehicles are located under the cargo area.

Notes on operation

The screwdriver is located in the handle of the wheel bolt wrench.



A - Compressor

Compressor

On vehicles without level-control systems, there is an additional compressor with pressure tester under the loadspace floor.

▶ Please observe the chapter "CHECKING TIRE PRESSURE WITH A PRESSURE GAGE" on Page 346.

On vehicles with level control, you can use the compressor of the level-control system to fill the

The filler hose required for this purpose can be found under the left rear seat.

▶ Please observe the chapter "FOLDING REAR SEATS FORWARD" on Page 236.

Spacers

- ▶ Use the spacers only together with wheels approved by Porsche. Before having spacers fitted, find out about the current approval status.
- ▶ Remove spacers if 18 inch tires, snow chains or a collapsible spare wheel are mounted.



Risk of accident if the spacers are not removed before mounting 18 inch tires or collapsible spare wheel.

▶ 17 mm spacers are always to be removed before mounting 18 inch tires or a collapsible spare wheel, because the wheel cannot be fitted correctly.

!\ Caution!

Risk of damage to wheel housings if the spacers on the rear axle are not removed before fitting the snow chains.

▶ 17 mm spacers must always be removed from the rear axle when snow chains are to be fitted.

Note on operation

▶ To remove or mount the spacers: Please observe the chapter "CHANGING A WHEEL WITH REMOVAL OF 17 MM SPACER" on Page 342.

Please observe the chapter "FITTING THE 17 MM SPACER" on Page 343.



Wheel Bolts

▶ Always clean the wheel bolts before installing.

Maintenance Notes

- ▶ Wheel bolts must not be greased.
- Replace damaged wheel bolts.
 Only use the original Porsche wheel bolts specially designed for this vehicle type.

Tightening torque

Tightening torque of the wheel bolts and wheel nuts **118 ftlb.** (160 Nm).

Security wheel bolts

The adapter (wrench socket) for the security wheel bolts is located in the tool box.

To loosen or tighten the wheel bolt with anti-theft protection, the adapter must be used between the wheel bolt and the wheel bolt wrench.

When positioning the wrench socket, ensure that it engages fully in the teeth of the wheel bolt.

Note on operation

- On vehicles with 17 mm spacers on the rear axle, the wheels are secured with steel nuts.
 There is no anti-theft protection for the wheel nuts
- If the wheels have to be removed at the workshop, please do not forget to hand over the socket for the security wheel bolts along with the car key.

Changing Wheels



Failure to follow these instructions may result in serious personal injury or death to you or to bystanders.

Before changing the wheel

- ▷ If you have a flat tire, move a safe distance off the road. Turn the emergency flasher on and use other warning devices to alert other motorists.
- ▷ Do not park your vehicle where it may contact dry grass, brush or other flammable materials. The hot parts of the exhaust system could set such materials on fire, thereby causing both property damage and severe or fatal physical injury.
- Passengers must not be in the vehicle when it is jacked up.
- ▶ Before you change a wheel, be sure the ground is level and firm. If necessary, use a board under the jack to ensure that the jack does not sink into the ground.
- ▷ Set the parking brake and block the wheels opposite the flat tire on the other side of the vehicle.

While operating the jack

- ▶ The jack is only to be used for changing a wheel. Do not use it as a support to work under
- The car must be jacked up only at the illustrated jacking points. Lifting at any other place may damage the vehicle or may result in personal injury. Never jack the car up by the body or the bumpers.
- ▶ For safety reasons do not use tire inflating bottles. Do not use commercially available sealant bottles. Use only the tire inflating bottle located in the luggage compartment.

Sequence of operation



The iack must be used only to raise the car for wheel changing. The lack must never be used as a support to work underneath the vehicle. If the jack is accidentally dislodged, you or bystanders could suffer severe personal injury.

- ▶ Never jack up other vehicles or other loads with the jack.
- ▷ Always place the car on stable supports if you have to work under it. When working under the vehicle, always use safety stands specifically designed for this purpose.
- ▶ Please use a suitable knee rest to protect your clothing against soiling.

Flat Tire

- 1. Stop the vehicle as far away from the driving lane as possible. The car must be parked on a firm and flat
 - surface offering adequate grip.
- 2. Switch on the emergency flashers.
- 3. Fully apply the parking brake.
- 4. Shift into 1st gear or move the Tiptronic selector lever to position **P**.
- 5. Straighten the front wheels.
- 6. Withdraw the ignition key to lock the steering and prevent the engine from being started.
- 7. Have any passengers leave the vehicle.
- 8. Set up a warning triangle at a suitable distance.






Securing the vehicle against rolling

For this purpose, use the two folding wedges A secured next to the tool box.

1. You can remove the wedges after undoing the Velcro fastening.



- A Folding wedges
- 2. Unfold the wedges.
- 3. Lock them in unfolded position.




4. Place one wedge directly in front of and another directly behind the diagonally opposite wheel.

Tire sealant

The tire sealant can be used to seal small cuts, especially in the tire tread.

Sealing the tire with the tire sealant is only an emergency repair, so you can drive to the next workshop. Even with the tire air-tight, it may be used only for short trips in an emergency.



- **A** Filler bottle **B** Filler hose

On vehicles without level control, the tire sealant and a compressor with pressure tester can be found under the cargo floor in the luggage compartment.

The tire sealant comprises:

- A filler bottle
- A filler hose
- A valve turner and
- A spare valve insert.

∕!\ Danger!

Risk of accident, resulting in serious personal injury or death.

- ▶ Use the tire sealant only in the case of cuts or punctures no larger than 0.15 in. (4 mm).
- ▶ Never use the tire sealant if the rim is damaged.

∕!\ Warning!

The sealant is highly flammable and harmful to health.

- ▶ Fire, naked flame and smoking are prohibited when handling tire sealant.
- ▷ Avoid contact with skin, eyes and clothing due to caustic chemical properties of the tire sealant.
- ▶ Keep tire sealant away from children.
- ▷ Do not inhale vapours, due to consequent harm to personal health resulting in serious personal injury or death.

In case of contact with the sealant:

- ▶ If sealant gets on the skin or in the eyes, thoroughly rinse the affected part of the body off immediately.
- ▶ Change soiled clothing immediately.
- ▷ Get medical attention immediately in the event of an allergic reaction.
- ▶ If sealant was swallowed, thoroughly rinse out the mouth without delay and drink plenty of water.

Do not induce vomiting. Get medical attention immediately.



- A Filler bottle
- B Filler hose
- C Plug of the filler hose
- D Valve turner
- E Valve insert
- F Tire valve

Inserting sealant

- 1.Leave the object that caused the puncture in the tire.
- 2. Remove sealant and the enclosed sticker from the luggage compartment.
- 3. Adhere the sticker in the driver's field of vision.
- 4. Shake filler bottle A.

- 5. Screw filler hose **B** onto the filler bottle. The filler bottle is now open.
- 6. Unscrew valve cap from tire valve **F**.
- 7. Remove valve insert **E** from the tire valve with valve turner **D**.

Keep the valve insert in a clean and dry place.

- 8. Remove plug **C** of the filler hose **B**.
- 9. Push filler hose onto the tire valve.
- 10. Hold filler bottle higher than the level of the tire valve and press it together forcefully until the bottle is completely emptied into the tire.
- 11. Pull filler hose off the tire valve.
- 12. Twist the valve insert firmly into the tire valve using the valve turner.
- 13.Inflate the tire. Set the prescribed tire pressure. Please observe the chapter "TIRE PRESSU-RES, COLD" on Page 406.
- 14. Screw valve cap onto the tire valve.
- 15. Check the tire pressure after driving for around 10 minutes.

If the tire pressure is less than 22 psi (1.5 bar), do not continue driving.

If a value of more than 22 psi (1.5 bar) is indicated, correct the pressure to the prescribed value.

16. Please consult your authorized Porsche dealer.

The settings for Tire Pressure Monitoring must be update on the multi-purpose display after filling the tire with sealant.

To do this: Please observe the chapter "SETTING TIRE SEALANT/SEALING SET" on Page 163.

Car care instruction

After drying, any sealant that emerges can be peeled off like a film.



Risk of accident, resulting in serious personal injury or death.

- ▶ Have the tire replaced by a specialist workshop as soon as possible.
- Avoid hard acceleration and high cornering speeds.
- ▷ Do not exceed maximum speed of 50 mph (80 km/h).
- ▶ Please always observe the safety and operating instructions, which can be found in the separate operating instructions for the sealant and on the compressor.

Lifting the Vehicle with a Lifting **Platform or Garage lift**

- ▶ The car must be raised only at the illustrated jacking points. Please observe the chapter "LIFTING THE VEHICLE WITH A LIFTING PLATFORM OR GARAGE LIFT" on Page 337. Please observe the chapter "RAISING VEHICLE WITH THE JACK" on Page 223.
- ▶ Lifting at any other place may damage the vehicle or may result in personal injury.



Serious personal injury or death and/or serious damage to the engine or the vehicle may occur, if you lift the vehicle improperly.


- ▶ Never lift the vehicle at any other place than the jacking points.
- ▶ Never lift the vehicle by the engine, transmission or axles.
- ▶ Do not damage any sensitive components in the vicinity of the jacking points.



- A Front jacking points platform lift
- **B** Front jacking point garage lift

Platform lift

▶ Before the car is driven on to a lifting platform, it must be ensured that there is enough space between the lifting platform and the vehicle.



- **C** Rear jacking points platform lift
- **D** Rear jacking point garage lift

Garage lift

A garage lift may be used only at the illustrated jacking points.

Lifting at any other place may damage the vehicle or may result in personal injury.

Lifting the vehicle with a jack



Danger of serious personal injury or death. The car may slip off the lack.

- ▶ Make sure that no one is in the vehicle when jacking up and changing a wheel.
- ▶ Never jack up the vehicle when it is parked on a surface that slopes up, down or to the side.
- ▶ Use the jack only to raise the car for wheel changing.
- ▷ Always place the car on stable supports if work has to be carried out under the car. The car jack is not suitable for this.

Danger of injury if the level-control system operates during the wheel change.

▷ Set the car to jacking mode before raising the

Please observe the chapter "RAISING VEHICLE WITH THE JACK" on Page 223.

Risk of injury and damage if the vehicle is not secured.

- ▷ Secure the vehicle against rolling.
- ▶ Please observe the chapter "SECURING THE VEHICLE AGAINST ROLLING" on Page 333.

Maintenance Note

The jacking point on the vehicle must be free of

- 1. Slightly loosen the wheel bolts of the wheel to be changed.
- 2. Only set up the jack at the rear jacking point designed for the purpose. The jack foot must be in contact over its whole area and must be positioned directly below the head piece. Use a suitable support if necessary.
- 3. Hold jack still and wind it up until its head enters the jacking point on the vehicle. Only jack vehicle up until the wheel to be changed is completely off the ground.
- 4. After lowering the vehicle, remove the jack.



Front jacking point

Access to the jacking points differ according to the respective vehicle equipment.

Jacking points

▶ Set up jack only at the points provided **A** or **C**.





The rear jacking point is accessible after removing the covering cap **B** from the sill cover.

Removing covering cap:

▶ Pull out covering cap **B** at the bottom at the rear.

Inserting covering cap:

Insert the covering cap ${\bf B}$ in the bottom guides and push in completely until you feel the upper lugs snap into place.



Vehicles with running board Front jacking point

Jacking points for vehicles with a running board

▷ Set up jack only at the points provided **D** or **E**.



Vehicles with running board Rear jacking point



Vehicles with side member panels Front jacking point

Jacking points for vehicles with side member panels

The jacking points are accessible after removing the plastic covering caps **F** or **H** from the side member panels.

Removing covering cap:

1. Open covering cap **F** or **H** in the side member panel to the front by means of the internal handle recess and pull off (arrow).



Vehicles with side member panels Rear jacking point

2. Attach jack only at the points provided **G** or **I**. Fitting covering cap:

▷ Insert the covering cap F or H completely in the slots of the side member panel with both centring lugs and fold back until it can be felt to engage.



Wheel change

1. Remove the top wheel bolt with the wheel bolt wrench from the tool kit.



Screwing in assembly aid

- 2. Remove assembly aid from the tool kit and screw in instead of the wheel bolt.
- 3. Remove the remaining wheel bolts. Please observe the chapter "WHEEL BOLTS" on Page 331.
- 4. Change wheel.

- 5. Insert wheel bolts and tighten by hand. Remove assembly aid and screw in remaining wheel bolt. Initially tighten bolts in diagonally opposite sequence so that the wheel is centered.
- 6. Inflate the tire if necessary. Please observe the chapter "TIRE PRESSU-RES, COLD" on Page 406. In vehicles with tire pressure monitoring: Please observe the chapter "SETTING THE TIRE TYPE AND SIZE" on Page 157.
- 7. Lower car and remove jack.
- 8. Tighten wheel bolts in diagonally opposite sequence.

Tire Pressure Monitoring:

The settings on the multi-purpose display must be updated after a wheel change.

Please observe the chapter "SETTING TIRE PRES-SURE MONITORING" on Page 155.

Maintenance Note

▶ Immediately after changing a wheel, use a torque wrench to check the prescribed tightening torque of the wheel bolts (118 ftlb./160 Nm).

Changing a wheel with removal of 17 mm spacer




Risk of accident if the spacers are not removed before mounting 18 inch tires or collapsible spare wheel.

▶ 17 mm spacers are always to be removed before mounting 18 inch tires or a collapsible spare wheel, because the wheel cannot be fitted correctly.



Risk of damage to wheel housings if the spacers on the rear axle are not removed before fitting the snow chains.

- ▶ 17 mm spacers must always be removed from the rear axle when snow chains are to be fitted.
- ▶ Remove spacers if 18 inch tires, snow chains or a collapsible spare wheel are mounted.
- ▶ It is not necessary to use a assembly aid for mounting a wheel or spare wheel of the same quality.
- ▶ For information on the spacers: Please observe the chapter "SPACERS" on Page 330.




Puller

1. Remove plastic covers from the wheel nuts with the puller **D** from the toolbox.



2. Remove wheel nuts.



- 3. Unscrew the wheel bolts **A** with which the spacer is fastened.
- 4. Remove the spacer.
- 5. Remove assembly aid from the tool kit and screw in instead of the wheel bolt.
- 6. Fit wheel.
- 7. Use the wheel bolts A with which the spacer was fastened to mount the wheel. Insert wheel bolts and tighten by hand. Remove assembly aid and screw in remaining wheel bolt. Initially tighten bolts in diagonally opposite sequence so that the wheel is centred.

- 8. Inflate the tire if necessary.
 Please observe the chapter "TIRE PRESSURES, COLD" on Page 406.
 On vehicles with Tire Pressure Monitoring:
 Please observe the chapter "SETTING THE TIRE TYPE AND SIZE" on Page 157.
- 9. Lower the car and remove the jack.
- 10. Tighten wheel bolts in diagonally opposite sequence.

Maintenance Note

- Immediately after changing a wheel, use a torque wrench to check the prescribed tightening torque of the wheel bolts (160 Nm/118 ftlb.).
- ► Spacer, steel nuts, and plastic covers should be stored together.

Fitting the 17 mm spacer

- 1. Remove wheel.
- Fit the spacer with the wheel bolts A used to fasten the wheel.
 Tightening torque: 160 Nm (118 ftlb.)
- 3. Fit wheel.

To do this use the original wheel nuts for fastening the wheels.

Tightening torque: **160 Nm (118 ftlb.)** Place plastic covers onto the steel nuts.

Note

There is no anti-theft protection for the wheel nuts.

Collapsible spare wheel

The collapsible spare wheel is fastened under the floor in the luggage compartment.

On vehicles with 17 mm spacers:

▶ Before fitting a collapsible spare wheel on the rear axle always remove the corresponding spacer.

For information on the spacers: Please observe the chapter "SPACERS" on Page 330. For information about removing the spacers: Please observe the chapter "CHANGING A WHEEL WITH REMOVAL OF 17 MM SPACER" on Page 342.



- 1. Take out rotary knob **A** and put it on bolt **B**.
- 2. Unscrew the screw and take out the collapsible spare wheel.
- 3. Mount the collapsible spare wheel on the vehicle before inflating it. Leave the car jacked up. Please observe the chapter "LIFTING THE VEHICLE WITH A JACK" on Page 338.
- 4. Inflate the tire. Please observe the chapter "TIRE PRESSU-RES, COLD" on Page 406.

! Warning!

Risk of accident.

- ▶ The collapsible spare wheel must be used only over short distances in cases of emergency. For safety reasons, replace the tires **before** the wear indicators appear (webs in the tire grooves, 1/16 in. (1.6 mm) high).
- ▶ Never deactivate the Porsche Stability Management (PSM) system.
- Avoid hard acceleration and high cornering speeds.

The maximum permitted speed is **50 mph** (80 km/h) and must not be exceeded because of altered driving characteristics and for reasons of wear.

The tread depth of the spare wheel is subject to the same laws as the original tires.

- Do not use a collapsible spare wheel from a different vehicle type.
- ▷ Do not mount the collapsible spare wheel from your car on a different vehicle.
- ▷ Only fit **one** collapsible spare wheel on the vehicle at a time.
- ▷ On vehicles with air suspension, use the tire filling connection **A** only to inflate the collapsible spare wheel.
- ▶ To avoid damage, do not use automatic car washes when the spare wheel is installed.

After using the collapsible spare wheel

▶ Release air by unscrewing the valve insert.

Notes on operation

The tire will revert to its original shape only after several hours. Only then can it be stowed in the spare wheel recess in the luggage compartment.

There is a plastic sheet in the tool box to store the damaged wheel.

Maintenance Note

The collapsible spare wheel must be repaired only by the manufacturer.

▶ Please consult your authorized Porsche dealer if the collapsible spare wheel is defective.

Checking tire pressure with a pressure gage

- 1. Remove the valve stem cap from the tire.
- 2. Press the pressure gauge onto the valve stem.

Note on operation

- ▷ Do not press too hard or force the valve stem sideways, or air will escape. If the sound of air escaping from the tire is heard, reposition the pressure gauge.
- 3. Read the tire pressure on the gauge stem and compare it to the permissible tire pressure. This information can be found on the tire pressure plate in the left door aperture. Please observe the chapter "TIRE PRESSU-RES, COLD" on Page 406.
- 4. Remove the pressure gauge.

Inflating tires on vehicles without air suspension

- 1. Please follow the operating instructions on the compressor.
- 2. Screw filler hose of the compressor onto the tire valve.



3. Remove cover **A** of the engine-compartment cover.

Please observe the chapter "CONNECTING JUMPER CABLES" on Page 373.



- + = Positive terminal for jump lead starting
- = Grounding point for jump lead starting
- 4. Connect clamps of the compressor to the jump lead starting terminals. Always observe the following sequence:
- Open the cap of the positive terminal for emergency starting with jumper cables (+).
- Connect positive lead (red) to the positive terminal for emergency starting with jumper cables (+).
- Connect negative lead (black) to the negative terminal for emergency starting with jumper cables (-).

! Warning!

Danger of burning. The compressor filler hose can become hot during the inflation process.

- ▶ Wear gloves.
- 5. Switch on compressor. The required filling pressure will be reached after a few minutes.
- 6. Switch off compressor.
- 7. Check filling pressure with pressure tester. Then reduce tire pressure or add more air if necessary. Recheck the filling pressure.
- 8. Unscrew filler hose of the compressor.

Reducing filling pressure on vehicles without air suspension


- 1. Switch off compressor.
- 2. Open air bleed screw on the filling hose until the correct filling pressure is achieved.



Inflating tires on vehicles with air suspension

The bag with the tire filling hose is located under the loadspace floor in the spare-wheel recess.

- 1. Take tire filling hose out of the bag.
- 2. Remove cover in footwell of right front seat.



- **B** Screw coupling for compressor connection
- C Pressure tester
- **D** Hand valve for tire filling
- E Air bleed screw
- **F** Filler connection for tire valve
- 3. Screw screw coupling **B** into the compressor connection (in footwell of the front passenger seat).
- 4. Screw filler connection **F** onto the tire valve.

Warning!

Danger of injury and risk of damage if the operating unit is used improperly.

- ▶ Use this operating unit only to inflate or to bleed air from the tires of this vehicle.
- 5. Switch ignition on.
- 6. Press hand valve **D** until the correct tire pressure is achieved. Monitor the tire pressure with pressure tester
- **C** during the inflation process.
- 7. Unscrew the screw coupling from the compressor connection.
- 8. Unscrew filler connection from the tire valve.
- 9. Stow tire filler hose in the bag.

Note on operation

The compressor features a protective function against overheating and switches itself off automatically if necessary. The compressor must cool down for a few minutes after automatic deactivation.

Reducing tire pressure on vehicles with air suspension

Open air bleed screw E until the correct tire pressure is achieved.
 Monitor the tire pressure with pressure tester C while correcting the tire pressure.

Spare wheel



Risk of accident. The wheel and tire size and the tire quality of the spare wheel and normal wheel may differ.

If a spare wheel that differs from the normal tires is used, this may impair the driving behavior.

- ▶ The spare wheel must be used only over short distances in cases of emergency. For safety reasons, replace the tires before the wear indicators appear (webs in the tire grooves, 1/16 in. (1.6 mm) high).
- ▶ Never deactivate the Porsche Stability Management (PSM) system.
- ▶ If the tire on the spare wheel is older than 4 years, the spare wheel should be used only in the event of a flat.
- ▶ Avoid hard acceleration and high cornering speeds.

The maximum permitted speed is **50 mph** (80 km/h) if the mounted spare wheel differs from the other three wheels on the car. This maximum speed must not be exceeded because of altered driving characteristics and for reasons of wear.

- ▷ Do not use a spare wheel from a different vehicle type.
- ▷ Do not mount the spare wheel from your car on a different vehicle.

Removing spare wheel



Danger of injury if the spare wheel is removed improperly.

- ▶ Remove the spare wheel only when the spare wheel bracket is locked.
- ▶ Remove the spare wheel from the spare wheel bracket with care. The wheel is very heavy [approx. 77 lbs. (35 kg)].
- 1. Unscrew all five wheel bolts.
- 2. Remove the top wheel bolt. Remove assembly aid from the tool kit and screw in instead of the wheel bolt. Remove the remaining wheel bolts.



Fitting spare wheel

- ▷ Insert wheel bolts and tighten by hand. Remove assembly aid and screw in remaining wheel bolt. Initially tighten bolts in diagonally opposite sequence so that the wheel is centerd.
- ▶ Please observe the chapter "TIRE PRESSU-RES, COLD" on Page 406.
- ▶ After mounting the wheel, tighten all five wheel bolts to 111 ftlb. (150 Nm).

350 Minor Repairs



B - Button for unlocking the spare wheel bracket

Opening spare wheel bracket



Danger of injury and risk of accident if the spare wheel bracket is operated improperly.

- ▶ Make sure that no persons or animals are within the range of movement of the spare wheel bracket. Operate the spare wheel bracket only using button **B**.
- ▶ If the vehicle is inclined to the side, the additional lock C on the spare wheel bracket must be operated.


Precondition

The central locking system must be unlocked.

▶ Press button **B** and swing the spare wheel bracket open.

Notes on operation

- If the opening angle **exceeds 30°**, the spare wheel bracket automatically moves to final position.
- The rear lid may be opened only when the spare wheel bracket is in final position.
- ▶ If the opening angle is **less than 30°**, the spare wheel bracket automatically moves back to its initial position.
 - However, the spare wheel bracket is not completely engaged yet and must be closed by hand.



C - Additional lock

Operating the additional lock of the spare wheel bracket if the vehicle is tilted to the side

- 1. Open spare wheel bracket.
- 2. Slide additional lock **C** to the left. The spare wheel bracket is mechanically

The warning light "rear lid" and a message on the multi-purpose display of the instrument panel warn the driver that the spare wheel bracket is open.

Closing spare wheel bracket




Danger of injury and risk of accident if the spare wheel bracket is operated improperly.

- ▷ Operate the spare wheel bracket only using button **B**.
- ▷ If the vehicle is tilted to the side, more effort will be required to swing the spare wheel bracket.
- ▶ Make sure that no persons or animals are within the range of movement of the spare wheel bracket.
- 1. Check whether additional lock **C** is engaged. If necessary, slide additional lock **C** to the right.
- 2. Swing spare wheel bracket closed with force.
- 3. Check lock and observe indication on the multipurpose display of the instrument panel. The indicator light must go out when the spare wheel bracket is locked.

Automatic locking

In the multi-purpose display of the instrument panel, you can set different variants of locking and unlocking the doors and the rear lid as well as the check-back signal when locking and unlocking the vehicle and save them on the respective remote control.

▶ Please observe the chapter "SETTING REAR LID LOCKING" on Page 168.



D-Towing lug cover (left) **E**-Emergency release cable

Emergency release for the spare wheel bracket

If the battery is flat, the only way to open the spare wheel bracket is by using the mechanical emergency release.

! Warning!

Danger of injury and risk of accident if the spare wheel bracket is operated improperly.

▶ Perform emergency unlocking of the spare wheel bracket only when the vehicle is on a level surface.

- 1. Remove cover of left towing lug **D**.
- 2. Pull emergency release cable **E** in the direction of the arrow.

The spare wheel bracket is now unlocked and can be operated.

352 Minor Repairs

Electrical System

In order to avoid damage and faults in electrical or electronic systems, electrical accessories should be installed at your authorized Porsche dealer.

▶ Use only accessories authorized by Porsche.



∕!\ Warning!

Risk of short circuit and fire, resulting in serious personal injury or death. Replacing fuses or relays with engine running or the ignition on could cause electrical

▷ Disconnect the battery during all work on the electrical system.

Relays

Relays should be checked or changed only by an authorized workshop.

Alarm system, central locking

The status of the central locking and alarm system is not changed by disconnecting the battery. When the battery is disconnected, the alarm system ceases to function.



Sockets

The assignment and number of sockets depend on the respective vehicle equipment.

Electrical accessories can be connected to the 12 V sockets.



Note on operation

The sockets and thus the connected electrical accessories will function even if the ignition is swi tched off or the ignition key is withdrawn. If the engine is not running and the accessories are switched on, the vehicle battery will be discharged. Do not operate additional accessories for more than 5 minutes when engine is off.

Changing fuses

In order to prevent damage to the electrical system due to short circuits and overloads, the individual circuits are protected by fuses.

One fuse box is in the engine compartment. Two additional fuse boxes are located in the outer ends of the dashboard.

- 1. Switch off the consumer with the defective fuse. Before replacing a fuse, switch off all electrical consumers and remove the ignition key.
- 2. Open the fuse-box lid.
- 3. Remove the corresponding fuse from its slot to check it using the plastic gripper. A blown fuse can be identified by the melted metal strip.
- 4. Replace only with fuses of the same rating.

Note

If a fuse blows repeatedly, please consult an authorized Porsche dealer immediately, so that the short circuit can be located and corrected.

▶ Never try to "repair" fuses: you may cause serious damage to other parts of the electrical system.



Cover of engine-compartment fuse box

Opening fuse-box lid in engine compartment

1. Rotate the turn-locks 90° anti-clockwise with a screwdriver and remove the cover.



Fuse box in engine compartment

2. Rotate the turn-locks of the fuse-box lid 90° anti-clockwise with a screwdriver and remove the lid.



Opening fuse-box lid in the dashboard

 Carefully pry off the plastic cover with a screw-driver (arrow) and remove. The fuse plan is located on the inside of the cover.



- A Fuse puller
- 2. Remove the fuses carefully with the fuse puller **A**.

Fuse assignment – fuse box in left side of dashboard

No.	Designation	Rating in A
1	Center console socket, cigarette lighter	20
2	Parking heater radio receiver	5
3	Socket in passenger footwell	20
4	Parking heater	20
5	Sockets in luggage compartment	20
6	not used	
7	Diagnostic socket, rain sensor, light sensor	5
8	Wiper motor for windshield	30
9	Vehicle electrical system control unit, pump for washer fluid	15
10	Power window, rear left	25
11	Central locking system, left	15
12	not used	
13	not used	
14	Power window, front left	25
15	Tail light, right	15
16	Vehicle electrical system control unit, horn	20
17	Vehicle electrical system control unit, left direction indicator, right side marker light, left low beam	30
18	Headlight washer system	20
19	Vehicle electrical system control unit, interior light	5
20	Instrument lighting, left fog light, left additional high beam	30
21	not used	

No.	Designation	Rating in A
22	Rear differential lock, automatic rear lid	30
23	Differential lock	10
24	Tire Pressure Monitoring	5
25	not used	
26	Engine control unit (engine management, radiator fans), airbag, instrument panel	10
27	not used	
28	not used	
29	not used	
30	not used	
31	not used	
32	not used	
33	Steering column module	15
34	Passenger compartment monitoring, inclination sensor	5
35	Vehicle electrical system control unit, right fog light, right additional high beam	30
36	Electrical seat adjustment, left	10
37	not used	
38	not used	
39	Heated rear window	5
40	Instrument panel, diagnosis	5
41	Steering column lock, ignition lock, central locking system, Porsche Entry & Drive	15
42	Sliding/lifting roof or Panorama roof system	30
43	Subwoofer	30
44	Electrical seat adjustment, left; electrical steering column adjustment	30

No.	Designation	Rating in A
45	Seat heating, rear	30
46	not used	
47	Rear differential lock	10
48	not used	
49	Servotronic	5
50	not used	
51	Air conditioner, diagnosis, moving-off assistant	5
52	Rear wiper	30
53	Vehicle electrical system control unit, automatic low beam, steering column module	5
54	Headlight beam adjustment	10
55	not used	
56	Fan, front air-conditioning system	40
57	Fan, rear air-conditioning system	40
RES 1	Spare fuse 1	
RES 2	Spare fuse 2	

Fuse assignment – fuse box in right side of dashboard

No.	Designation	Rating in A
1	Trailer coupling	15
2	ParkAssist	5
3	Trailer coupling	15
4	Telephone/telematics	5
5	Trailer coupling	15
6	Porsche Stability Management (PSM)	30
7	Transfer box (center-differential lock), telephone preparation	5
8	Vehicle electrical system control unit, left side marker light, right turn signal, right low beam	30
9	CD changer, DVD navigation	5
10	TV tuner, satellite receiver	5
11	Radio or Porsche Communication System (PCM)	10
12	Amplifier for sound package	30
13	not used	
14	Tail light, left	15
15	Power window, rear right	25
16	not used	
17	not used	
18	Heated rear window relay	30
19	Trailer coupling	25
20	not used	
21	Spare wheel release, horn for alarm system	10

No.	Designation	Rating in A
22	Electrical seat adjustment front right, front seat heating	30
23	Air conditioner	10
24	Seat memory, front right; electrical seat adjustment, front right	30
25	Air conditioner, rear	5
26	Xenon headlight, right	10
27	Level control	15
28	not used	
29	Transmission control unit, Tiptronic selector lever switch	10
30	Rear lid power closing mechanism	20
31	Central locking system, filler flap	15
32	Central locking system, right doors	10
33	not used	
34	Power window, front right	25
35	Electrical seat adjustment, right	10
36	Roof console, telephone, compass	5
37	Xenon headlight, left	10
38	Porsche Stability Management	10
39	Diagnosis	5
40	Transfer box (center-differential lock)	10
41	Trailer coupling	10
42	Roof module	5
43	Reversing light	5
44	Heatable washer nozzles, air suspension, seat heating	5

No.	Designation	Rating in A
45	not used	
46	not used	
47	Telephone preparation	10
48	Level control	10
49	Telephone, anti-dazzle interior mirror	5
50	not used	
51	Tiptronic transmission	15
52	Tiptronic selector lever switch	5
53	not used	
54	not used	
55	Reversing camera	5
56	Porsche Stability Management (PSM)	40
57	Transfer box (center-differential lock)	40

Fuse assignment – fuse box in Cayenne engine compartment

No.	Designation	Rating in A
1	Fan	60
2	Fan	30
3	not used	
4	not used	
5	not used	
6	not used	
7	Ignition coils	15
8	Ignition coils	15
9	Engine control unit, high-pressure fuel injectors, throttle adjusting unit	20
10	Water run-on pump, tank leakage detection, carbon canister shut-off valve, fan, pressure sensor for air conditioner	10
11	Air-conditioning compressor, service interval sensor, crankcase vent	10
12	Camshaft adjustment, tank vent, quantity control valve	15
13	Fuel pump, right	15
14	Fuel pump, left	15
15	Engine control unit, main relay	10
16	not used	
17	Oxygen sensors ahead of catalytic converter	15
18	Oxygen sensors behind catalytic converter	7,5

Note

▶ Use the plastic grippers from the fuse boxes in the dashboard to replace the fuses.

Fuse assignment – fuse box in Cayenne S engine compartment

No.	Designation	Rating in A
1	Fan	60
2	Fan	30
3	not used	
4	not used	
5	not used	
6	not used	
7	Ignition coils	15
8	Tank vent, air-conditioning compressor, intake pipe switchover, crankcase vent	15
9	Quantity control valve, camshaft adjuster, valve lift adjuster	15
10	Engine components: Cooling air output stages, carbon canister shut-off valve, pressure sensor for air conditioner, tank leakage detection, exhaust flap control valve, Hall sensor, oil-level sensor	10
11	Engine control unit, high-pressure fuel injectors, throttle adjusting unit	20
12	not used	
13	Fuel pump, right	15
14	Fuel pump, left	15
15	Engine control unit, main relay	10
16	not used	
17	Oxygen sensors ahead of catalytic converter	15
18	Oxygen sensors behind catalytic converter	7,5

Note

Use the plastic grippers from the fuse boxes in the dashboard to replace the fuses.

Battery



Risk of short circuit and fire, resulting in serious personal injury or death.

- ▷ Observe all warning notes on the battery.
- ▷ Disconnect the battery during all work on the electrical system.
- ▷ Do not lay tools or other metal objects on the battery as they could cause a short circuit across the battery terminal.

Hydrogen gas generated by the battery could cause an explosion, resulting in serious personal injury or death.

- ▷ Charge battery in a well vetilated area.
- ▶ Never charge a frozen battery. It may explode because of gas trapped in the ice. Allow a frozen battery to thaw out first.
- ▷ Do not expose the battery to an open flame, electrical spark or a lit cigarette.

Risk of explosion as a result of static charge, resulting in serious personal injury or death.

- ▷ Do not wipe the battery with a dry cloth.
- ▶ Before touching the battery, discharge any static electricity by touching the vehicle.

Risk of serious personal injury or death and damage to the fabric, metal or paint.

- ▶ Wear eye protection.
- ▷ Do not allow battery acid to come in contact with your skin, eyes, fabric or painted surfac-
- ▶ If you get electrolyte, which is an acid, in your eyes or on your skin, immediately rinse with cold water for several minutes and call a doctor.
- ▷ Spilled electrolyte must be rinsed off at once with a solution of baking soda and water to neutralize the acid.

Battery posts, terminals and related accessories contain lead and lead compounds. chemicals known to the State of California to cause cancer and reproductive harm.

Always protect your skin by washing thoroughly with soap and water.

Charge state

A well charged battery will not only prevent starting problems but will also last longer.

In order to avoid unintended battery discharge

- ▷ Switch off unnecessary electrical loads in city traffic. on short trips or in a line of traffic.
- Always remove the ignition key from the ignition switch when leaving the vehicle or switch ignition off in vehicles with Porsche Entry & Drive.
- ▶ Avoid using the Porsche Communication Management system and the audio system when the engine is not running.

Battery care

- ▶ Ensure that battery is securely mounted.
- ▶ Keep terminals and connections clean and properly tightened. Corrosion can be prevented by coating the terminals and connections with petroleum jelly or silicone spray.
- ▶ Ensure that vent caps are securely tightened to prevent spillage.

Checking the electrolyte fluid level (only on low-maintenance batteries)

Generally, the electrolyte level must be checked more often in summer than in the winter, and more often when driving long distances.

- ▶ When adding water, use only clean containers. In no case may alcohol (e.g. window cleaner residues) be permitted to enter the battery.
- ▶ Unscrew and open the filler vent caps of each

With the car on a level surface, the fluid level should meet the indicator mark in each cell.

▶ If necessary, top up with distilled water. Do not use acid. Only fill up to the mark, otherwise the electrolyte will overflow when the battery is being charged and cause damage.

Winter operation

During the winter months, battery capacity tends to decrease as temperatures drop. Additionally, more power is consumed while starting, and the headlights, heater, rear window defogger, etc... are used more frequently.

Let your Porsche dealer test the battery's capacitv before winter sets in.

Vehicle storage

If the car stands for long periods in the garage or workshop, the doors and lids should be closed.

▶ Remove the ignition key and, if necessary, disconnect the battery.

Notes on operation

- ▶ When the battery is disconnected, the alarm system ceases to function. If the vehicle was locked before the battery was disconnected, the alarm will be triggered when the battery is reconnected. To deactivate the alarm system:
- ▶ Lock the vehicle and unlock it again.

Maintenance Notes

Even if you put your vehicle out of operation, the battery still discharges.

The battery will discharge more quickly if your vehicle is not driven on a daily basis over a distance of several miles. The more often you drive your vehicle, and the longer the distance driven on each trip, the more opportunity the vehicle's charging system will have to recharge the batteries.

- ▶ To preserve its efficiency, charge the battery about every 6 weeks.
- ▷ Check the battery acid level and top off with distilled water if necessary.
- Store a battery that has been removed in a dark, cool place, but not subject to freezing.

Replacing the battery

The service life of the battery is subject to normal wear; it depends greatly on care, climatic conditions, and driving conditions (distances, loads).

- ▷ Only use an original Porsche battery, with the correct part number, as a replacement. Only this battery meets the specific requirements of the vehicle.
- Please observe the disposal instructions for batteries.

Putting vehicle into operation

After the battery is connected or after a **completely discharged** batterie is charged, the PSM warning light lights up on the instrument panel and a message appears on the multi-purpose display of the instrument panel to indicate a fault.

This fault can be remedied with a few simple steps:

- Start the engine.
 To do this, turn the ignition key or the control unit (on vehicles that have Porsche Entry & Drive) to ignition lock position 2 twice.
- Perform a few steering movements and drive a short distance in a straight line until the PSM warning light goes out and the message is erased from the memory of the multi-purpose display of the instrument panel.
- If the warnings does **not** go out, then:
 Drive carefully to the nearest authorized Porsche dealer.
 Have the fault remedied by an authorized Porsche dealer.
- 4. After the warnings disappear: Stop the vehicle in a suitable place.
- Perform adaptation of the power windows: Please observe the chapter "STORING FINAL POSITION OF THE DOOR WINDOWS" on Page 109.

 On vehicles with tire pressure monitoring: Please observe the chapter "SETTING THE TIRE TYPE AND SIZE" on Page 157.

Removing and installing battery



Risk of short circuit and explosion, resulting in serious personal injury and death.
Risk of damage to the alternator and electronic control units.

- Have the battery removed and installed only by a qualified professional.
- ▶ Do not disconnect battery while the engine is running.
- Disconnect and connect the battery only with the greatest care. Danger of short circuit and explosion.
- ▶ Do not tilt the battery when removing it. Risk of caustic burns from escaping acid.

The battery is located in the battery box under the left front seat.

If the battery is completely discharged, the vehicle must be provided with external power at the jumplead starting points so that you can move the seat.

Please observe the chapter "EMERGENCY STARTING WITH JUMPER CABLES" on Page 372.

Maintenance note

The seat mounting bolts must be replaced each time they are loosened.

The bolts are micro-encapuslated and keep dust and water out.

If this is not observed, it might not be possible to attain the prescribed tightening torque of **37 ftlb** (50 Nm).



Removing battery


- 1. Switch off all electrical loads and withdraw the ignition key.
- 2. Move the left front seat all the way back and Move the backrest fully upright.
- 3. Unclip front seat trim **A**.



4. Fold sections of floor carpet forward. Unscrew both screws **B** of the seat mounting.



5. Tilt the seat all the way back. With the seat tilted back, use the fore-and-aft adjustment to move the seat forward again.




- 6. Open the 4 clamps **C** of the battery-box lid with a screwdriver.
- 7. Remove the battery-box cover with ventilation duct.

! Danger!

Risk of short circuit and explosion, resulting in serious personal injury and death.
Risk of damage to the alternator and electronic control units.


- ▷ Disconnect the negative (-) cable first, and then the positive (+) cable.
- 8. Disconnect the negative cable.
- 9. Disconnect the positive cable.

368 Minor Repairs



- 10.Pull off vent hose **D** on the battery
- 11.Unscrew screw **E** of the battery fastening plate.

Remove battery fastening plate.




12.Unscrew screw **F** of the bracket. Remove bracket.




Danger of caustic burns, explosion and risk of injury. Contact with battery acid will burn your eyes and skin.

- Lift battery out of the battery box using the folding handles.
 Try not to tip the battery.
- 13.Lift battery out of the battery box using the folding handles. Try not to tip the battery.




Installing the battery

- 1. Danger of caustic burns! Place battery in the battery box without tipping it if possible.
- 2. Push battery forwards and toward the center of the vehicle until it is under the stops G.



- ▶ Always tighten all screws to the prescribed torque.
- 3. Fasten the battery fastening plate with screw **E.** Tightening torque 15 ftlb. (20 Nm).
- 4. Fasten the bracket with screw F. Tightening torque 6.5 ftlb. (9 Nm).
- 5. **Important:** Do not forget to connect vent hose **D** to the battery. Make sure that both ends of the vent hose are properly connected.



! Danger!

Risk of short circuit and explosion, resulting in serious personal injury and death. Risk of damage to the alternator and electronic control units.

- ▷ Connect the positive (+) cable first, and then the negative (-) cable.
- 6. Connect the positive cable.
- 7. Connect the negative cable.
- 8. Put on the battery-box cover carefully. Ensure that the ventilation duct is properly inserted.



- 9.Engage the 4 clamps **C** on the battery-box lid and close them with a screwdriver.
- 10. With the seat tilted back, use the fore-and-aft adjustment to move the seat back. Tilt the seat forward.
- 11. Clean threaded holes on the seat mounting.
- 12.Use only new bolts **B** (the bolts are micro-encapsulated).

Insert bolts **B** and screw them in a few turns by hand.

Tighten bolts.

Tightening torque 37 ftlb. (50 Nm).

- 13.Clip in front seat trim.
- 14. Move seat to normal position.

370 Minor Repairs



Replacing the remote control battery

Note

Please dispose of batteries in compliance with any and all government regulations.

Vehicle key

If the battery in the remote control becomes tooweak, a warning will appear on the multi-purpose display in the instrument panel. The battery should be changed in this case.

Changing the battery

1. Carefully pry out the lid on the back of the key housing with a small screwdriver.

- Replace battery (observe polarity).
 A replacement battery is available from your authorized Porsche dealer.
- 3. Replace cover and press together firmly.

Parking heater remote control

The battery should be changed when the range of the remote control becomes smaller or when the light-emitting diode lights up orange when the remote control is operated.

Emergency Starting with Jumper Cables

If the battery is discharged, e.g. in winter or after the car has been parked for a long time, the battery of another car can be used for starting with the help of jumper cables.

Make sure the voltage of both batteries is the

The capacity (Ampere hours, Ah) of the booster battery must not be substantially less than that of the discharged battery. The discharged battery must be correctly connected to the vehicle's electrical system.

▶ Please observe the chapter "BATTERY" on Page 364.

Note

Do not try to start the car by pushing or towing. Damage to the catalytic converters and other components of the car may result.



Risk of short circuit, damage and explosion. resulting in serious personal injury or death.

- ▶ Use only iumper cables of adequate diameter cross-section and fitted with completely insulated alligator clips.
- ▶ Follow all warnings and instructions of the jumper cable manufacturer.
- ▶ When connecting jumper cables, make sure that they cannot get caught in any moving parts in the engine compartment. The jumper cables must be long enough so that neither vehicles nor cables touch another.
- ▶ The vehicles must not be in contact, otherwise current might flow as soon as the positive terminals are connected.
- ▶ The cable clamps must not be allowed to contact each other when one end of the jumper cables are connected to a battery.
- ▷ Carefully ensure that tools or conductive iewelery (rings, chains, watch straps) do not come into contact with the positive jumper cable or the positive battery post.
- ▶ Improper hook-up of jumper cables can ruin the alternator.

Danger of caustic burns.

▷ Do not lean over the battery.

Danger of gas explosion.

- ▶ Improper use of booster battery to start a vehicle may cause an explosion, resulting in serious personal injury or death.
- ▶ Keep sources of ignition away from the battery, e.g. open flame, burning cigarettes or sparking due to cable contact or welding work.
- ▷ A discharged battery can freeze even at 14°F (-10°C). Before connecting jumper cables, a frozen battery must be thawed out.





- 8. Disconnect the positive jumper cable from the positive terminal of the donor battery first, then from the positive terminal for jump starting (+).
- 9. Close the cap of the positive terminal for jump starting (+).

Connecting jumper cables

Always observe the sequence below:

- 1. Remove cover A.
- 2. Open the cap of the positive terminal for jump starting(+).
- 3. Attach the positive lead first to the positive terminal for jump starting (+), then to the positive terminal of the donor battery.
- 4. Connect the negative lead first to the negative terminal of the donor battery, then to the grounding point for jump starting (-).

- + = Positive terminal for jump starting- = Grounding point for jump starting
- 5. Run the engine of the donor car at a higher speed.
- 6. Start the engine. An attempted start using jumper cables should not last more than 15 seconds. Then allow a waiting period of at least one minute.
- 7. Disconnect the negative jumper cable from the ground point for jump starting (-) first, then from the negative terminal of the donor battery.

Battery charging

Automotive batteries loose their efficiency when not in use. The charge available in your battery can be measured with a battery hydrometer. We recommend that the battery voltage be tested by your Porsche dealer who has the appropriate equipment.

If the car is not driven for prolonged periods, the battery must be charged at least every 6 weeks. A discharged battery allows rapid formation of sulfates, leading to premature deterioration of the plates.



Hydrogen gas generated by the battery could cause an explosion, resulting in serious personal injury or death.

- ▷ Charge battery in a well ventilated area.
- ▶ Never charge a frozen battery. It may explode because of gas trapped in the ice. Allow a frozen battery to thaw out first.
- ▶ If you get electrolyte, which is an acid, in your eyes or on your skin, immediately rinse with cold water for several minutes and call a doctor.

Note

Your authorized Porsche dealer will be pleased to advise you about a suitable charger.

Slow battery charging

- 1. Pay attention to all warnings and follow instructions that come with your battery charger.
- 2. When charging, ensure adequate ventilation.
- 3. Remove battery. Please observe the chapter "REMOVING AND INSTALLING BATTERY" on Page 366.
- 4. All vent caps should be open. The fluid level should meet the indicator mark in each cell.
- 5. Ensure that charger is switched off danger of short circuit!
- 6. Connect charger cables. Charger cables must be connected POSITIVE (+) to POSITIVE (+) and NEGATIVE (-) to NEGATIVE (-).
- 7. Switch on charger. Normally, a battery should be charged at no more than 10 percent of its rated capacity. Rated capacity of the battery in your vehicle is listed on the battery housing.
- 8. After charging, turn off charger and disconnect charger cables.
- 9. Tighten the vent caps and reinstall battery. Please observe the chapter "REMOVING AND INSTALLING BATTERY" on Page 366.

Charging the battery

Your authorized Porsche dealer will be pleased to advise you about a suitable charger.

- 1. Always observe the instructions of the charger manufacturer.
- 2. When charging the battery, ensure adequate ventilation.
- 3. Check the acid level of a low-maintenance battery.
- 4. Connect charger to the jump starting points. Only plug into the mains and switch the charger on when it has been correctly connected up.
- 5. After charging, disconnect the charger.
- 6. Check the acid level of a low-maintenance battery.

After charging the battery

After the battery is connected or the **completely** discharged battery is charged, the PSM warning light lights up on the instrument panel and a message appears on the multi-purpose display of the instrument panel to indicate a fault.

This fault can be remedied with a few simple steps:

- 1. Start the engine. To do this, turn the ignition key or the control unit (on vehicles that have Porsche Entry & Drive) to ignition lock position 2 twice.
- 2. Perform a few steering movements to the left and to the right when vehicle is standing and drive a short distance in a straight line until the PSM warning light goes out and the message is erased from the memory of the multi-purpose display of the instrument panel.
- 3. If the warnings does **not** go out, then: Drive carefully to the nearest authorized Porsche dealer. Have the fault remedied by an authorized Porsche dealer.

- 4. After the warnings disappear: Stop the vehicle in a suitable place.
- 5. Perform adaptation of the power windows: Please observe the chapter "STORING FINAL POSITION OF THE DOOR WINDOWS" on Page 109.
- 6. On vehicles with tire pressure monitoring: Please observe the chapter "SETTING THE TIRE TYPE AND SIZE" on Page 157.

Replacing Bulbs



Danger of short circuit.

▷ Always switch off the relevant consumer when changing bulbs.

Risk of serious personal injury or death. The headlights are under high voltage when installed.

▷ Exercise extreme caution when working in the area of the headlights.

Risk of damage. Bulbs of a higher wattage can damage the light housing.

- ▷ Only use the bulbs specified in the bulb chart.
- ▶ Bulbs must be clean and free from oil, grease or fingerprints.
- ▶ Never touch bulbs with your bare hands. Use a cloth or soft paper when replacing bulbs.
- ▷ Always carry spare bulbs with you. In certain countries, the carrying of spare bulbs is mandatory.



Risk of damage to headlights due to excessive temperatures and abrasion.

- ▷ Attach no coverings (e.g. films, "stone guards") in the area of the headlights.
- ▷ Use soapy water only to clean light lenses and plastic headlight lenses. In no case may chemical cleaners or other volatile cleaning fluids be used.
- ▶ To prevent scratches, do not rub with a dry or merely moist cloth, tissue or insect sponges.

Headlights

Note

The headlights can mist up depending on the temperature and humidity.

▷ To ensure optimum ventilation, do not cover the gap between headlight and body.




Removing headlights

- 1. Switch off ignition and withdraw the ignition key.
- 2. Open lid.
- 3. Press down cover **A** in the engine compartment in the direction of the arrow and remove.



- **B** Headlight release **C** Socket wrench
- 4. Take socket wrench C out of the tool kit.
- 5. Place socket wrench **C** on the release **B** and turn in the direction of the arrow until you feel and hear the headlight being released.





- 7. Press back the release tab of the plug **D** and pull plug off.
- 8. Pull out headlight completely.



- A Cover C Socket wrench D Plug

Installing headlights

- 1. Insert headlight in the guide rails, connect plug **D** and then push the headlight fully into the fender.
- 2. Push headlight to the rear and simultaneously turn socket wrench **C** in the direction of the
 - The headlight locking device must perceptibly and audibly engage.
- 3. Check whether the headlight is seated securely.

- 4. Remove socket wrench C and replace in tool kit.
- 5. Fit cover **A** and fold it down.
- 6. Close lid.




Halogen headlights

Changing bulb for low beam/high beam

1. Press down both release tabs ${\bf A}$ and remove cover.



2. Turn bulb socket **B** counter-clockwise and remove.



- 3. Remove defective bulb and replace.
- Insert bulb socket and turn in clockwise direction.
 Make sure that the bulb is installed in the correct position.
- 5. Fit cover on headlight.
 Both release tabs must be fully engaged.
- 6. Install headlight.
- 7. Check operation of bulbs.
- 8. Close lid.




Changing bulb for additional high beam

1. Press down both release tabs **A** and remove cover.



2. Turn bulb socket **B** counter-clockwise and remove.



- 3. Remove defective bulb and replace.
- 4. Insert bulb socket and turn in clockwise direction. Make sure that the bulb is installed in the correct position.
- 5. Fit cover on headlight.
 Both release tabs must be fully engaged.
- 6. Install headlight.
- 7. Check operation of bulbs.
- 8. Close lid.



Bi-xenon headlights with cornering light

Changing gas discharge lamp for low beam/ high beam/dynamic cornering light

1. Press down both release tabs **A** and remove cover.



2. Turn gas discharge lamp counter-clockwise and remove.



- 3. Press the release tab on the plug and pull plug
- 4. Connect plug to new gas discharge lamp.
- 5. Insert gas discharge lamp and turn in clockwise direction. Make sure that the bulb is installed in the correct position.
- 6. Fit cover on headlight. Both release tabs must be fully engaged.
- 7. Install headlight.
- 8. Check operation of bulbs.
- 9. Close lid.



Changing bulb for additional hiBgh beam

1. Press down both release tabs **A** and remove cover.



2. Turn bulb socket **B** counter-clockwise and remove.



- 3. Remove defective bulb and replace.
- 4. Insert bulb socket and turn in clockwise direction. Make sure that the bulb is installed in the correct position.
- 5. Fit cover on headlight. Both release tabs must be fully engaged.
- 6. Install headlight.
- 7. Check operation of bulbs.
- 8. Close lid.



Changing lamp for static cornering light

1. Press down both release tabs **A** and remove cover.



2. Turn bulb socket **B** counter-clockwise and remove.



- 3. Pull both release tabs on the plug apart, and pull plug out of lamp socket.
- 4. Replace defective bulb. Make sure that the bulb is installed in the correct position.
- 5. Fit cover on headlight. Both release tabs must be fully engaged.
- 6. Install headlight.
- 7. Check operation of bulbs.
- 8. Close lid.



Changing bulb for turn signal and side marker light

- ▶ Please observe the chapter "REMOVING HEADLIGHTS" on Page 377.
- 1. Open lid.
- 2. Remove headlight.
- 3. Press release tab on the bulb housing in the direction of the arrow and at the same time push forward to the first detent A.



4. Press release tab **A** in direction of arrow again and push forward. Using your other hand, pull the bulb housing completely out of the front apron.



Replacing side marker light bulb

5. Pull bulb socket out of the bulb housing.







- 6. Remove the defective bulb from the socket and replace.
 - When inserting the socket in the bulb housing, make sure that the socket has engaged fully.

Changing turn signal bulb

- 1. Turn socket counter-clockwise and remove.
- 2. Replace the defective bulb (bayonet fitting).
- 3. Insert socket and turn in clockwise direction. Make sure that the bulb is installed in the correct position.

Installing bulb housing

- 1. Insert the bulb housing in the front apron. Make sure that the two tabs are inserted correctly in the openings. Push light fully into the front apron until you hear and feel it engage.
- 2. Check operation of lights.
- 3. Install headlight.
- 4. Close lid.

Tail light

Removing tail light


As a result of the design, a relatively large amount of effort is required to remove the tail light. In case of doubt, please consult a qualified specialist workshop.




- 1. Switch ignition off.
- 2. Open rear lid.
- 3. Remove the two caps **A** with a screwdriver, for example.



4. Unscrew the two fastening screws **B** with the socket wrench from the tool kit.



- 5. Pull out the light unit to the side in the **direc**tion of the arrow and additionally pull it out in the area of the ball head **C**.
- 6. Disengage cable and then press on the plug release (arrow) on the plug **D** and pull off the plug.




Installing tail light

- 1. Push on plug **D** until the plug is felt to click into place (arrow) and secure cable.
- 2. Insert ball head of tail light **C** into clip nut **E** and fit the light unit into the body (arrow).




- 3. Screw in the fastening screws **B**. When screwing in the fastening screws, make sure that the tail light is flush with the body.
- 4. Press in caps A.

191-170



Replacing bulbs at rear

- 1. Unscrew fastening screws **D** with the crosshead screwdriver from the tool kit.
- 2. Remove lamp bracket C.



- E Rear fog light F Direction indicator G Tail light
- 3. Replace the defective bulb (bayonet fitting). Insert lamp bracket and screw in fastening screws.
- 4. Install tail light.
- 5. Check operation of lights.


Close the rear lid.



License Plate Lights

Changing bulb for license plate light

- 1. Unscrew both screws **A** and remove the light.
- 2. Push the bulb holder apart and pull the bulb out.
- 3. Replace defective bulb.
- 4. Insert light, initially tighten both screws **A** and then screw in uniformly.



Headlight Adjustment

- ▶ Check tire pressure and adjust if necessary.
- ▶ Please observe the chapter "TIRE PRESSU-RES, COLD" on Page 406.
- ▶ Please observe the chapter "REPLACING BUL-BS" on Page 376.

Adjustment

The adjustment is made with the vehicle ready to drive and the fuel tank completely filled.

The driver's seat must be loaded by a person or a 165lbs. (75kg) weight and the tire pressures must meet the prescribed values. After being loaded, the car must be rolled a few meters so that the suspension can settle.

For checking the headlight adjustment, the vertical position of the cutoff of the lowbeam (see fig.) has to be projected on a vertical screen (wall) in distance of 24.6 ft. (7.5 m) from the front lens of the headlamp. The correct position of the cutoff is 3.0 in. (7.5 cm) at 24.6 ft. or 7.5 m (0.4°) below a horizontal line, x cm from ground to the center of the headlamp lens.

Lateral adjustment of the headlights should be carried out at a specialist workshop with an optical adjustment unit.

Distance

Visual aim shall be performed at not less than 24.6 ft. (this value is a rounded down conversion from the 25-foot distance typical of field aim using a screen). The 24.6 ft. (7.5 m) distance is measured from the headlamp lens to the viewing screen.

Floor

The surface upon which the vehicle rests is flat and approximately level.

Screen

The screen upon which headlamp beams are projected is perpendicular to the floor and the vehicle's longitudinal axis, flat, uniformly light in color, unobstructed, and wide and high enough to accommodate the vehicle beam patterns to be

The screen should be wide enough to provide at least 3.3 ft. (1 m) of space outboard of the vehicle's headlamp spacing.



Height adjustment for low beam/ high beam and additional high beam

- 1. Switch ignition on.
- 2. Switch on low beam and/or high beam.
- 3. Open engine compartment lid.
- 4. Place allen key (6 mm) on adjusting screw.
- 5. Adjust low beam in direction of the arrow.

Changing headlights from left to right-hand traffic

If you travel to a country where traffic uses the other side of the road, the headlights must be repositioned when you cross the border. The dipped beam then lights symmetrically and drivers of oncoming vehicles are not dazzled.

On the return journey, do not forget to readjust the headlights.



Repositioning headlights

1. Please observe the chapter "REMOVING HEADLIGHTS" on Page 377. Remove headlight. Press down both release tabs A and remove cover.



Halogen headlights

2. Push lever **B** down to the stop.



Xenon headlight

- 3. Turn spindle **C** in clockwise direction to the stop using a crosshead screwdriver.
- 4. Fit cover on headlight.

 Both release tabs **A** must be fully engaged.
- 5. Please observe the chapter "INSTALLING HEADLIGHTS" on Page 378. Install headlight.
- 6. Reposition the other headlight.

Bulb Chart

Exterior lights	Type, rating	Interior lights	Type, rating
Halogen low beam and high beam	H7	Interior light, front	W5W
Xenon low beam and high beam	D1S	Reading light	W5W
Side marker lights, front	W5W	Footwell light	W3W
Turn signal light, rear	P21W	Glove compartment light	W3W
Turn signal light, front	PY21W	Center console	W3W
License plate light	C5W	Curb lights (doors)	W3W
Fog light	H11	Warning lights (doors)	W3W
Rear fog light	P21W	Curb light (rear lid)	W5W
Back up light	P21W	Guard light (rear lid)	W5W
Additional high beam	H7	Luggage compartment light	K12V10W
Cornering light	H11		

Towing

Certain state statutes and local ordinances prohibit towing with a chain, rope or even a tow bar. In addition, damage to your vehicle may result from improper procedures. Consult your authorized Porsche dealer for details.

When the turn signal light is set with the ignition on and the emergency warning lights active, only the turn signal light on the corresponding side of the vehicle will light up. After the turn signal light is reset, the emergency warning lights will be switched on again.

Vehicle towing

Flat bed towing is the preferred type of towing to be used on Porsche vehicles. Under certain circumstances, wheel lifts may be used when the vehicle will not roll.

The vehicle must be towed with all four wheels off the ground, otherwise damage to the vehicle may result.

Towing hook

Depending on the vehicle equipment, the sparewheel well contains one or two towing hooks.



Risk of damage to the vehicle.

- ▶ Use the towing hook only for an emergency to remove the vehicle off the road. The towing hook is to be used only to pull the vehicle onto the flat bed, tractor or towing aparatus if the vehicle will roll freely. Under no circumstances is the vehicle to be secured using the towing hook.
- ▶ Never use the towing hook to tow this or any other vehicle.



Screwing in rear towing hook

1. Carefully lever out the appropriate plastic cover **A** in the bumper with the screwdriver. The cover is captive and need not be removed completely.



2. Screw in towing hook **B** as far as the stop (left-hand thread) and tighten hand-tight.



Screwing in front towing hook

1. Carefully lever out the appropriate plastic cover **A** in the bumper with the screwdriver. Place cover in the vehicle.



2. Screw in towing hook **B** as far as the stop (left-hand thread) and tighten hand-tight.




Fitting plastic cover at front

First engage the upper locking tabs of the plastic cover, and then press in the bottom tabs and side tab uniformly until the tabs have engaged fully.



Pulling vehicle onto flat bed

- 1. Position wooden ramps at the base of the flat bed to reduce the angle of the pull.
- 2. Reel in the hoist cable and check the underside of the vehicle for any interference.



Tying down vehicle on flat bed

- 1. Carefully feed towing straps through the opening in the rear wheels.
 - Make sure metal parts of straps do not damage rim. Make sure the strap is flat over the rim bead.
 - Make sure brake backing plate is not damaged.
- 2. Secure straps to rear of flat bed.
- 3. Reel in hoist cable only far enough to tension tie-down straps.

4. Carefully feed towing straps through the opening in the **front wheels**.

Make sure metal parts of straps do not damage rim.

Make sure the strap is flat over the rim bead. Make sure brake backing plate is not damaged.

- 5. Secure straps to front of flat bed.
- 6. Release tension on hoist cable, but do not disconnect. Use hoist cable as a safety cable.

Recovering the vehicle

Depending on the vehicle equipment, the sparewheel well contains one or two towing lugs.

▶ When recovering the vehicle, always use two towing lugs if possible.

Screw in the towing lugs only at the front or rear

Never screw them in so that one towing lug is at the front and one is at the back.

Tire Pressure and Technical Data

Vehicle Identification	399
Engine Data	401
Transmission	402
Tires, Rims, Tracks	403
Tire Pressures, Cold	406
Weights	408
Ground Clearance	
Capacities	411
Dimensions	412
Driving Performance	



Vehicle Identification

When ordering spare parts or making inquiries, please always quote the vehicle identification number.

Data bank

When ordering spare parts or making inquiries, please always quote the vehicle identification number.

This label contains the following information:

- 1. Vehicle Identification No.
- 2. Type/Type description
- 3. Engine code/Transmission code
- 4. Paint No./Interior
- 5. Optional equipment

A duplicate of this label is in your Maintenance Booklet.

Note

The data bank can not be reordered when lost or damaged.



Vehicle identification number

In accordance with Federal Safety Regulations, the vehicle identification number of your car is located at the bottom left of the windshield frame and can be seen from the outside and in the luggage compartment on the right in front of the tool box.



Safety compliance sticker

The safety compliance sticker is your assurance that your new Porsche complies with all applicable Federal Motor Vehicle Safety Standards which were in effect at the time the vehicle was manufactured.

The sticker also shows the month and year of production and the vehicle identification number of your car (perforations) as well as the Gross Vehicle Weight Rating and the Gross Axle Weight Rating.



Tire pressure plate

The tire pressure plate is attached to the left-handdoor aperture.

The pressures shown on the tire pressure plate refer to a fully loaded vehicle. In case the combined weight of occupants and cargo does not exceed 260 kg or 573 lbs the pressures for "PARTIALLY LOADED" may be used for greater driving com-

- ▶ Please observe the chapter "TIRE PRESSU-RES, COLD" on Page 406.
- ▶ Please observe the chapter "LOADING INFOR-MATION" on Page 263.

For setting "Partially Load":

- 1. Correct the setting in the multi-purpose dis-Please observe the chapter "SETTING VEHIC-LE LOADING AND ADJUSTING TIRE PRESSU-RE" on Page 158.
- 2. Correct the tire pressure.

Engine Data

	Cayenne	Cayenne S
Туре	6-cylinder V-engine	8-cylinder V-engine
Number of cylinders	6	8
Bore	3.5 in. (89 mm)	3.78 in. (96 mm)
Stroke	3.8 in. (96.4 mm)	3.27 in. (83 mm)
Displacement	219.5 cu. in. (3598 cm ³)	293.3 cu. in. (4806 cm ³)
Net-horsepower, SAE J 1349	213 kW (290 HP)	283 kW (385 HP)
at engine speed	6200 rpm	6200 rpm
Net. torque, SAE J 1349	273 ftlb. (370 Nm)	369 ftlb. (500 Nm)
at engine speed	3000 rpm	3500 rpm
Maximum permitted engine speed	6700 rpm	6700 rpm
Engine oil consumption	up to 1.5 liters/1000 km (1.6 quarts/622 miles)	up to 1.5 liters/1000 km (1.6 quarts/622 miles)

Transmission

Transmission ratio	Cayenne manual transmission	Cayenne Tiptronic S	Cayenne S manual transmission	Cayenne S Tiptronic S
1st gear	4.68: 1	4.15:1	4.68 : 1	4.15:1
2nd gear	2.53:1	2.37 : 1	2.53:1	2.37 : 1
3rd gear	1.69:1	1.56:1	1.69:1	1.56:1
4th gear	1.22:1	1.16:1	1.22:1	1.16:1
5th gear	1.00:1	0.86 : 1	1.00:1	0.86 : 1
6th gear	0.84 : 1	0.69:1	0.84 : 1	0.69:1
Reduction gear	2.70 : 1	2.70 : 1	2.70 : 1	2.70 : 1
Reverse gear	4.27 : 1	3.39:1	4.27 : 1	3.39:1
Final drive ratio	3.70:1	4.30:1	3.55:1	3.55:1

Tires, Rims, Tracks

Cayenne	Tires	Wheel front/rear	Rim offset front/rear	Track front	rear
Summer tires	235/65 R 17 108 V XL ¹⁾	7.5 J x 17	2.09 in. (53 mm)	65.2 in. (1655 mm)	65.8 in. (1670 mm)
	255/55 R 18 109 Y XL ²⁾	8 J x 18	2.24 in. (57 mm)	64.8 in. (1647 mm)	65.4 in. (1662 mm)
	275/45 R 19 108 Y XL	9 J x 19	2.36 in. (60 mm)	64.6 in. (1641 mm)	65.2 in. (1656 mm)
	275/40 R 20 106 Y XL	9 J x 20	2.36 in. (60 mm)	64.6 in. (1641 mm)	65.2 in. (1656 mm)
	275/40 R 20 106 Y XL	9 J x 20/10 J x 20	2.36 in. (60 mm)/ 2,17 in. (55 mm)	64.6 in. (1641 mm)	65.6 in. (1666 mm)
	295/35 R 21 107 Y XL	10 J x 21	1.97 in. (50 mm)	65.4 in. (1661 mm)	66.0 in. (1676 mm)
	295/35 R 21 107 Y XL	10 J x 21	1.97 in./1.77 in. 50 mm/45 mm	65.4 in. (1661 mm)	66.4 in. (1686 mm)
Winter tires	235/65 R 17 108 H XL ¹⁾	7.5 J x 17	2.09 in. (53 mm)	65.2 in. (1655 mm)	65.8 in. (1670 mm)
	255/55 R 18 109 V XL ²⁾	8 J x 18	2.24 in. (57 mm)	64.8 in. (1647 mm)	65.2 in. (1656 mm)
	255/50 R 19 107 V XL ³⁾	9 J x 19	2.36 in. (60 mm)	64.8 in. (1647 mm)	65.4 in. (1662 mm)
All-Season	235/65 R 17 108 T XL ¹⁾	7.5 J x 17	2.09 in. (53 mm)	65.2 in. (1655 mm)	65.8 in. (1670 mm)
	235/60 R 18 107 T XL ¹⁾	8 J x 18	2.24 in. (57 mm)	64.8 in. (1647 mm)	65.4 in. (1662 mm)
	275/45 R 19 108 V XL ²⁾	9 J x 19	2.36 in. (60 mm)	64.6 in. (1641 mm)	65.6 in. (1666 mm)
Collapsible spare wheel	195/75 18	6.5 J x 18			

Cayenne S	Tires	Wheel front/rear	Rim offset front/rear	Track front	rear
Summer tires	255/55 R 18 109 Y XL ²⁾	8 J x 18	2.24 in. (57 mm)	64.8 in. (1647 mm)	65.4 in. (1662 mm)
	275/45 R 19 108 Y XL	9 J x 19	2.36 in. (60 mm)	64.6 in. (1641 mm)	65.2 in. (1656 mm)
	275/40 R 20 106 Y XL	9 J x 20	2.36 in. (60 mm)	64.6 in. (1641 mm)	65.2 in. (1656 mm)
	275/40 R 20 106 Y XL	9 J x 20/10 J x 20	2.36 in. (60 mm)/ 2,17 in. (55 mm)	64.6 in. (1641 mm)	65.6 in. (1666 mm)
	295/35 R 21 107 Y XL	10 J x 21	1.97 in. (50 mm)	65.4 in. (1661 mm)	66.0 in. (1676 mm)
	295/35 R 21 107 Y XL	10 J x 21	1.97 in./1.77 in. 50 mm/45 mm	65.4 in. (1661 mm)	66.4 in. (1686 mm)
Winter tires	255/55 R 18 109 V XL ²⁾	8 J x 18	2.24 in. (57 mm)	64.8 in. (1647 mm)	65.4 in. (1662 mm)
	255/50 R 19 107 V XL ³⁾	9 J x 19	2.36 in. (60 mm)	64.6 in. (1641 mm)	65.2 in. (1656 mm)
All-Season	255/55 R 18 109 V XL ²⁾	8 J x 18	2.24 in. (57 mm)	64.8 in. (1647 mm)	65.4 in. (1662 mm)
	275/45 R 19 108 V XL ²⁾	9 J x 19	2.36 in. (60 mm)	64.6 in. (1641 mm)	65.2 in. (1656 mm)
Collapsible spare wheel	195/75 18	6.5 J x 18			
Cayenne and Cayenne S	The load capacity coefficient (e.g. "106") and maximum speed code letter (e.g. "T") for permitted top speed are minimum requirements. When fitting new tires or changing tires: Please observe the chapter "TIRES/WHEELS" on Page 317.				
Tire and rim sizes	Extensive tests are performed before specific tires and wheels are approved by Porsche. Your Porsche dealer has information about approved tires and wheels and is happy to assist you. If aftermarket tires and/or wheels are installed which are not approved by Porsche, the vehicle's driveability, stability while in motion and handling characteristics might be impaired. Since Porsche has no data on such combinations, Porsche cannot stand behind the safety or durability of these aftermarket combinations. Please observe the chapter "SNOW CHAINS" on Page 326.				

1, 2, 3)Snow chains and clearance

Clearance for tires marked $^{1)}$ is only assured with snow chain, part No. 955.044.600.07. Clearance for tires marked $^{2)$, $^{3)}$ is only assured with snow chain, part No. 955.044.600.08. For tires marked with $^{3)}$: Only use snow chains on the rear axle.

Optimal handling characteristics can be achieved only when snow chains are fitted on all four wheels of the vehicle.

It is also possible to fit snow chains on only one axle (preferably the rear axle). Maximum speed 50 km/h (30 mph).

- ▷ Observe the respective road traffic regulations.
- ▶ Use only Porsche-authorized fine-link cross-type or edge chains.

Tire Pressures, Cold

These tire filling pressures apply only to the tire makes and types approved by Porsche. Please observe the chapter "TIRES/WHEELS" on Page 317.

Partially loaded (up to 3 people and 46 lbs./21 kg of luggage)	Cayenne		Cayenne S	
Summer tires	Front axle	Rear axle	Front axle	Rear axle
235/65 R 17				43 psi (2.9 bar)
255/55 R 18			38 psi (2.6 bar)	
275/45 R 19	38 psi (2.6 bar)	43 psi (2.9 bar)		
275/40 R 20				
295/35 R 21				
AllSeason and Winter Tires	Front axle	Rear axle	Front axle	Rear axle
235/65 R 17 M+S				
255/55 R 18 M+S	35 psi (2.4 bar)	39 psi (2.7 bar)	35 psi (2.4 bar)	39 psi (2.7 bar)
255/50 R 19 M+S	33 psi (2.4 par)	39 psi (2.7 par)	33 psi (2.4 par)	39 psi (2.7 par)
275/45 R 19 M+S	1			
Collapsible spare wheel	Front axle	Rear axle	Front axle	Rear axle
195/75 - 18	51 psi (3.5 bar)			

Fully loaded (more than 3 people and 46 lbs./21 kg of luggage)	Cayenne		Cayenne S	
Tire size	Front axle	Rear axle	Front axle	Rear axle
235/65 R 17 summer and M+S tires				
255/55 R 18 summer and M+S tires				
255/50 R 19 M+S tires	39 psi (2.7 bar)	50 psi (3.4 bar)	39 psi (2.7 bar)	50 psi (3.4 bar)
275/45 R 19 summer and M+S tires	03 por (2.7 bul)	00 por (0.1 bur)	03 por (2.7 bur)	00 por (0. 1 bur)
275/40 R 20 summer tires				
295/35 R 21 summer tires				
Collapsible spare wheel		51 psi (3.5 bar)		

On vehicles with Tire Pressure Monitoring, the vehicle load must be set in the multi-purpose display of the instrument panel. Please observe the chapter "SETTING VEHICLE LOADING AND ADJUSTING TIRE PRESSURE" on Page 158.

Weights

	Cayenne manual transmission	Cayenne Tiptronic S	Cayenne S manual transmission	Cayenne S Tiptronic S
Empty weight				
Empty weight (depending on equipment)				
per DIN 70020	4762 - 5556 lbs. (2160 - 2520 Kg)	4784 -5578 lbs. (2170 - 2530 kg)	4905 - 5732 lbs. (2225-2600 kg)	4949 - 5776 lbs. (2245 - 2620 kg)
per 70/156/EEC ¹⁾	4927 - 5720 lbs. (2235 - 2595 kg)	5051 - 5861 lbs. (2245 - 2605 kg)	5070 - 5897 lbs. (2300 - 2675 kg)	5115 - 5941 lbs. (2320 - 2695 kg)
Maximum axle load, front 2)	3053 lbs. (1385 kg)	3053 lbs. (1385 kg)	3208 lbs. (1455 kg)	3208 lbs. (1455 kg)
Maximum axle load, rear ²⁾	3638 lbs. (1650 kg)	3637 lbs. (1650 kg)	3704 lbs. (1680 kg)	3704 lbs. (1680 kg)
Maximum gross weight	6493 lbs. (2945 kg)	6492 lbs. (2945 kg)	6790 lbs. (3080 kg)	6790 lbs. (3080 kg)
Trailer operation Canada/USA				
Maximum gross weight	6493 lbs. (2945 kg)	6493 lbs. (2945 kg)	6790 lbs. (3080 kg)	6790 lbs. (3080 kg)
Maximum axle load, front/rear axle	3053/3802 lbs. (1385/1725 kg)	3053/3802 lbs. (1385/1725 kg)	3208/3803 lbs. (1455/1725 kg)	3208/3913 lbs. (1455/1725 kg)
Roof load				
Maximum roof load ³⁾ when roof rail is fitted ³⁾	225 lbs. (100 kg) 165 lbs. (75kg)	225 lbs. (100 kg) 165 lbs. (75 kg)	225 lbs. (100 kg) 165 lbs. (75 kg)	225 lbs. (100 kg) 165 lbs. (75 kg)
Towing capacity/vehicle + trailer weight				
Maximum towing capacity, braked (up to a max. 12% slope)	7716 lbs. (3500 kg)	7716 lbs. (3500 kg)	7716 lbs. (3500 kg)	7716 lbs. (3500 kg)
Maximum towing capacity, unbraked	1654 lbs. (750 kg)	1654 lbs. (750 kg)	1654 lbs. (750 kg)	1654 lbs. (750 kg)
Maximum vehicle + trailer weight	14209 lbs. (6445 kg)	14209 lbs. (6445 kg)	14506 lbs. (6580 kg)	14506 lbs. (6580 kg)
Maximum trailer hich load	617 lbs. (280 kg)	617 lbs. (280 kg)	617 lbs. (280 kg)	617 lbs. (280 kg)

¹⁾ Empty weight includes 165 lbs. (75 kg) driver and baggage share.

408 Tire Pressure and Technical Data

²⁾ The maximum gross weight must not be exceeded.

Note: If additional equipment is installed, the useful load will be correspondingly less.

³⁾ Use only Original Porsche Roof Transport System.

Ground Clearance

	Cayenne	Cayenne S
Steel suspension		
Ramp angle	20.4°	20.4°
Overhang angle, front	28.6°	28.6°
Overhang angle, rear	22.8°	22.8°
Ground clearance (center of axles)	8.58 in. (218 mm)	8.58 in. (218 mm)
Air suspension – normal level		
Ramp angle	20.0°	20.0°
Overhang angle, front	28.5°	28.5°
Overhang angle, rear	22.3°	22.3°
Ground clearance (center of axles)	8.46 in. (215 mm)	8.46 in. (215 mm)
Air suspension – low level		
Ramp angle	17.6°	17.6°
Overhang angle, front	27.3°	27.3°
Overhang angle, rear	20.6°	20.6°
Ground clearance (center of axles)	7.52 in. (191 mm)	7.52 in. (191 mm)
Air suspension – loading level		
Ramp angle	14.8°	14.8°
Overhang angle, front	21°	21°
Overhang angle, rear	18.5°	18.5°
Ground clearance (center of axles)	6.34 in. (161 mm)	6.34 in. (161 mm)
Air suspension – terrain level		
Ramp angle	22.1°	22.1°
Overhang angle, front	30.2°	30.2°
Overhang angle, rear	23.6°	23.6°
Ground clearance (center of axles)	9.49 in. (241 mm)	9.49 in. (241 mm)

	Cayenne	Cayenne S
Air suspension – special terrain level Ramp angle	24.7°	24.7°
Overhang angle, front	31.8°	31.8°
Overhang angle, rear	25.4°	25.4°
Ground clearance (center of axles)	10.67 in. (271 mm)	10.67 in. (271 mm)

Capacities

Use only fluids and fuels authorized by Porsche. Your authorized Porsche dealer will be pleased to advise you. Your Porsche has been designed so that it is not necessary to mix any additives with oils or fuels.

	Cayenne	Cayenne S
Engine oil change quantity without oil filter	approx. 6.34 quarts (6.0 liters)	approx. 8.5 quarts (8.0 liters)
Engine oil change quantity with oil filter	approx. 7.29 quarts (6.9 liters) Reference indication is the level on the oil dipstick. Please observe the chapter "ENGINE OIL LEVEL" or	approx. 9.0 quarts (8.5 liters)
Coolant, depending on equipment level	approx. 3.4 – 4.8 U.S. gallons (13 – 18 liters)	approx. 4.8 – 5.5 U.S. gallons (18 – 21 liters)
Manual transmission with compensation	approx.1.9 quarts (1.8 litres)	approx.1.9 quarts (1.8 litres)
Automatic transmission with torque converter	approx. 10.04 quarts (9.5 liters)	approx. 9.51 quarts 9.0 liters)
Transfer box	approx. 0.9 quarts (0.85 liter)	approx. 0.9 quarts (0.85 liter)
Front-axle differential	approx. 1.1 quarts (1.0 liter)	approx. 1.1 quarts (1.0 liter)
Rear-axle differential	approx. 1.2 quarts (1.25 liters)	approx. 1.5 quarts (1.4 liters)
Locking rear differential	approx. 1.7 quarts (1.6 liters)	approx. 1.7 quarts (1.6 liters)
Fuel tank		approx. 26.4 U.S. gallons (100 liters), including approx. 3 U.S. gallons (12 liters) reserve
Fuel quality	98 RON/88 MON is used.	nance and fuel consumption if unleaded premium fuel with tleast 95 RON/85 MON are used, the engine's "Electronic gnition timing.
Power steering	approx. 1.6 quarts (1.5 liters) Pentosin CHF 11 S^{\circledR} or Pentosin CHF 202 S^{\circledR}	approx. 1.6 quarts (1.5 liters) Pentosin CHF 11 S $^{\! (\!B\!)}$ or Pentosin CHF 202 S $^{\! (\!B\!)}$
Brake fluid	approx. 1.0 quart (0.95 liter) Use only Original Porsche brake fluid.	approx. 1.0 quart (0.95 liter) Use only Original Porsche brake fluid.
Window/headlight washer system	approx. 7.9 quarts (7.5 liters)	approx. 7.9 quarts (7.5 liters)

Dimensions

	Cayenne	Cayenne S
Length	188.9 in. (4798 mm)	188.9 in. (4798 mm)
Length with external spare wheel	198.0 in. (5029 mm)	198.0 in. (5029 mm)
Width	75.9 in. (1928 mm)	75.9 in. (1928 mm)
Height at DIN empty weight	66.9 in. (1699 mm)	66.9 in. (1699 mm)
Height at DIN empty weight (rail)	68.5 in. (1741 mm)	68.5 in. (1741 mm)
Height at DIN empty weight (basic carrier of Roof Transport System)	70.4 in. (1789 mm)	70.4 in. (1789 mm)
Height at DIN empty weight with rear lid open	87.3 in. (2218 mm)	87.3 in. (2218 mm)
Max. wading depth	19.7 in. (500 mm) ¹⁾	19.7 in. (500 mm) ¹⁾
Wheelbase	112.4 in. (2855 mm)	112.4 in. (2855 mm)
Overhang, front	36.6 in. (936 mm)	36.6 in. (924 mm)
rear	39.7 in. (1007 mm)	39.7 in. (1007 mm)
Turning circle	461 in. (11.7 m)	461 in. (11.7 m)

 $^{^{1)}\,\}mathrm{Up}$ to 21.9 in. (555 mm) for vehicles with air suspension at special terrain level.

Driving Performance

The specifications refer to a vehicle with DIN kerb weight and max. 441 lbs. (200 kg) load without performance-reducing additional equipment (e.g. special tires)

	Cayenne manual transmission	Cayenne Tiptronic S	Cayenne S manual transmission	Cayenne S Tiptronic S
Top track speed	141 mph (227 km/h)	141 mph (227 km/h)	157 mph (252 km/h)	155 mph (250 km/h)
Acceleration 0 - 60 mph (96 km/h)	7.5 seconds	7.9 seconds	6.2 seconds	6.4 seconds
Acceleration 0 - 62 mph (100 km/h)	8.1 seconds	8.5 seconds	6.6 seconds	6.8 seconds
Maximum speed when driving with a trailer		50 mph	n (80 km/h)	

Index

2-zone air conditioning	
Air-conditioning sensors	89
Defrosting windshield	88
Operating overview	85
REST mode	
Setting air distribution	
Setting air quantity	
Setting temperature	86
Switching ECON mode on/off	88 A
Switching Mono function on/off	87 A
Switching on automatic recirculating-air mode	
Switching on recirculating-air mode	88 Ai
Using engine residual heat	89
4-wheel drive	
Functional description	211
Warning message	
4-zone air conditioning	
Air-conditioning sensors	92
Controlling rear air-conditioned areas	
with the front control panel	97
Defrosting windshield	95
Disabling control panel (rear)	97
Disabling control panel for	Ai
air-conditioned areas at the rear	97
Operating overview, front	
Operating overview, rear	
REST mode	
Setting air distribution	94
Setting air quantity	94
Setting temperature	
Switching ECON mode on/off	96
Switching Mono function on/off	95
Switching on automatic recirculating-air mode	
Switching on recirculating-air mode	
Using engine residual heat	
_	Ai
A	
ABD (Automatic brake differential)	Ai
Automatic deactivation	214
Functional description	
ABS (anti-lock brake system)	
A DO (MINITOON DI MINO OJOCOTII)	

Functional description	216
Off-road ABS functional description	217
Warning light on the tachometer	
Warning message	
Additional door mirrors when towing a trailer	266
Additional high beam	
Installing headlights	378
Removing headlights	377
After driving off-road	
Aftermarket Alarms	
Air cleaner maintenance instructions	
Air conditioner	294
Child lock	0.7
Cover flap	/0
Operating overview	0.5
of 2-zone air conditioning	85
Operating overview	00
of 4-zone air conditioning, front	
Operating overview of 4-zone air conditioning, i	
Operating overview of manual air conditioning	80
Switching child protection on/off	97
Which system is in my car?	77
Air conditioning	
Fresh-air intake	
Vents	98
Air pressure	
Data (bar/psi)	406
Plate	400
Warning message	174
Air suspension25	6, 270
Compressor connection	348
Lowering the vehicle	
Lowering the vehicle for loading	222
Overview	220
Raising the vehicle	
Warning message on the multi-purpose display	
Air vents	LLO
Opening/closing	98
Airbag	50
Airbag warning light on the tachometer	57
Automatic deactivation of the passenger airbag	
Care Instructions	
0410 1134 4040113	

Disposal	54
Function	54
Functional description	53
Installation location	53
Passenger airbag warning light	56
Unit	
Air-conditioning sensors	
For 2-zone air conditioning	80
For 4-zone air conditioning	92
Alarm button	
Alarm system	
Function	
Function indication	280
Hitching a trailer	
Switching on/off	
When disconnecting battery	353
Alcantara	
Care instructions	313
All-Season tires	
Overview	404
All-Terrain tires	
All-wheel drive	
Functional description	211
Warning message	
Aluminium rims	
Care instructions	311
Inscription	
Antifreeze	
In coolant	
Anti-freeze content	
Anti-lock brake system (ABS)	
Functional description	216
Off-road ABS functional description	217
Warning light on the tachometer	216
Warning message	177
Armrest	255
Ashtray	
Assembly aid for wheel changes	
Assistance when driving downhill	
(Engine Braking Support)	219
Audio	
Tips	249

auto (light switch)		Warning message	4-zone air-conditioning (rear control panel)
Functional description, driving light assistant		Winter driving365	Door mirrors
Switching on driving light assistant	.123	Before driving off6, 227	Manual air-conditioning
AUTO button		Belts49	Opening and locking from outside
2-zone air conditioning		Adjusting belt height52	Sliding/lifting roof
4-zone air conditioning	93	Belt tensioner functional description50	Windshield wipers
Automatic (Tiptronic S)		Care instructions	Bulbs
Functional description	.195	Fastening51	Changing bulb for high beam 380,
Rocker switches on the steering wheel	69	Opening51	Changing bulb for license plate light
Selector lever	196	Warning light62	Changing bulb for low beam
Transmission ratios	402	Warning light on the tachometer50	Changing bulb for side light, halogen
Automatic anti-dazzle function for interior mirror	67	Bi-xenon	Chart
Automatic anti-dazzle operation		Changing bulb381	Overview
Automatic brake differential (ABD)		Installing headlights	Replacing brake light
Automatic deactivation	214	Removing headlights	Replacing direction indicator
Functional description		Brake booster	Replacing rear direction indicator
Automatic headlight beam adjustment		Brake booster faulty warning message	Replacing rear fog light
Functional description	125	Brake fluid	Replacing reversing light
Automatic transmission fluid		Change quantity411	Replacing tail light
Automatically closing the rear lid		Changing	,
Auxiliary battery		Checking level291	
Installing and removing	370	Warning light on speedometer292	C
Avoiding false alarms		Warning message	Capacities
<u> </u>		Brake light	Brake fluid
		Changing bulb	Engine oil
В		Installing tail light	Fuel
Baby seat		Removing tail light	Overview
Installing with LATCH system	62	Brake pads	Washer fluid
LATCH restraint system		Warning message on the multi-purpose display 176	Car care
Prescribed installation direction	02	Brake pedal	Airbags
(depending on age of child)	58	Brake wear	Alcantara
Battery		Warning light	Cleaning the engine compartment
After charging		Brake wear warning message	Fabric linings
Care		Brakes	Headlights, plastic parts
Changing in vehicle key	371	Applying/releasing parking brake185	Leather
Charge state		Brake pedal187	Light alloy wheels
Charging		Break in brake pads8	Paint
General information		Discs	Safety belts
Procedure after battery connection		Pads	Seals
Putting vehicle into operation		Parking brake test	Seat belts
Removing and installing		Test stand219	Storing your Porsche
Removing and installing auxiliary battery		Warning light	Undercoating
Replacing		Warning message on the multi-purpose display 176	Use of high-pressure cleaning units
Starting with jumper cables		Brief overview	Washing
Vehicle electrical system voltage indication		2-zone air-conditioning84	Wheel bolts
Voltage indication		4-zone air-conditioning (front control panel)90	Windows
VUITARE INDICATION	. 144	. Earlie am a transming the order of parioty minimum	WILLIAMS

Car Telephone	250
Care instructions	
Airbags	313
Alcantara	313
Carpet	312
Cleaning the engine compartment	309
Fabric linings	313
Floor mats	
Headlights, plastic parts	
Leather	
Light alloy wheels	
Paint	309
Safety belts	313
Seals	312
Seat belts	
Storing your Porsche	
Undercoating	
Use of high-pressure cleaning units	307
Washing	
Wheel bolts	331
Windows	
Cargo	
Cargo management system	
Inserting and adjusting the strap reel	
Inserting and adjusting the telescopic bar	
Inserting and adjusting the telescopic bar	
Overview	
Carpet, care instructions	
Catalytic converter	
Center armrest	
Center differential lock	200
Engaging	206
Central locking system	200
Changing settings via multi-purpose display	166
Functional description	24
When disconnecting battery	353
Changing bulb for license plate light	
Changing wheels	
Check engine (emission control)	
Functional description	145
Warning light on the tachometer	
Checking hydraulic fluid (power steering)	293
Child restraint anchorages	
Child seat	
Installing with LATCH system	62
LATCH restraint system	
and the distriction of the state of the stat	

Prescribed installation direction (depending on age of
child)58
Child seat bracket62
Cigarette lighter260
Front
Rear260
Cleaning the engine compartment
Clock
Button for setting
Setting on the multi-purpose display
Closing
Automatically closing the rear lid32
Rear window34
Clutch 194
Cockpit
Adjusting illumination
Clock
Cooling system temperature gage141
Fuel level gage
Odometer 142
Oil temperature gage
Speedometer
Tachometer 140
Voltage indication
Warning and indicator lights, overview
Collapsible spare wheel
PSM (Porsche Stability Management)215
Tire size
Collapsible spare wheel in the luggage compartment344
Comfort function
Panorama roof system
Comfort lighting
Dimming
Coming Home function
Setting lighting off delay
Switching on
Compass
Setting on the multi-purpose display170
Compressor
Connection (on vehicles without air suspension)346
Storage location (on vehicles
without air suspension)
Conering light
Control panel 97
Control systems
Overview (PTM, PTM Plus, PSM, PASM, PDCC)210
OVERVIEW (I TIVI, I TIVI I IUS, I SIVI, I ASIVI, I DOG)ZIV

Coolant	
Antifreeze	28
Checking level	28
Cooling system	
Engine coolant level warning	14
Engine coolant temperature warning	
Temperature gage	14
Cornering light	
Installing headlights	37
Removing headlights	37
Cornering light, static	
Crankcase ventilation	
Crossing obstacles	
Cruise control	
Accelerating	19
Decelerating	
Functional description	
Interrupting operation	
Storing speed	
Switching off	
Switching on	
Cupholder	
Closing rear	25
Front	
Rear	25
Removing insert front	
S .	
D	
Data bank for vehicle data	39
Defrosting windshield	
With 2-zone air conditioning	8
With 4-zone air conditioning	9
With manual air conditioning	8
Digital speedometer	14
Dimensions	
Dimming footwell light	
Dimming the comfort lighting	
Disabling control panel for air-conditioned areas	
at the rear	9
Distance displays	
ParkAssist	27
Door	
Locking	2
Locking with Porsche Entry & Drive (keyless) .	2
Looking with the vehicle key (venete central)	2

Unlocking with Porsche Entry & Drive (keyles:	s)	27
Unlocking with the vehicle key (remote control	ار)	27
Door lock		
De-icing		307
Door locking, automatic		28
Door mirrors		
Activating synchronous adjustment		
Activating synchronous mirror adjustment		166
Additional door mirrors when towing a trailer		266
Adjusting		65
Adjusting as parking aid		66
Adjusting synchronously		
Brief overview		64
Door-surrounding lighting		130
Driving with a trailer		266
Folding in		65
Storing setting as parking aid		43
Switching heating on/off		
Unfolding		65
When towing a trailer		
Door opening	. 28,	280
Door trim panel		
Lighting		130
Drinks holder		
Closing rear		258
Removing insert front		25
Driving		
Load		
Trailer		
Winter		20.
Driving light assistant		100
Switching on light switch		123
Driving performance		413
Driving program	100	000
Off road		
Reduced	107	20.
Road		
Driving programs for on-road and off-road driving		204
Driving systems for off-road driving		22
Driving with a trailer	266,	26
Drop-center rim		328
DVD Installation location		25/
Navigation		250
Player		256

DVD Player	
Under the right front seat	258
_	
E	
Easy Entry function	
Functional description	45
Switching on/off	45
Electrical system	353
Emergency flasher	
Switching on/off	126
Emergency operation	
Of sliding/lifting roof	113
Of the filler flap	302
Of the Panorama roof system	
Of the selector lever for Tiptronic S	202
Of the spare wheel bracket	352
Emergency starting	372
Emergency unlocking	
Of the filler flap	302
Spare wheel bracket	352
Emission control (check engine)	
Functional description	
Warning light on the tachometer	
Emission Control System	298
Engaging the rear differential lock	207
Engine	
Cooling system	
Data	
Idling	196
Starting (manual transmission)	
Starting (Tiptronic S)	
Stopping	183
Engine Braking Support (assistance	210
when driving downhill)	219
Functional description	21.4
Engine oil	202
Change	
Change quantity	/111
Dipstick	
Engine oil pressure	
Level	
Oil-level warning on the multi-purpose display	
Performance class	
Recommendation	
Neconinendation	

Temperature gage	140
Topping up	
Viscosity	
ngine oil level	
Checking	
ntry & Drive	
Locking vehicle door with Porsche Entry & Drive.	28
Opening/closing Panorama roof system with ve	
kev	118
Unlocking vehicle door with Porsche Entry & Drive	27
ntry aid	/
Functional description	45
Switching on/off	
xhaust gas	10
Monitoring warning light	138
xit aid	130
Functional description	45
Switching on/off	
Switching on on	43
ahvia lininga, aava inatuustiana	212
abric linings, care instructions	313
actory settings	171
Resetting multi-purpose display	1/1
iller flap	
Emergency unlocking	302
illing pressure	
Plate location	
Reducing	349
Tires (bar/psi)	406
Warning light on speedometer	164
Warning message	174
ilter	
Air cleaner maintenance instructions	
Particle filter maintenance instructions	294
ire extinguisher	
loor mats, care instructions	312
luids and fuels	
Brake fluid	411
Coolant	411
Engine oil	
Fuel	
Overview	
Washer fluid	
olding wedges	

Warning light	187
Footwell lightning	
Dimming	130
Four-wheel drive	
Functional description	
Warning message	178
Four-zone air conditioning	
Air-conditioning sensors	92
Controlling rear air-conditioned areas	
with the front control panel	97
Defrosting windshield	95
Disabling control panel (rear)	97
Disabling control panel for	
air-conditioned areas at the rear	97
Operating overview, front	92
Operating overview, rear	93
REST mode	96
Setting air distribution	94
Setting air quantity	94
Setting temperature	94
Switching ECON mode on/off	96
Switching Mono function on/off	95
Switching on automatic recirculating-air mode.	95
Switching on recirculating-air mode	95
Using engine residual heat	96
Fresh-air intake	98
Front seat	
Adjusting	41
Drawer under the right front seat	256
Passenger mirror as parking aid	43
Recalling settings (memory)	42
Storing driver's seat settings (memory)	43
Storing passenger's seat settings (memory)	44
Front seat with memory	42
Storing door mirror settings	66
Front seats	41
Front windshield wipers	
Changing the sensitivity	133
Switching on rain sensor	132
Windshield wiping plus washer system	
Windshield, fast wiping	
Windshield, slow wiping	133
Wiping windshield once (one-touch function)	133
Fuel	
Economy	
Evaporation control	

Fuel level gage	.142
Fuel reserve warning	142
General information	
Recommendations	
Tank capacity	
Fuel containers, portable	.505
Fuel filler opening	
Opening filler flap	201
Cuel level gage	1 4 2
Fuel level gage	
Fuel quality	
Fuel reserve	.303
Function keys on steering wheel	/1
Fuse assignment356,	363
Fuses	.354
G	
Garage door opener	
Applying	275
Deleting programed signals	
Functional description	
Programming signal (changeable code system)	
Programming signal (changeable code system)	275
Programming signal (fixed code system)	.2/5
Gear display for Tiptronic S	
Glasses case in the roof console	.253
Glove compartment	
Cooling	
Locking	.254
Opening	.254
Switching off cooling	.254
Gross weight	.263
Ground clearance	.412
Data	.409
Н	
Halogen	
Changing bulb for high beam	200
Changing bulb for low beam	.3/5
Changing bulb for side light	
Installing headlights	.3/8
Removing headlights	.3/7
Hand-held transmitter	.274
Headlight beam adjustment	.266

Headlight beam adjustment (automatic)	
Checking operation	125
Functional description	125
Headlights	381
Adjusting	
Before driving with a trailer	266
Care instructions	311
Changing bulb for high beam, halogen	380
Changing bulb for high beam, halogen, xenon	382
Changing bulb for low beam, halogen	379
Changing bulb for side light	384
Changing to left-hand traffic	391
Height adjustment	391
Installing	378
Operating washer system	134
Removing	
Headrests	0,,
Adjusting	46
Removing and installing	
Heated rear window	
Switching off	. 99
Switching on	90
Height adjustment	
Lowering the vehicle	222
Overview	
Raising the vehicle	
Warning message on the multi-purpose display	
High beam	
Changing bulb, halogen, xenon 380,	382
Indicator light	138
Installing headlights	
Removing headlights	
Stalk	
Switch	
Switching on/off	
High beam,additional	
High Range	
High-pressure cleaning units, information on use	307
Hillholder (moving-off assistant for Tiptronic S)	217
Horn	69
	00

		J		Warning message on the multi-purpose display .	
Identification number location	399	Jack	223	License plate light	13
Idling		Jacking points on the vehicle	338	Lid	
Ignition lock		Storage location in luggage compartment		Luggage compartment	3
Functional description	180	Jump lead starting with exhausted battery	373	Lifting	
Illumination	100	Jump lead starting, external power supply	373	Garage lift	
Of steering wheel keys, switching on/off	72	Jumper cables		Jack	
Switching on when entering the vehicle		Juliper Cables	372	Platform	33
Switching on when leaving the vehicle				Light	
Immobilizer		K		Headlight flasher	12
Inclination sensor	200			Switching on Coming Home function	13
Deactivating/Activating	270	Key	071	Switching on when leaving the vehicle	13
		Changing battery		Light alloy wheels	
Function		Locking the vehicle door		Care instructions	3
Function indication		Opening/closing sliding/lifting roof	112	Inscription	32
Monitored areas		Unlocking the vehicle door		Light segments	2
Switching on/off		Keys		Light switch	
Inserting and adjusting tie-down rings	242	Kickdown	198	Functional description, auto function	12
Instrument cluster	105			Overview	
Adjusting illumination	125	The second secon		Switching on auto position	
Clock		L		Lighting	
Cooling system temperature gage		Language		Switching on when entering the vehicle	13
Fuel level gage		Setting on the multi-purpose display	171	Lights	
Odometer		Large roof		Care instructions	3
Oil temperature gage		Emergency operation	120	Changing	
Speedometer		Functional description		Chart	
Tachometer		Opening/closing		Dimming comfort lighting	
Voltage indication		Opening/closing roller blind	119	Dimming footwell light	
Warning and indicator lights, overview	136	Opening/closing with vehicle key	118	Switching front reading lights on/off	
Instrument panel		LATCH system	62	automatically	13
Adjusting illumination	125	Fastening		Switching interior light on/off	
Clock	143	Installing a child seat	62	Switching interior light on/off automatically	
Cooling system temperature gage	141	Prescribed installation direction of child seat	5Q	Switching rear reading lights on/off	
Fuel level gage		Leather, care instructions		Switching rear reading lights on/off automatically	
Odometer	142	Left-hand traffic (changing headlights)		When towing a trailer	20
Oil temperature gage		Level control		Limit speed	20
Speedometer				Off-road shifting	20
Tachometer		Displaying status on the multi-purpose display Loading level22	104		
Voltage indication				Load	
Warning and indicator lights, overview		Low level		Compartment cover	
Interior light		Lowering the vehicle		Installing luggage compartment cover	24
Switching on/off	128	Lowering the vehicle for loading	222	Luggage compartment cover,	
Switching on/off automatically		Normal level		pulling out/retracting	
Interior lighting		Overview		Luggage safety net, permitted uses	
Interior mirror		Raising the vehicle		Position of tie-down rings	
Automatic anti-dazzle function		Special terrain level		Removing luggage compartment cover	
Automatic and dazzie function		Switching on and off	223	Safety net	21

Ski bag246
Stowing
Loading
Loading level
Lowering the vehicle for loading222
Luggage safety net, permitted uses
Loadspace
Cargo management system
Opening floor 239
Opening floor 239 Overview 239
Locking
Locking vehicle door from inside
Vehicle door with vehicle key (remote control)28
Locks
Displaying status on the multi-purpose display 154
Low beam
Changing bulb, halogen, xenon
Door-surrounding lighting
Installing headlights
Removing headlights
Switch
Switching on/off
Low level
Low Range (reduction)
Displaying status on the multi-purpose display 154
Indicator light
Switching off
Switching on
Luggage
Compartment cover253
Luggage compartment cover,
pulling out/retracting243
Luggage safety net, permitted uses244
Position of tie-down rings
Safety net
Ski bag
Luggage compartment
Closing luggage compartment lid
Closing the luggage compartment window34
Opening floor
Opening luggage compartment lid
Opening luggage compartment window34
Overview
Luggage compartment cover
Installing
Pulling out 243

Removing	243
Retracting	243
Luggage compartment lid	31
Luggage net	
Luggage safety net	233
Bracket	244
Permitted uses	
Permitted uses	244
Removing from rear seat backrest	245
Securing passenger compartment	245
M	
Make-up mirror	/4
Manual air conditioning	
Defrosting windshield	82
Operating overview	
REST mode	
Setting air distribution	81
Setting air quantity	81
Setting temperature	81
Switching ECON mode on/off	
Switching on recirculating-air mode	
Using engine residual heat	
Manual headlight beam adjustment	266
Manual transmission	
Clutch	194
Shift pattern	
Transmission ratios	
Maximum permitted engine speeds	
Memory	
Automatic storage	
Recalling seat settings	42
Storing driver's seat settings	
Storing passenger's seat settings	44
Minor repairs	
In the event of a flat tire	
Jack in the luggage compartment	329
Securing the vehicle against rolling	333
Tool kit in the luggage compartment	329
Towing the vehicle	394
Mirror	
Automatic anti-dazzle function for interior mir	ror67

Mirrors	266
Activating synchronous adjustment	
of door mirrors	166
Additional door mirrors when towing a trailer	266
Adjusting door mirrors	65
Adjusting door mirrors as parking aid	66
Adjusting the door mirrors synchronously	65
Folding in door mirrors	
Interior mirror	
Switching door mirror heating on/off	
Unfolding door mirrors	
Moving off	
Moving-off assistant	
For Tiptronic S (hillholder)	217
On vehicles with manual transmission	218
Multi-functional steering wheel	210
Functional description	71
Operating the function keys	
With telephone function	72
Without telephone function	
Multi-purpose display	, 0
Activating synchronous mirror adjustment	166
Changing settings of central locking system	
Displaying status of level control	
Displaying status of locks/reduction	154
Gear display for Tiptronic S	196
Overview of warning messages	
Resetting to factory settings	
Setting a speed limit	
Setting compass	
Setting language for displays	171
Setting lighting off delay	169
Setting the clock	
Setting Tire Pressure Monitoring	
Setting tire sealant/sealing set	
Setting units of displays	
Cottains arms or anopadyo miniminani	/ 1
N	
Navigation system	251
Nearfield lighting	
rvearrieru lightling	140

0	
Octane ratings	304
Odometer	
Display	142
Resetting	142
Off delay	1 12
Setting	169
Switching on	130
Off-road	100
Crossing obstacles	233
Driving downhill	
Rules for off-road driving	
Sand	
Track ruts	
Uphill driving	
Water crossing	231
Off-road ABS	
Off-road ABS functional description	
Off-road driving	217
Crossing obstacles	222
Downhill driving	
Driving rules	
Engaging the center differential lock	206
Engaging the center differential lock	
Low Range (reduction) indicator light	
Recommendation	
Sand	
Switching off Low Range (reduction)	
Switching on Low Range (reduction)	
Track ruts	
Uphill driving	
Water crossing	
Off-road PSM functional description	214
Off-road shifting Limit speed	007
Oil	
Change	
Change quantity	
Consumption	
Dipstick	
Engine oil pressure	
Filler opening	
Oil-level warning on the multi-purpose display	
Performance class	
Temperature gage	140

Topping up	286
Viscosity	
Oil level	
Checking	284
On-board computer	
Activating synchronous mirror adjustment	166
Changing settings of central locking system	
Displaying status of level control	
Displaying status of locks/reduction	154
Gear display for Tiptronic S	196
Overview of warning messages	
Resetting to factory settings	
Setting a speed limit	
Setting compass	
Setting language for displays	
Setting lighting off delay	
Setting the clock	169
Setting Tire Pressure Monitoring	155
Setting tire sealant/sealing set	
Setting units of displays	171
Opening and closing	
Automatically closing the rear lid	32
Closing the rear window	34
Locking vehicle door with the vehicle	
key (remote control)	
Opening the rear lid automatically	31
Unlocking and opening rear window	
Unlocking vehicle door with Porsche Entry & D	rive .27
Unlocking vehicle door	
with the vehicle key (remote control)	
Opening and closing the engine compartment lid	37
Opening and locking	
Engine compartment lid	37
Locking vehicle door with Porsche Entry & Driv	
Opening and locking vehicle door from inside .	
Opening the rear lid automatically	
Operating in other countries	300
Overview of capacities	
Engine oil	
Oxygen sensor	299

r	
Paint	
Care instructions	30
Polishing	30
Preserving	
Removing spots and stains	30
Repairing damage	30
Panic button	
Panorama roof system	
Comfort function	11
Functional description	
Opening closing with vehicle key	
Opening/closing	11
Opening/closing Opening/closing roller blind	11
ParkAssist	26
Distance display, front	27
Distance display, rear	27
Functional description	26
Switching on/off	
When driving with a trailer	
Parking	
Parking aid	6
Distance display, front	
Distance display, rear	
Functional description	
Storing door mirror setting as pa	
Switching on/off	
Swivelling down mirror glass	
When driving with a trailer	
Parking brake	
Applying	18
Releasing	18
Test stand	21
Warning light	
Warning message	
Parking heater	
Activating the memory	
Changing the remote control bat	tery 37
Faults	
Programming	
Switching on/off	
Partiala filtar maintananaa instructions	20

PASM (Porsche Active Suspension Management)	
Functional description224	ļ
Overview210	
Selecting the running-gear setup224	ļ
Warning light224	
Passenger airbag	
Automatic deactivation of the passenger airbag 55	;
Warning light in the center console	5
PASSENGER AIRBAG OFF	
Warning light in the center console56	5
Passenger compartment	;
Passenger compartment monitoring	
Function277	7
Passenger compartment monitoring system	
Deactivating/Activating279)
Function indication)
Switching on/off278	
Passenger mirror	
Activating synchronous mirror adjustment 166	5
Additional door mirrors when towing a trailer 266	
Adjusting 65	
Adjusting as parking aid	
Adjusting synchronously65	
Driving with a trailer	
Folding in65	
Storing setting as parking aid	3
Storing setting as parking aid	
Unfolding65	
PCM (Porsche Communication Management)251	
PDCC (Porsche Dynamic Chassis Control)	
Functional description	
Overview210	
Performance test on roller test stands)
Person buttons	
Petrol	
Fuel reserve warning)
General information	
Tank capacity	
Porsche Active Suspension Management (PASM)	ſ
Functional description	ı
Overview	
Selecting the running-gear setup224	
Warning light	ı
Warning light	

Porsche Drive-Off Assistant	
Moving-off assistant on vehicles	
with manual transmission	218
Porsche Dynamic Chassis Control (PDCC)	
Functional description	22!
Overview	210
Porsche Entry & Drive	
Locking the vehicle	28
Opening/closing Panorama roof system	
with vehicle key	118
Unlocking the vehicle	2
Porsche Stability Management (PSM)	
Functional description	21:
Functional description of off-road PSM	214
Multi-functional light in the tachometer	21
Overview	210
Switching off	214
Switching on	21
Warning message on the multi-purpose display	
Porsche Traction Management (PTM)	
Functional description	21
Overview	210
Porsche Traction Management Plus (PTM Plus)	
Overview	210
Portable Fuel Container	
Power measurement	
Power Steering	293
Power windows	
Adjusting after connecting battery	109
Closing windows with button	
in door handle (Porsche Entry & Drive)	109
Disabling in the rear doors	10
Opening/closing windows	
with vehicle key (without Porsche Entry & Drive)	108
Overview of driver's door control panel	
Overview of passenger's door control panel	
Readiness for operation	10
Powerliftgate	3
Power-transmission and running-gear control systems	
Overview (PTM, PTM Plus, PSM, PASM, PDCC)	210
Pressure tester	348
Protection	
Child protection	9
Disabling control panel	
for air-conditioned areas at the rear	97

PSM (Porsche Stability Management)	
Functional description	. 212
Functional description of off-road PSM	. 214
Multi-functional light in the tachometer	. 215
Overview	. 210
Switching off	. 214
Switching on	
Warning message on the multi-purpose display	
PTM (Porsche Traction Management)	
Functional description	. 211
Overview	. 210
PTM Plus (Porsche Traction Management Plus)	
Overview	. 210
D	
R	
Radiator fans	290
Radio	
Tips	. 249
Radio remote control	
Rain sensor	. 133
Adjusting	
Switching on	. 132
Reading lights, front	
Switching on/off	. 128
Switching on/off automatically	. 128
Rear differential lock	
Rear fog light	
Changing bulb	. 388
Switching on	. 123
Rear lid	
Locking	
Opening	
Rear reading lights	
Switching on/off	. 129
Switching on/off automatically	
Rear seats	
Adjusting to vertical position	. 238
Folding forward	236
Folding forward and returning to upright position	236
Rear shelf	
Installing	244
Pulling out	
Removing	
Retracting	

Rear window		Running in		Seats
Closing		Tires	8	Adjusting rear seats to vertical position 2
Opening	34	Running-gear control systems (air suspension)		Adjusting the front seat
Rear window wiper		Overview (PTM, PTM Plus, PSM, PASM, PDCC)2	210	Folding forward at rear
Changing wiper blade	. 297	Running-gear setup		and returning to upright position
Switching on intermittent operation	134	Functional description	224	Front
Window wiping plus washer system	134	Selecting	224	Recalling settings (memory)
Wiping rear window once (one-touch function)	.134	Warning light		Storing driver's seat settings (memory)
Rear-axle load				Storing passenger mirror setting
Reduction (Low Range)				as a parking aid (memory)
Displaying status on the multi-purpose display	154	\$		Storing passenger's seat settings (memory)
Indicator light		Safety belts	40	Securing points in the luggage compartment
Switching off		Adjusting belt height		Selection mode
Switching on		Belt tensioner functional description	.52	Automatic
Refueling		Care instructions	212	Manual
Relays				Selector lever
Release button		Fastening	.01	Automatic
Remote control		Opening		Tiptronic S 1
Changing battery		Warning light		Selector lever (Tiptronic S)
Locking the vehicle door		Warning light on the tachometer	.00	Display on the multi-purpose display
		Safety button in the armrest		
Opening/closing Panorama roof system	110	Safety compliance sticker		Emergency operation
Opening/closing sliding/lifting roof		Safety net		Selector lever position (Tiptronic S)
Reserve	303	Bracket		Display on the multi-purpose display 1
REST mode	00	Permitted uses		Sensors
With 2-zone air conditioning		Removing from rear seat backrest		Air-conditioning sensors for 2-zone air conditioning
With 4-zone air conditioning		Securing passenger compartment		Air-conditioning sensors for 4-zone air conditioning
With manual air conditioning		Screwdriver	329	Service indicator
Reverse gear		Sealant/sealing set		Setting air distribution
Swivelling down mirror glass		For defective tires	334	With 2-zone air conditioning
Swivelling down the mirror glass	66	Setting on the multi-purpose display	163	With 4-zone air conditioning
Reversing light		Seals		With manual air conditioning
Changing bulb	388	Care instructions	312	Setting air quantity
Rim offset	403	Seat belts		With 2-zone air conditioning
Rims		Care instructions	313	With 4-zone air conditioning
Diameter		Seat heating		With manual air conditioning
Rim width	328	Rear (4-zone air conditioning)	.48	Setting temperature
Rocker switches	197	Switching off		With 2-zone air conditioning
Roller blind		Switching on		With 4-zone air conditioning
Cleaning position	119	Seat memory		With manual air conditioning
Opening/closing for Panorama roof system		Recall using car key		Setting units on the multi-purpose display
Roof console		Recall using person buttons		Shifting
Comfort lighting	130	Storing parking aid		Down1
Interior lighting		Swivelling down mirror glass		On the steering wheel
Roof Transport System		Seat memory (comfort)		Up
Height		Seat with memory		Shifting gears
Load		Swivelling down mirror glass		Shifting up 2
		OWINGHING GOWN HINTOL GLOSS	_ / J	

Shock absorber adjustment21	0
Shock absorbers	0
Short trip counter	
Display14	2
Resetting14	2
Side lights	
Changing bulb38	
Installing headlights	
Removing headlights37	7
Side marker light	4
Door-surrounding lighting	
Ski bag	_
Loading24	6
Securing	
Stowing 24	
Sliding/lifting roof	,
Brief overview	Λ
Closing 11	
Emergency operation	7
Functional description	1
Lifting 11	
Opening completely	
Opening completely	
Opening to conflort setting	2
Opening/closing with vehicle key	2
Readiness for operation	
General information	
Overview40	
Snow tires	5
Spacers	_
Fitting34	
General information	0
Removing/fitting	
Spare wheel	
Fitting on spare wheel bracket35	
General information	
Removing from spare wheel bracket35	
Tire size403, 40	4
Spare wheel bracket	
Closing35	
Opening35	1
Spare wheel in the luggage compartment34	
Special terrain level	0
Speed code letter on tire	
Speed limit	
Setting on the multi-purpose display15	2

Sport button	208
Sport mode	208
SportDesign package	
Information on risk of damage	
Sports exhaust system	220
Switching on/off	209
Stainless steel exhaust tailpipes	
Starting	311
Emergency storting with jumper cobles	27
Emergency starting with jumper cables	10
Engine (manual transmission)	100
Engine (Tiptronic S)	193
With Jumper cables	3/2
With Tiptronic S	
Steam-jet cleaners, information on use	30
Steam-jet units	270
Steering column	
Locking with Porsche Entry & Drive	181
Locking without Porsche Entry & Drive	181
Steering column lock	
With Porsche Entry & Drive	
Without Porsche Entry & Drive	181
Steering wheel	69
Adjusting	70
Heating	69
Multi-functional steering wheel	
with telephone function	72
Multi-functional steering wheel	
without telephone function	73
Multi-functional steering wheel	
functional description	71
Operating the function keys	71
Shifting	198
Steering lock	180
Switching key illumination on/off	72
Stopping	201
Storage	253
Drawer under the right front seat	256
Glasses case in the roof console	253
Glove compartment	
Storage compartment at the sides	25-
of the luggage compartment	256
Storage compartment in the front armrest	251
Storage compartment in the rear armrest	250
Storage compartment in the rear affiliest	200
Storage compartment	
At the sides of the luggage compartment	
Drawer under the right front seat	256

Glasses case in the roof console	253
Glove compartment	254
In the front armrest	
In the rear armrest	255
Storage	253
Stowing luggage	265
When towing a Trailer	
Strap reel	
Inserting and adjusting	240
Strap reel storage location	240
Summer tires	403
Overview	
Storage	
Wheel change	
Sun visor	
Sunblind	
Cleaning position	
Opening/closing for Panorama roof system	110
Switching child lock (rear doors) on/off	36
Switching child protection on/off	
Switching ECON mode on/off	10,
With 2-zone air conditioning	88
With 4-zone air conditioning	
With manual air conditioning	
Switching front reading lights on/off	
Switching Mono function on/off	
With 2-zone air conditioning	87
With 4-zone air conditioning	
Switching on automatic recirculating-air mode	
With 2-zone air conditioning	87
With 4-zone air conditioning	95
Switching on door-surrounding lighting	130
Switching on fog lights	123
Switching on parking light	
Switching on recirculating-air mode	
With 2-zone air conditioning	. 88
With 4-zone air conditioning	95
With manual air conditioning	82
That manage are contained in the	52

1	
Tachometer	
Display	140
Tail light	
Changing bulb	388
Installing	387
Removing	386
Tank opening	302
Technical data	
Capacities	
Dimensions	
Engine	
Ground clearance	
Tire pressure (bar/psi)	
Transmission ratio	
Weights	
Telephone	250
Telescopic bar	
Inserting and adjusting	240
Temporary change-down	
Terrain level	220
Test stands	010
Brake test	
Performance test	
Theft protection	22
Tie-down	220
Belts	
Equipment	
Rings	244
Tie-down rings, securing points in the luggage compartment	220
Tiptronic S	239 60
Functional description	
Gear display on the multi-purpose display	
Rocker switches	
Rocker switches on the steering wheel	60
Selector lever	
Transmission ratios	
Tire	402
Care	322
Checking pressure	
Life Life	
Traction	
Wear	
Tire and rim sizes	

Tire pressure	.26
Air pressure (bar/psi)	.40
Load	.26
Plate	
Plate location	
Reducing347,	34
Warning light136,	13
Warning light on speedometer	.16
Warning message	.17
Tire Pressure Monitoring	
Setting on the multi-purpose display	.15
Tive eaglant (eagling est	
For defective tires	.33
Setting on the multi-purpose display	.16
Tires	
Changing251,	34
Damage	.32
Fitting spare wheel on spare wheel bracket	.35
Flat	
General information	
Inflating	.34
Inflating (with compressor from tool kit)	.34
Inflating (with compressor on vehicles	
with air suspension)	.34
Inscription on radial tire	
Overview	.40
Removing spare wheel from spare wheel bracket	35
Removing/fitting spacers	.34
Replacing	.32
Rim offset	
Sidewall	.32
Size327,	
Snow chains (general information)	
Spare wheel (general information)	.35
Storage	.32
Tracks	.40
Valves	.32
Winter tires (general information)	
Tool kit	.31
Compressor (on vehicles without air suspension)	
Jack	.32
Screwdriver	.32
Wedges	

Tools		310
	Compressor (on vehicles without air suspension)	330
	Jack	329
	Screwdriver	329
	Wedges	334
Towin	g	20:
	Capacity	26
	General information	39
	Towing bar	39
	Towing lug	39
	Towing rope	39
Tow-s	tarting	20
Track		
	Data	
Tracti	on	229
Trailer		
	Coupling	
	Effects on ParkAssist	
	Electrical connection	
	Hitching	
	Operation	26
	Retrofitting	26
	Tips on driving	
	Trailer load data	408
	Unhitching	26
Transı	mission	
	Shift pattern	
	Transmission ratios	40
Transp	port	
	Switching off inclination sensor	278
Transp	oort (on car trains, ferries, etc.)	22
Trip c	ounter	
	Display	
	Resetting	142
Turn s		
	Switch	12
Turn s	ignal light	
	Changing bulb	384
	Indicator light	13
Turn s	ignal pilot light	
	Indicator light	13
Turn s	signal, front	
	Changing bulb	
	Installing headlights	
	Removing headlights	37

Turn signal, rear	
Changing bulb	388
Installing tail light	387
Removing tail light	386
Turn signal/high beam/headlight flasher stalk	126
Two-zone air conditioning	
Air-conditioning sensors	89
Defrosting windshield	88
Operating overview	
REST mode	89
Setting air distribution	87
Setting air quantity	
Setting temperature	
Switching ECON mode on/off	88
Switching Mono function on/off	87
Switching on automatic recirculating-air mode	
Switching on recirculating-air mode	88
Switching on recirculating-air mode	
Switching on recirculating-air mode Using engine residual heat	
Using engine residual heat	
Using engine residual heat	89
Using engine residual heat U Ultrasonic measurement	89
Using engine residual heat U Ultrasonic measurement Ultrasound sensors, ParkAssist	272
Using engine residual heat U Ultrasonic measurement	272 270 272
Using engine residual heat U Ultrasonic measurement Ultrasound sensors, ParkAssist Ultrasound sources Undercoating (care instructions)	272 270 272
Using engine residual heat U Ultrasonic measurement	272 270 272 310
Using engine residual heat U Ultrasonic measurement	272 270 272 310
Using engine residual heat U Ultrasonic measurement Ultrasound sensors, ParkAssist Ultrasound sources Undercoating (care instructions) Uphill driving Offroad Traction	272 270 272 310
Using engine residual heat U Ultrasonic measurement Ultrasound sensors, ParkAssist Ultrasound sources Undercoating (care instructions) Uphill driving Off-road Traction Using engine residual heat	89272270272310229229
Using engine residual heat U Ultrasonic measurement Ultrasound sensors, ParkAssist Ultrasound sources Undercoating (care instructions) Uphill driving Off-road Traction Using engine residual heat With 2-zone air conditioning	272 270 272 310 229 229
Using engine residual heat U Ultrasonic measurement Ultrasound sensors, ParkAssist Ultrasound sources Undercoating (care instructions) Uphill driving Off-road Traction Using engine residual heat	8927227027231022922989

V	
Vehicle	
Battery	251
Care	
Charging the battery	
Data bank	
Identification number location	399
Keys	
Lowering with level control	222
Putting into operation	366
Raising vehicle with the jack	223
Raising with level control	
Recovering	397
Securing the vehicle against rolling	
Storage	
Storing your Porsche	
Switching off inclination sensor for transport	
Towing	394
Transporting	223
Vehicle door	
Locking with Porsche Entry & Drive (keyless)	28
Locking with the vehicle key (remote control)	
Unlocking with Porsche Entry & Drive (keyless)	
Unlocking with the vehicle key (remote control)	27
Vehicle key (remote control)	
Changing battery	3/1
Locking the vehicle door	
Opening/closing Panorama roof system	118
Opening/closing sliding/lifting roof	112
Opening/closing windows	100
(without Porsche Entry & Drive)	108
Unlocking the vehicle door	
Ventilation	
Vents	
Vertical coupling load	
Voltage indication	
Voltmeter	
Battery/alternator warning	144
W	
Warning - brake proportioning	177
Warning messages	,
Overview	172
Warning triangle	

Warning triangle (storage location)	256
Washer fluid	
Antifreeze	292
Change quantity	411
Level	292
Topping up	292
Washing	307
Water crossing	
Wedges to prevent rolling	33/
Wedges to prevent foiling	
Weights	334
Data	400
Wheel alignment	
Wheel change	323
Wheels	201
Adjusting	324
Changing	
Fitting spare wheel on spare wheel bracket	
Flat	
General information	317
Overview	403
Removing spare wheel from spare wheel bracket	350
Removing/fitting spacers	342
Rim offset	403
Security wheel bolt (wrench socket)	331
Size	403
Snow chains (general information)	326
Spare wheel (general information)	350
Storage	324
Tracks	
Wheel balancing	324
Wheel bolts (care instructions)	
Winter tires (general information)	325
Windows	OLG
Adjusting after connecting battery	100
Care instructions	310
Opening/closing with rocker switch	106
Opening/closing with vehicle key	100
(without Porsche Entry & Drive)	108
Windshield	100
Washer fluid	202
Windshield washer system	232
Change quantity	411
Mindehield winer (weeker stell)	411
Windshield wiper/washer stalk	100
Rain sensor adjustment	133
Rear window wiping plus washer system	134

Switching on intermittent operation	
of rear window wiper	13
Switching on rain sensor	
Windshield wiping plus washer system	134
Windshield, fast wiping	
Windshield, slow wiping	13
Wiping rear window once (one-touch function) .	13
Wiping windshield once (one-touch function)	
Windshield wipers	
Brief overview	13
Care instructions	
Rain sensor adjustment	
Rear window wiping plus washer system	
Switching on intermittent operation	
of rear window wiper	1.3
Switching on rain sensor	13:
Windshield wiping plus washer system	13
Windshield, fast wiping	13
Windshield, slow wiping	13
Wiping rear window once (one-touch function)	13
Wiping windshield once (one-touch function)	
Winter driving	36
Winter tires	
General information	
Overview	40
Storage	32
Wheel change	
Wiper blades	54
Care instructions	310
Changing (rear)	
With Porsche Entry & Drive	
Working on your vehicle	
Wrench socket (security wheel bolt)	33
Wichell Socket (Seedinty Wilcer Bolt)	55
X	
Xenon	
Changing bulb	38
Installing headlights	
Removing headlights	